COMPUTER MOUSE B2280HS-W1

iiyama ProLite B2280HS-1 LED Monitor User Manual

Model: B2280HS-W1

1. Introduction

Thank you for purchasing the iiyama ProLite B2280HS-1 LED Monitor. This manual provides essential information for the safe and efficient operation of your new display. Please read this manual thoroughly before using the product and keep it for future reference.

2. Safety Information

Always observe the following safety precautions to prevent injury and damage to the monitor.

- Do not expose the monitor to rain or moisture to prevent fire or shock hazards.
- Do not block ventilation openings. Ensure adequate space around the monitor for proper airflow.
- Use only the power cord and adapter supplied with the monitor.
- Do not place heavy objects on the power cord.
- Unplug the monitor from the power outlet during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. Package Contents

Verify that all items are present and in good condition upon unpacking.

- iiyama ProLite B2280HS-1 LED Monitor
- Power Cable
- VGA Cable
- DVI Cable
- Audio Cable
- User Manual (this document)

4. Setup

4.1. Physical Setup

Carefully remove the monitor from its packaging. Attach the stand base to the stand neck, and then attach the assembled stand to the monitor panel. Ensure all connections are secure.



Image 1: Front view of the iiyama ProLite B2280HS-1 LED Monitor, showcasing its white bezel and stand.

4.2. Connecting to a Computer

Connect the monitor to your computer using one of the following video cables:

- **VGA Connection:** Connect one end of the VGA cable to the VGA port on the monitor and the other end to the VGA port on your computer.
- **DVI Connection:** Connect one end of the DVI cable to the DVI port on the monitor and the other end to the DVI port on your computer.
- **HDMI Connection:** Connect one end of the HDMI cable (not supplied) to the HDMI port on the monitor and the other end to the HDMI port on your computer.

Connect the power cable to the monitor's power input and then to a wall outlet. If desired, connect the audio cable from your computer's audio output to the monitor's audio input for sound through the monitor's built-in speakers.

5. Operating the Monitor

5.1. Power On/Off

Press the power button located on the front or bottom bezel of the monitor to turn it on or off. The power indicator light will illuminate when the monitor is on.

5.2. Menu Navigation

Use the control buttons (usually located on the front or bottom bezel) to access and navigate the On-Screen Display (OSD) menu. Common menu options include:

- **Picture Settings:** Adjust brightness, contrast, sharpness, and color temperature.
- **Input Select:** Manually switch between VGA, DVI, and HDMI inputs.
- **Audio Settings:** Adjust volume and mute the speakers.
- **OSD Settings:** Change OSD language, position, and timeout.
- **Information:** Display current resolution and refresh rate.

6. Maintenance

To ensure the longevity and optimal performance of your monitor, follow these cleaning guidelines:

- Always unplug the monitor before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen.
- Avoid using harsh chemicals, solvents, or abrasive materials.

7. Troubleshooting

If you encounter issues with your monitor, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No image on screen	Power cable not connected; Video cable loose or incorrect input selected.	Check power and video cable connections; Select correct input source via OSD menu.
Image too dark/bright	Brightness/Contrast settings incorrect.	Adjust Brightness and Contrast in the OSD menu.
No sound from speakers	Audio cable not connected; Volume too low or muted.	Connect audio cable; Adjust volume in OSD menu or computer settings.

Problem	Possible Cause	Solution

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section

Submit question