TOTO MS854114-SW502-01

TOTO MS854114-SW502-01 One-Piece Toilet and Washlet Combination User Manual

Model: MS854114-SW502-01 | Brand: TOTO

1. Introduction

This manual provides essential information for the safe and efficient use of your TOTO MS854114-SW502-01 One-Piece Toilet and Washlet Combination. Please read these instructions thoroughly before installation and operation to ensure proper function and longevity of the product. This unit features a powerful gravity flushing system, a wide 3-inch flush valve, a fully glazed trapway, a heated seat, gentle aerated warm water rinse, adjustable water temperature and volume, oscillating comfort wash, and a self-cleaning dual-action spray.

2. Safety Information

Observe all local plumbing and building codes. Professional installation is recommended for optimal performance and safety. Ensure all water connections are secure to prevent leaks. Do not use abrasive cleaners on any part of the unit, especially the Washlet components, as this may cause damage. Disconnect power before performing any maintenance or cleaning of the Washlet.

3. Package Contents

Verify that all components are present before beginning installation:

- TOTO MS854114-SW502-01 One-Piece Toilet Bowl and Tank
- Integrated Washlet Unit
- SoftClose Seat
- Tank Cover
- Fittings
- Chrome Plated Trip Lever

- Installation Hardware
- User Manual (this document)

4. Setup and Installation

Installation of this one-piece toilet and Washlet combination requires basic plumbing knowledge. If you are unfamiliar with plumbing procedures, it is highly recommended to consult a qualified professional.

1. **Preparation:** Turn off the main water supply to the bathroom. Flush the old toilet to drain the tank and bowl. Remove the old toilet.
2. **Floor Flange:** Ensure the floor flange is clean and free of debris. Install new closet bolts into the flange.
3. **Wax Ring:** Place a new wax ring around the discharge opening on the bottom of the new toilet.
4. **Positioning:** Carefully lower the toilet onto the closet bolts, ensuring the wax ring creates a seal. Press down firmly and evenly.
5. **Securing:** Install washers and nuts onto the closet bolts. Tighten nuts alternately until the toilet is secure, but do not overtighten.
6. **Water Supply:** Connect the water supply line to the toilet's fill valve. Ensure all connections are hand-tightened, then use a wrench for a final quarter-turn.
7. **Washlet Power:** Connect the Washlet's power cord to a grounded electrical outlet.
8. **Water Supply to Washlet:** Connect the Washlet's water supply hose to the toilet's water supply.
9. **Test:** Turn on the main water supply. Check for leaks around the base of the toilet and all water connections. Flush the toilet and test Washlet functions.



Figure 1: The TOTO MS854114-SW502-01 One-Piece Toilet and Washlet Combination, fully assembled.

5. Operating Instructions

The Washlet unit is controlled via a convenient, easy-to-read control panel located on the right side of the unit. Familiarize yourself with the buttons and their functions.



Figure 2: The Washlet unit with the seat raised, revealing the self-cleaning dual-action spray nozzle.

5.1 Basic Cleansing Functions

- **Rear Wash:** Activates the rear cleansing spray.
- **Front Wash (Feminine Wash):** Activates the front cleansing spray.
- **Oscillating Wash:** Moves the nozzle back and forth for a wider cleansing area.

5.2 Temperature and Volume Adjustment

- **Water Temperature:** Use the designated buttons to adjust the temperature of the cleansing water.
- **Water Volume:** Use the designated buttons to adjust the intensity of the water spray.
- **Heated Seat:** Activate and adjust the heated seat temperature using the control panel.

5.3 Nozzle Position

Adjust the nozzle position forward or backward to find the most comfortable and effective cleansing angle.

5.4 Stop Function

Press the 'Stop' button to cease any active cleansing or drying function.

6. Maintenance

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your TOTO toilet and Washlet.

6.1 General Cleaning

- Clean the exterior of the toilet and Washlet with a soft cloth and a mild, non-abrasive cleaner.
- Do not use harsh chemicals, abrasive pads, or brushes, as these can damage the surfaces.
- Wipe down the control panel with a damp cloth.

6.2 Washlet Nozzle Cleaning

The Washlet features a self-cleaning dual-action spray nozzle. The nozzle automatically cleans itself before and after each use. For additional cleaning:

- Refer to your Washlet's specific manual for instructions on manual nozzle extension for cleaning.
- Use a soft brush and mild soap to gently clean the nozzle.
- Do not pull or force the nozzle.

6.3 Water Filter (If Applicable)

Some Washlet models may include a water filter. Consult your Washlet's specific manual for information on filter replacement schedules and procedures.

7. Troubleshooting

If you encounter issues with your TOTO toilet and Washlet, refer to the following common problems and solutions:

- **No Water Flow to Washlet:** Ensure the water supply valve to the Washlet is fully open. Check for kinks in the water supply hose.
- **Washlet Not Functioning:** Verify that the Washlet is properly plugged into a grounded electrical outlet and that the outlet has power. Check if the seat sensor is engaged (some Washlets require a user to be seated for functions to activate).

- **Weak Flush:** Ensure the water supply to the toilet tank is fully open. Check for obstructions in the trapway.
- **Continuous Running Water:** Inspect the flapper or fill valve in the toilet tank for proper seating or damage.
- **Leaks:** Tighten all water connections. Inspect the wax ring seal at the base of the toilet. If leaks persist, professional assistance may be required.

For issues not covered here, please contact TOTO customer support.

8. Specifications

Feature	Specification
Model Number	MS854114-SW502-01
Product Dimensions	33"D x 23"W x 28"H
Material	Cotton (Finish)
Item Weight	104 Pounds
Shape	Oblong
Flushing System	Power Gravity
Flush Valve Size	3 inches
Trapway Size	2 1/8 inches (fully glazed)
Rough-in	12 inches
Water Consumption	1.6 Gallons Per Flush (6 Lpf)
UPC	852324002242

9. Warranty and Support

TOTO products are manufactured to high-quality standards. For specific warranty details regarding your MS854114-SW502-01 One-Piece Toilet and Washlet Combination, please refer to the warranty card included with your purchase or visit the official TOTO website. For technical assistance, parts, or service, please contact TOTO customer support directly.

TOTO Customer Support: Visit TOTO USA Contact Page

© 2023 TOTO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question