Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Perfect Choice EL-993476

Perfect Choice HOME THEATER 5.1 EL-993476 User Manual

1. Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your Perfect Choice HOME THEATER 5.1 EL-993476 speaker system. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Product Overview

The Perfect Choice HOME THEATER 5.1 EL-993476 is a 5.1 channel speaker system designed for an immersive audio experience. It features a compact and elegant design, offering both 5.1 and 2.1 channel functionality. The satellite speakers are magnetically shielded for clear audio reproduction.



Figure 1: Perfect Choice HOME THEATER 5.1 EL-993476 Speaker System. This image displays the complete Perfect Choice HOME THEATER 5.1 EL-993476 speaker system. It includes one central subwoofer unit with a volume control knob on the front, and five compact satellite speakers. All components are black with a sleek design.

Package Contents:

- 1 x Subwoofer unit
- 5 x Satellite speakers
- Audio connection cables (3.5mm)
- Power cable

3. Setup Instructions

Follow these steps for easy installation and configuration of your speaker system:

1. **Placement:** Position the subwoofer on a stable surface, ideally near your audio source (e.g., PC). Arrange the five satellite speakers around your listening area for optimal 5.1 surround sound. Ensure adequate ventilation for the subwoofer.
2. **Connect Satellite Speakers:** Connect each of the five satellite speakers to the corresponding output ports on the rear of the subwoofer unit. Ensure connections are secure.
3. **Connect to Audio Source:** Use the provided 3.5mm audio cable to connect the subwoofer's input port to the audio output jack of your PC or other audio device.
4. **Power Connection:** Connect the power cable to the subwoofer's power input and then plug it into a standard AC power outlet.
5. **Initial Power On:** Turn on the power switch on the subwoofer. The system is now ready for operation.

4. Operating Instructions

Once the system is set up, follow these steps to operate your Perfect Choice HOME THEATER 5.1 EL-993476:

1. **Power On/Off:** Use the power switch located on the subwoofer to turn the system on or off.
2. **Volume Control:** Adjust the master volume using the prominent knob on the front panel of the subwoofer unit. Rotate clockwise to increase volume and counter-clockwise to decrease.
3. **Audio Source:** Ensure your connected audio source (e.g., PC) is playing audio and its volume is set to an appropriate level.
4. **Sound Configuration:** For 5.1 channel audio, ensure your audio source's sound settings are configured for 5.1 output. The system also supports 2.1 channel audio.

5. Maintenance

To ensure the longevity and optimal performance of your speaker system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the subwoofer and satellite speakers. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the subwoofer's ventilation openings are not blocked to prevent overheating.
- **Environment:** Avoid exposing the speakers to extreme temperatures, humidity, direct sunlight, or dusty environments.
- **Cable Management:** Keep cables tidy and free from kinks or excessive tension to prevent damage.

6. Troubleshooting

If you encounter issues with your speaker system, refer to the following troubleshooting tips:

- **No Sound:**
    - Ensure the power cable is securely plugged into both the subwoofer and the power outlet.
    - Verify the power switch on the subwoofer is in the 'ON' position.
    - Check that the 3.5mm audio cable is firmly connected to both the subwoofer and your audio source.
    - Confirm that your audio source (e.g., PC) is playing audio and its volume is not muted or set too low.
    - Adjust the volume knob on the subwoofer.

- **Distorted Sound:**
  - Reduce the volume on both the speaker system and your audio source.
  - Check for loose cable connections.
  - Ensure the audio source is not outputting a distorted signal.
- **Only Some Speakers Working:**
  - Verify that all satellite speakers are correctly connected to the subwoofer.
  - Check your audio source's sound settings to ensure it is configured for 5.1 channel output if you expect all speakers to function.

7. Specifications

Feature	Detail
Model	EL-993476
Audio Output Channels	5.1
Estimated RMS Power	8 W
Satellite Speaker Frequency Range	20 - 20000 Hz
Satellite Speaker Mid-range Driver Diameter	6.35 cm (2.5")
Subwoofer Driver Diameter	10.2 cm (4")
Input Connectivity	3.5 mm (Auxiliary)
Power Source	AC Current (Electric with cable)
Product Color	Black
Dimensions (W x D x H)	29.2 x 25.6 x 22.7 cm
Weight	3.36 kg
Special Features	Tweeters, Magnetic Shielding
Recommended Use	PC

8. Warranty and Support

Your Perfect Choice HOME THEATER 5.1 EL-993476 speaker system comes with a**Limited 1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

For technical support or warranty inquiries, please refer to the contact information provided with your product packaging or visit the official Perfect Choice website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00A9BFYA6

More documents and user manuals: **https://manuals.plus/**