Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nintendo NINRVLSWFSPGHW

Nintendo Wii Mini Console MotionPlus Bundle User Manual

Model: RVL-201(USA) / NINRVLSWFSPGHW

1. Introduction

This manual provides instructions for setting up, operating, and maintaining your Nintendo Wii Mini Console MotionPlus Bundle. The Wii Mini is a compact home video game console designed for playing Wii game discs. It includes a Wii Remote Plus and Nunchuk controller for an immersive gaming experience. Please note that the Wii Mini does not support internet connectivity or online features.

2. Package Contents

Verify that all items listed below are included in your package:

- Wii Mini Console (Red)
- Wii Remote Plus (Red)
- Nunchuk Controller (White)
- Wii AC Adapter
- Wii AV Cable
- Sensor Bar



Image: Included accessories: Wii AV Cable, Sensor Bar, and Wii AC Adapter.



Image: The Wii Remote Plus and Nunchuk controller, essential for gameplay.

3. Setup

3.1 Console Overview



Image: Top view of the Wii Mini console, showing its compact design.



Image: Rear view of the Wii Mini console, displaying the power input, AV output, and USB port.

3.2 Connecting to a Television

1. Connect the multi-out plug of the Wii AV Cable to the AV Multi Out port on the back of the Wii Mini console.
2. Connect the yellow (video), white (left audio), and red (right audio) RCA plugs of the Wii AV Cable to the corresponding input jacks on your television.
3. Set your television to the correct video input channel (e.g., Video 1, AV, Input).

3.3 Connecting Power

1. Plug the Wii AC Adapter into the AC Adapter port on the back of the Wii Mini console.
2. Plug the other end of the AC Adapter into a standard wall outlet.

3.4 Setting up the Sensor Bar

1. Place the Sensor Bar either above or below your television, centered horizontally.
2. Connect the Sensor Bar cable to the Sensor Bar port on the back of the Wii Mini console.

3.5 Connecting Controllers

1. Insert two AA batteries into the Wii Remote Plus, ensuring correct polarity.
2. Attach the wrist strap to the Wii Remote Plus.
3. To connect the Nunchuk, plug its connector into the expansion port at the bottom of the Wii Remote Plus.
4. Press the SYNC button inside the battery compartment of the Wii Remote Plus, then quickly press the SYNC button on the front of the Wii Mini console (located near the disc slot). The player indicator lights on the Wii Remote Plus will flash and then light up solid when connected.

4. Operating Instructions

4.1 Turning On/Off

- To turn on the console, press the POWER button on the Wii Mini console or the POWER button on the Wii Remote Plus.
- To turn off the console, press and hold the POWER button on the Wii Mini console or the POWER button on the Wii Remote Plus until the console shuts down.

4.2 Inserting and Ejecting Game Discs

1. To open the disc cover, press the OPEN button located on the front right corner of the console.
2. Place a Wii game disc onto the disc spindle with the label side facing up. Gently press down on the center of the disc until it clicks into place.
3. Close the disc cover.
4. To eject a disc, open the disc cover and carefully lift the disc from the spindle.



Image: The Wii Mini console with its top-loading disc tray open, ready for disc insertion.

4.3 Playing Games

Once a game disc is inserted and the console is powered on, the game will typically start automatically. Follow on-screen instructions and use the Wii Remote Plus and Nunchuk to navigate menus and play games.

4.4 Important Note on Connectivity

The Nintendo Wii Mini console does not connect to the internet and does not support any online features in

games. All gameplay is offline.

5. Maintenance

5.1 Cleaning the Console

- Use a soft, dry cloth to wipe the exterior of the console.
- Do not use liquid cleaners, solvents, or abrasive materials.
- Keep the console's ventilation openings clear of dust and debris.

5.2 Disc Care

- Handle discs by their edges to avoid fingerprints and scratches.
- Store discs in their cases when not in use.
- Clean discs with a soft, lint-free cloth, wiping from the center outwards.

5.3 Wii Remote Plus Battery Replacement

When the battery indicator on the Wii Remote Plus is low, replace both AA batteries with new ones. Ensure correct polarity (+/-) when inserting batteries.

6. Troubleshooting

- **No Power:** Ensure the AC adapter is securely connected to both the console and a working wall outlet.
- **No Video/Audio:** Check that the AV cables are correctly connected to both the console and the TV, and that the TV is set to the correct input channel.
- **Disc Read Error:** Ensure the disc is clean and free of scratches. Make sure the disc is inserted correctly with the label side up.
- **Wii Remote Not Responding:** Ensure batteries are fresh and correctly inserted. Re-sync the Wii Remote with the console (see Section 3.5). Ensure the Sensor Bar is properly connected and positioned.
- **Console Overheating:** Ensure the console's ventilation openings are not blocked and there is adequate airflow around the unit.

7. Specifications

Model Number	RVL-201(USA) / NINRVLSWFSPGHW
Platform	Nintendo Wii
Power Rating	12V ⎓ 32W (Use RVL-002(USA) AC Adapter only)
Dimensions (Approx.)	Compact design (specific dimensions not provided in source)
Weight (Approx.)	5 pounds (console only)
Connectivity	AV Multi Out, Sensor Bar Port, USB Port (for accessories, not internet)



Image: The regulatory label on the bottom of the Wii Mini console, displaying model and serial information.

8. Safety Information

- Do not expose the console or accessories to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or modify the console.
- Keep the console away from water or other liquids.
- Ensure adequate ventilation around the console during use.
- Use only the provided AC adapter and accessories.
- Always use the Wii Remote wrist strap during gameplay to prevent injury or damage.

9. Customer Support

For technical assistance or product inquiries, please contact Nintendo Customer Support:

- **Website:** support.nintendo.com
- **Phone:** 1-800-255-3700

Please have your console's model number and serial number ready when contacting support.

© 2006 Nintendo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00AJZNUUI

More documents and user manuals: **https://manuals.plus/**