Kärcher 6.295-773.0

Kärcher RM 500 Window Cleaning Solution User Manual

Model: 6.295-773.0

1. Introduction

This user manual provides essential information for the safe and effective use of the Kärcher RM 500 Window Cleaning Solution. Please read this manual thoroughly before first use and keep it for future reference. This product is designed for cleaning water-resistant smooth surfaces, particularly windows, and is compatible with Kärcher window vacuums.

2. Product Overview





Image: Kärcher RM 500 Window Cleaning Solution in a white bottle with a black cap. The label shows the Kärcher logo, "GLASREINIGER-KONZENTRAT" (Glass Cleaner Concentrate), and icons indicating streak-free cleaning, material friendliness, pleasant scent, good wetting, and manual applicability. It also states "Geeignet für Kärcher Fenstersauger" (Suitable for Kärcher Window Vacuums).

Product Description

The Kärcher RM 500 is an equipment cleansing liquid specifically formulated for streak-free cleaning of all water-resistant smooth surfaces. It effectively removes stubborn stains such as grease films, insect residues, skin oils, and emissions. The solution features a fresh, pleasant aroma and is extremely gentle on materials.

Key Features:

- For streak-free cleaning of all water-resistant smooth surfaces.
- Removes stubborn stains including grease films, insect, skin oils, and emissions.
- Fresh, pleasant aroma.
- Extremely gentle on materials.

Compatibility:

This cleaning solution is suitable for use with Kärcher window vacuums, including models WV 50 Plus, WV 60 Plus, WV 75 Plus, WV 5, WV Classic, and WV 2.

3. Setup

Preparation Before Use:

1. Ensure the surface to be cleaned is free from loose dirt or debris.
2. For optimal results, use with a Kärcher window vacuum cleaner.

Dilution Instructions:

The Kärcher RM 500 is a concentrate and must be diluted before use. Follow these guidelines:

- **For Kärcher Window Vacuums:** Mix 1 capful (approximately 20 ml) of RM 500 concentrate with 200 ml of water in the spray bottle provided with your window vacuum.
- **For Manual Application:** For general cleaning with a cloth or sponge, dilute 1 capful of concentrate in 5 liters of water. Adjust concentration based on the level of dirt.

Always use clean, fresh water for dilution.

4. Operating Instructions

Using with Kärcher Window Vacuums:

1. Prepare the cleaning solution as per the dilution instructions in Section 3.
2. Spray the diluted solution evenly onto the surface to be cleaned using the spray bottle.
3. Allow the solution to work for a short period (do not let it dry).
4. Use your Kärcher window vacuum to suction the dirty water from the surface, moving the device in straight, overlapping strokes.
5. For best results, wipe the rubber lip of the window vacuum clean after each stroke.

Manual Application:

1. Prepare the cleaning solution as per the dilution instructions in Section 3.
2. Apply the diluted solution to the surface using a clean cloth or sponge.
3. Wipe the surface thoroughly to remove dirt.
4. For a streak-free finish, wipe dry with a clean, lint-free cloth or a squeegee.

Tips for Best Results:

- Avoid cleaning in direct sunlight or on hot surfaces to prevent premature drying and streaking.
- For heavily soiled surfaces, a pre-treatment with a stronger cleaner or a second application may be necessary.
- Always test the solution on an inconspicuous area first, especially on delicate or painted surfaces.

5. Maintenance

Storage:

- Store the Kärcher RM 500 in its original container, tightly closed.
- Keep out of reach of children and pets.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.
- Do not store with food or beverages.

Disposal:

Dispose of contents/container in accordance with local/regional/national/international regulations. Do not pour unused solution down drains or into water bodies.

6. Troubleshooting

Problem	Possible Cause	Solution
Streaks on surface after cleaning.	• Solution too concentrated. • Surface not properly rinsed or wiped. • Cleaning in direct sunlight. • Dirty squeegee blade/cloth.	• Dilute solution further. • Ensure thorough wiping/suction. • Clean during cooler times or in shade. • Clean or replace squeegee blade/use clean cloth.
Insufficient cleaning power.	• Solution too diluted. • Heavy soiling.	• Increase concentration slightly (within recommended limits). • Pre-treat heavily soiled areas or apply solution twice.
Unpleasant odor.	• Contaminated water or equipment.	• Use fresh, clean water for dilution. • Clean your spray bottle and window vacuum reservoir regularly.

7. Specifications

- **Product Type:** Equipment cleansing liquid
- **Volume:** 500 ml (0.5 Liters)
- **Color:** White
- **Item Weight:** 1.2 pounds
- **Product Dimensions:** 2.56 x 2.56 x 8.27 inches
- **Model Number:** 6.295-773.0
- **Special Features:** Streak-free
- **Usage:** Window, Glass
- **Scent:** Wv (fresh, pleasant aroma)
- **Compatibility:** Kärcher WV 50 Plus, WV 60 Plus, WV 75 Plus, WV 5, WV Classic, WV 2 window vacuums.

8. Warranty and Support

For information regarding product warranty, technical support, or service, please visit the official Kärcher website or contact Kärcher customer service directly. Contact details can typically be found on the Kärcher website or on the product packaging. You can find more information and support at the Kärcher Store on Amazon.

© 2024 Kärcher. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question