Sony DSC-W730

Sony DSC-W730 Digital Camera Instruction Manual

Introduction

This manual provides essential instructions for the safe and effective use of your Sony DSC-W730 digital camera. Please read this manual thoroughly before operating the camera and retain it for future reference. The Sony DSC-W730 is a compact digital camera featuring a 16.1 megapixel CCD sensor, an 8x optical zoom Carl Zeiss Vario-Tessar lens, and Optical SteadyShot image stabilization. It is designed for capturing high-quality photos and 720p HD videos with ease.

Package Contents

Verify that your package contains the following items:

- Sony DSC-W730 Digital Camera
- Rechargeable Lithium-Ion Battery
- AC Adapter/USB Cable
- Wrist Strap
- Instruction Manual (this document)

Note: Memory card is typically sold separately.

Setup

1. Charging the Battery

1. Insert the supplied rechargeable battery into the camera.
2. Connect the camera to the AC adapter using the USB cable.
3. Plug the AC adapter into a wall outlet. The charge lamp will light up.
4. Charging is complete when the charge lamp turns off.

2. Inserting a Memory Card (Sold Separately)

Open the battery/memory card cover. Insert a compatible memory card (e.g., SD, SDHC, Memory Stick

Duo) into the slot with the correct orientation until it clicks into place. Close the cover securely.

3. Initial Settings

Upon first power-on, the camera may prompt you to set the date, time, and region. Follow the on-screen instructions using the directional buttons and the center button to confirm selections.

Operating Instructions



This image displays the back of the Sony DSC-W730 camera. It features a large LCD screen on the left, and on the right, various control buttons including the zoom lever (W/T), playback button, menu button, and a directional pad with DISP, flash, and self-timer functions. The power button is located on the top right.

Power On/Off

Press the **ON/OFF** button located on the top of the camera to turn it on or off.

Taking Photos

1. Turn on the camera.
2. Frame your shot using the 2.7-inch LCD display.
3. Use the **W/T** lever to zoom in (T) or out (W).

4. Press the shutter button halfway down to focus. The focus indicator will light up.
5. Press the shutter button all the way down to take the picture.

Recording Videos (720p MP4 HD Movie Mode)

To record a video, switch the camera to movie mode (refer to the mode selection on your camera, often indicated by a film reel icon). Press the shutter button to start recording and press it again to stop. Videos are recorded in 720p HD resolution at 30 frames per second.

Intelligent Auto Mode

This mode automatically detects the scene, lighting conditions, and faces, adjusting camera settings for optimal results. It helps achieve clear images with natural skin tones and reduced blur without manual adjustments.

Sweep Panorama Mode

Select Sweep Panorama mode from the camera's menu. Press the shutter button and sweep the camera horizontally or vertically in the desired direction. The camera will automatically stitch multiple images together to create a single panoramic photo, up to 360 degrees.

Image Enhancement Features

- **Beauty Effects:** Adjust skin tones, smooth skin, remove shine, widen eyes, and whiten teeth. These effects can be combined.
- **Picture Effect:** Apply creative filters like Pop Color, Toy Camera, or Partial Color to enhance the mood and visual style of your photos.
- **Advanced Flash:** This feature extends the flash range, illuminating distant subjects more effectively in dimly lit environments.

Focus and Detection Technologies

- **Face Detection:** Automatically detects up to eight individual faces in a scene and adjusts focus, exposure, and white balance for clear, well-lit portraits.
- **Smile Shutter:** When activated, the camera automatically captures a photo the moment it detects a smile. Sensitivity can be adjusted, and it can be used with Intelligent Auto mode.

Viewing Images and Videos

Press the playback button (often indicated by a play icon) to view your captured photos and videos on the 2.7-inch Clear Photo LCD display. Use the directional buttons to navigate through your media.

Maintenance

Cleaning the Camera

- **Camera Body:** Wipe with a soft, dry cloth. For stubborn dirt, use a cloth lightly dampened with water or a mild detergent, then wipe dry.
- **Lens:** Use a lens brush to remove dust, then gently wipe with a lens cleaning cloth. Avoid touching the lens with your fingers.
- **LCD Screen:** Gently wipe with a soft, dry cloth. Avoid pressing hard on the screen.

Battery Care

- Always use the original Sony battery and charger.

- Do not expose the battery to excessive heat or cold.
- If not using the camera for an extended period, remove the battery.

Storage

Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Use a camera case to protect it from dust and scratches.

Troubleshooting

If you encounter issues with your camera, refer to the following common solutions:

- **Camera does not turn on:** Ensure the battery is fully charged and correctly inserted.
- **Cannot take pictures:** Check if a memory card is inserted and has sufficient free space. Ensure the lens cap is removed (if applicable).
- **Pictures are blurry:** Ensure the lens is clean. Check if the camera is in focus before taking the shot. Use Optical SteadyShot for stability.
- **Flash does not fire:** Check flash settings to ensure it is not set to "Flash Off" or "Red-eye Reduction" in bright conditions.
- **Battery drains quickly:** Reduce LCD brightness, limit video recording, and turn off the camera when not in use. Ensure the battery is not old or damaged.
- **Camera freezes:** Remove and reinsert the battery to reset the camera.

For more detailed troubleshooting, please consult the full user manual available on the Sony support website.

Specifications

Model Number	DSC-W730
Image Sensor	16.1 Megapixel CCD
Lens	Carl Zeiss Vario-Tessar, 8x Optical Zoom
Image Stabilization	Optical SteadyShot with 2-way Active Mode
LCD Display	2.7-inch (230K dots) Clear Photo LCD
Video Recording	720p MP4 HD (1280 x 720 at 30 fps)
Dimensions (W x H x D)	3.66 x 0.87 x 2.05 inches (approx.)
Weight	4.3 ounces (approx.)
Battery Type	Lithium Ion (included)
Supported File Format	JPEG (Exif 2.3)

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Sony support website. You can find detailed support resources, FAQs, and contact information there.

Official Sony Support: www.sony.com/electronics/support

© 2024 Sony Corporation. All rights reserved.