FurReal A1649

FurReal Friends Trixie - The Skateboarding Pup Instruction Manual

Model: A1649 | Brand: FurReal

Introduction

The FurReal Friends Trixie - The Skateboarding Pup is an interactive electronic pet designed to provide engaging play. This cuddly companion responds to touch and features realistic pet movements and sounds. Trixie can be posed in various positions and interacts with her remote-controlled skateboard, offering a dynamic play experience for children aged 4 and up.



Image: FurReal Friends Trixie the Skateboarding Pup, shown with her remote control, bandana, and star-shaped sunglasses, ready on her pink skateboard.

What's Included

- Trixie the Skateboarding Pup
- Skateboard
- Remote Control (27 MHz)
- Patterned Bandana
- Star-shaped Sunglasses
- Stickers for customization

Setup

1. Battery Installation

Batteries are not included and must be installed before use.

- **Remote Control:** Requires 2 x 1.5V AAA alkaline batteries. Locate the battery compartment on the underside of the remote control. Use a Phillips head screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and replace the cover securely.
- **Skateboard:** Requires 3 x 1.5V AA alkaline batteries. Locate the battery compartment on the underside of the skateboard. Use a Phillips head screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and replace the cover securely.

Important: Always use fresh batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period.

2. Dressing and Decorating Trixie

- **Bandana:** Tie the patterned bandana around Trixie's neck, head, or tail as desired.
- **Sunglasses:** Gently place the star-shaped sunglasses over Trixie's eyes.
- **Skateboard Stickers:** Use the provided stickers to personalize Trixie's skateboard. Ensure stickers do not obstruct the wheels or battery compartment.

3. Attaching Trixie to the Skateboard

Trixie attaches to the skateboard using Velcro strips on her paws and the skateboard surface. Align Trixie's paws with the Velcro strips on the skateboard and press down gently to secure her. Ensure she is stable before operation.

Operating Instructions

1. Posing Trixie for Tricks

Trixie features posable ears, head, and legs, allowing for over 30 different trick poses. Adjust her limbs and head to create various dynamic stances on the skateboard, such as a "wheelie" or a playful lean.

2. Using the Remote Control

The 27 MHz remote control allows you to guide Trixie on her skateboard. It features two primary buttons:

- **Forward Button:** Press to make the skateboard move forward.
- **Spin Button:** Press to make the skateboard spin in circles.

As Trixie moves, the remote control will activate various sounds and fun music, enhancing the play experience. Ensure the remote control is pointed towards Trixie for optimal responsiveness.

3. Cuddle Time

After skateboarding adventures, Trixie can be easily removed from her skateboard for cuddling. Gently detach her paws from the Velcro strips on the skateboard.

Your browser does not support the video tag.

Video: An official demonstration of FurReal Friends Trixie the Skateboarding Pup, showcasing her remote-controlled movements, posing capabilities, and interactive sounds.

Care and Maintenance

- **Cleaning:** Surface clean Trixie with a damp cloth only. Do not immerse in water.
- **Battery Care:** Remove batteries from both the remote control and skateboard if the toy will not be used for an extended period to prevent leakage and damage.
- **Velcro Maintenance:** Periodically check the Velcro strips on Trixie's paws and the skateboard. Gently remove any trapped hair or debris to ensure a secure attachment.
- **Storage:** Store Trixie and her accessories in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Trixie is not moving or responding:**
  - Ensure fresh batteries are correctly installed in both the remote control and the skateboard.
  - Verify that the remote control is within range and pointed towards Trixie.
  - Check for any obstructions preventing movement of the skateboard wheels.
- **Sounds are distorted or absent:**
  - Replace the batteries in the skateboard.
- **Skateboard is not performing tricks correctly:**
  - Ensure Trixie is securely and correctly positioned on the skateboard.
  - Practice remote control movements to master the timing for specific tricks.

Specifications

Model Number	A1649
Brand	FurReal
Manufacturer	Hasbro
Age Recommendation	4 years and up
Remote Control Batteries	2 x 1.5V AAA Alkaline (not included)
Skateboard Batteries	3 x 1.5V AA Alkaline (not included)
Item Weight	1.85 Pounds (approximately 0.84 kg)
Item Dimensions	5.24 x 15.51 x 10.98 inches (L x W x H)

GTIN / UPC	653569840206

Warranty and Support

No specific warranty information is provided with this product data. For detailed warranty information, product support, or to inquire about replacement parts, please refer to the official Hasbro or FurReal website, or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Hasbro

Website: www.hasbro.com

© 2013 Hasbro. All rights reserved. FurReal and all related terms are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question