Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nippon NTX3007PZ

Nippon NTX3007PZ Super Horn Tweeter User Manual

Model: NTX3007PZ | Brand: Nippon

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Nippon NTX3007PZ Super Horn Tweeter. Please read this manual thoroughly before using the product to ensure optimal performance and safety.



Figure 1: Nippon NTX3007PZ Black Super Horn Tweeter. This image displays the black, rectangular horn-shaped tweeter with a circular housing at the rear, designed for car audio systems.

2. Product Features

- **Model:** Nippon NTX3007PZ
- **Type:** 7 1/2 X 3 1/4 Black Super Horn Tweeter
- **Power Handling:**
  - Maximum Watts: Not specified in detail, designed for high output.
  - RMS Watts: Not specified in detail, designed for continuous power.

- **Tweeter Type:** 3/16" PEI Balanced Tweeter
- **Design:** Piezo Horn
- **Frequency Response:** 0.8 KHz - 30 KHz
- **Impedance:** Not specified in detail, typically 4 or 8 Ohm for car audio.

3. Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Please handle with care and ensure proper ventilation during installation. Always follow local regulations for disposal.

4. Setup and Installation

Proper installation is crucial for optimal performance and longevity of your tweeter. It is recommended that installation be performed by a qualified professional.

4.1. Before Installation

- Ensure your vehicle's audio system is turned off and the battery is disconnected to prevent electrical shorts.
- Verify that the tweeter's impedance and power handling are compatible with your amplifier or head unit.
- Choose a suitable mounting location that allows for proper sound dispersion and physical clearance.

4.2. Wiring

- Connect the positive (+) terminal of the tweeter to the positive (+) output of your amplifier or crossover.
- Connect the negative (-) terminal of the tweeter to the negative (-) output of your amplifier or crossover.
- Ensure all connections are secure and insulated to prevent short circuits.

4.3. Mounting

- Carefully cut an opening in the chosen mounting surface that matches the dimensions of the tweeter's horn.
- Secure the tweeter using appropriate screws through the mounting holes on its flange.
- Ensure the tweeter is firmly seated and does not vibrate.

5. Operating Instructions

The Nippon NTX3007PZ Super Horn Tweeter is a passive component designed to reproduce high-frequency sounds. Once properly installed and connected to an audio system, it will operate automatically when audio signals are sent to it.

- **Initial Power-Up:** After installation, reconnect your vehicle's battery. Turn on your audio system at a low volume.
- **Volume Adjustment:** Gradually increase the volume to a comfortable listening level. Avoid excessively high volumes, which can damage the tweeters or other audio components.
- **Sound Customization:** Use your head unit's or amplifier's equalizer settings to fine-tune the treble output to your preference.

6. Maintenance

The Nippon NTX3007PZ Super Horn Tweeter requires minimal maintenance.

- **Cleaning:** Use a soft, dry cloth to gently wipe the surface of the tweeter. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check the wiring connections to ensure they remain secure and free from corrosion.
- **Environmental Factors:** Protect the tweeter from extreme temperatures, direct sunlight, and excessive moisture, which can affect its performance and lifespan.

7. Troubleshooting

If you experience issues with your tweeter, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No Sound from Tweeter	Loose or incorrect wiring. Amplifier/head unit issues. Damaged tweeter.	Check all wiring connections for security and correct polarity. Verify that the amplifier or head unit is functioning correctly and sending a signal. If connections are correct and other components work, the tweeter may be damaged and require replacement.
Distorted Sound	Overpowering the tweeter. Incorrect equalizer settings. Poor quality audio source.	Reduce the volume or amplifier gain. Adjust equalizer settings to reduce excessive treble boost. Try a different audio source to rule out source issues.
Intermittent Sound	Loose connections. Vibration.	Inspect and secure all wiring connections. Ensure the tweeter is securely mounted and not vibrating excessively.

8. Specifications

Attribute	Detail
Brand	Nippon
Model Name	NTX3007PZ
Speaker Type	Tweeter
Speaker Size	7.5 Inches (7 1/2 X 3 1/4)
Product Dimensions	7.5 x 3.2 x 4 inches (D x W x H)
Item Weight	0.01 Ounces
Power Source	Corded Electric (requires external amplifier/head unit)
Connectivity Protocol	Wired (Bluetooth listed in original data is likely an error for this passive component)
Is Waterproof	FALSE

Attribute	Detail
UPC	100177405902, 151903159033, 163120504299
ASIN	B00ATZLR5S
Date First Available	October 27, 2012

Note: Some specifications like "Connectivity Protocol: Bluetooth" and "Is Waterproof: FALSE" might be generic data points from the source. This tweeter is a passive component and typically connects via speaker wire, not Bluetooth.

9. Warranty and Support

This Nippon NTX3007PZ Super Horn Tweeter comes with a**1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.
For warranty claims or technical support, please contact your retailer or the official Nippon support channels. Keep your proof of purchase for warranty validation.
Legal Disclaimer: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

© 2024 Nippon. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00ATZLR5S

More documents and user manuals: **https://manuals.plus/**