Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beetel B80

Beetel B80 Corded Landline Phone User Manual

Model: B80

1. Introduction

Thank you for choosing the Beetel B80 Corded Landline Phone. This manual provides essential information for the proper setup, operation, and maintenance of your new telephone. Please read this manual thoroughly before using the phone to ensure optimal performance and longevity.

2. Package Contents

Please check the package for the following items:

- Beetel B80 Corded Landline Phone Unit
- Handset
- Coiled Handset Cord
- Line Cord
- User Manual (this document)

3. Setup

3.1 Connecting the Phone

1. **Connect the Handset:** Plug one end of the coiled handset cord into the handset and the other end into the jack on the side of the phone base marked with a handset icon.
2. **Connect to the Telephone Line:** Plug one end of the line cord into the jack on the back of the phone base marked with a telephone wall jack icon. Plug the other end into your telephone wall outlet.

3.2 Desk or Wall Mounting

The Beetel B80 is designed for both desk and wall mounting.



Image: The Beetel B80 phone is versatile, allowing for placement on a desk or secure mounting on a wall.

Desk Mounting:

Place the phone on a flat, stable surface. Ensure the cords are not tangled or obstructing movement.

Wall Mounting:

1. Locate the wall mounting holes on the back of the phone base.
2. Secure two screws (not supplied) into the wall, spaced to match the mounting holes. Leave a small gap between the screw head and the wall.
3. Align the phone's mounting holes with the screws and slide the phone downwards to secure it.
4. To prevent the handset from falling when wall-mounted, reverse the small plastic tab in the handset cradle so it protrudes upwards, holding the handset securely.

4. Operating Instructions

4.1 Making a Call

1. Lift the handset.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad.
4. Once the call is complete, replace the handset in the cradle.

4.2 Receiving a Call

1. When the phone rings, lift the handset to answer the call.
2. Once the call is complete, replace the handset in the cradle.

4.3 Function Buttons

- **MUTE:** Press this button during a call to temporarily mute your microphone. The other party will not hear you, but you can still hear them. Press again to unmute.
- **PAUSE:** Used for dialing sequences that require a pause, typically when accessing external lines or special services. Press this button to insert a pause in the dialing string.
- **FLASH:** Used to access network features such as call waiting or conference calling. Press this button to send a flash signal to the telephone exchange.
- **REDIAL:** Press this button to automatically dial the last number called.

4.4 Ringer Volume Control

The Beetel B80 features a ringer volume control switch, allowing you to adjust the incoming call volume to your preference.



Image: The Beetel B80 includes a ringer volume control feature, allowing users to adjust the loudness of incoming call alerts.

Locate the ringer volume switch on the side or bottom of the phone base. Slide the switch to select your desired volume level (e.g., High, Low, Off).

4.5 Tone/Pulse Dialing Switch

The phone supports both Tone (DTMF) and Pulse dialing modes. Most modern telephone systems use Tone dialing. If you are unsure, consult your telephone service provider or try Tone mode first.
Locate the Tone/Pulse switch on the bottom of the phone base and set it to the appropriate mode for your telephone line.

5. Maintenance

- **Cleaning:** Wipe the phone with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Avoid Liquids:** Keep the phone away from water and other liquids. If liquid spills on the phone, immediately unplug it from the wall outlet and allow it to dry completely before reconnecting.
- **Placement:** Avoid placing the phone in direct sunlight or near heat sources. Ensure adequate ventilation.
- **Cords:** Periodically check the cords for any signs of damage. Replace damaged cords immediately.

6. Troubleshooting

Problem	Possible Cause	Solution
No dial tone	Line cord is loose or disconnected. Telephone service issue.	Check all cable connections. Test with another phone if available. Contact your telephone service provider.
Phone does not ring	Ringer volume set to OFF or LOW. Telephone service issue.	Check the ringer volume switch and set it to HIGH. Contact your telephone service provider.

Problem	Possible Cause	Solution
Cannot hear caller / Caller cannot hear me	Handset cord loose. Mute function activated.	Ensure handset cord is securely plugged in. If MUTE is active, press the MUTE button again.
Dialing errors	Incorrect Tone/Pulse setting.	Check the Tone/Pulse switch on the bottom of the phone and set it correctly.

7. Specifications

Model	Beetel B80
Type	Corded Landline Phone
Dialer Type	Single Keypad
Dialing Mode	Tone/Pulse Switchable
Ringer Control	Adjustable Volume
Mounting Options	Desk / Wall Mountable
Functions	Mute, Pause, Flash, Redial
Material	Plastic
Dimensions (L x W x H)	21.9 x 15.2 x 7.9 Centimeters
Weight	510 Grams
Power Source	Corded Electric (Line Powered)
Country of Origin	India

8. Warranty Information

The Beetel B80 Corded Landline Phone comes with a **1-year manufacturer warranty** for the device from the date of purchase. In-box accessories, including batteries (if applicable), are covered by a **6-month manufacturer warranty** from the date of purchase.
Please retain your purchase receipt as proof of purchase for warranty claims. For detailed warranty terms and conditions, please refer to the official Beetel website or contact customer support.

9. Customer Support

For any queries, technical assistance, or warranty claims, please contact Beetel Customer Support:

Toll-Free Number: 1800-102-3456

Email: customer.care@beetel.in

Website: Visit the official Beetel website for more information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00AWPOQJY

More documents and user manuals: **https://manuals.plus/**