Sony BDP-S1100

Sony BDP-S1100 Blu-ray Disc Player User Manual

Important Safety Instructions

Please read all safety and operating instructions carefully before using this product. Retain these instructions for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- Do not expose the unit to rain or moisture.
- Do not open the cabinet. Refer servicing to qualified personnel only.
- Ensure proper ventilation to prevent overheating.
- Use only the power supply specified for this unit.

Product Overview

The Sony BDP-S1100 is a Blu-ray Disc Player designed for Full HD 1080p playback and DVD upscaling. It provides access to a wide range of streaming services and supports USB media playback. The fully-encased optical drive helps ensure optimal disc playback quality.



Image: Front view of the Sony BDP-S1100 Blu-ray Disc Player, showcasing its compact design and disc tray.

Front Panel Features

- **Power Button:** Turns the player on or off.
- **Disc Tray:** For inserting Blu-ray discs and DVDs.
- **USB Port:** For connecting USB storage devices to play photos, videos, and music.
- **Open/Close Button:** Ejects or closes the disc tray.

Rear Panel Connections

- **HDMI OUT:** Connects to your TV or AV receiver for high-definition video and audio.
- **COAXIAL AUDIO OUT:** Connects to an audio receiver for digital audio output.
- **LAN (Ethernet) Port:** Connects to your home network for internet access and streaming services.
- **AC IN:** Connects to the power supply.

Setup

1. Unpacking

Carefully remove all components from the packaging. Ensure the following items are present:

- Sony BDP-S1100 Blu-ray Disc Player
- Remote Control with Batteries
- AC Power Cord
- Instruction Manual (this document)

2. Connecting to a Television

For the best picture and sound quality, connect the player to your TV using an HDMI cable.

1. Connect one end of an HDMI cable (not included) to the **HDMI OUT** port on the rear of the Blu-ray player.
2. Connect the other end of the HDMI cable to an available **HDMI IN** port on your television. Note the HDMI input number (e.g., HDMI 1, HDMI 2).
3. Ensure your TV is powered on and set to the correct HDMI input source.

3. Connecting to an Audio System (Optional)

If you wish to connect the player to an external audio receiver for surround sound, use a coaxial digital audio cable.

1. Connect one end of a coaxial digital audio cable (not included) to the **COAXIAL AUDIO OUT** port on the rear of the Blu-ray player.
2. Connect the other end to a coaxial digital audio input on your audio receiver.
3. Configure your audio receiver to select the correct digital audio input.

4. Network Connection

To access streaming services and firmware updates, connect the player to your home network using an Ethernet cable.

1. Connect one end of an Ethernet cable (not included) to the **LAN** port on the rear of the Blu-ray player.
2. Connect the other end to an available LAN port on your internet router or modem.
3. After powering on the player, navigate to the network settings menu on your TV screen to configure the connection. Most home networks will automatically assign an IP address.
4. *Troubleshooting Tip:* If you experience difficulty accessing internet services after initial setup, try manually setting the DNS servers in the player's network settings to:
   Primary DNS: 8.8.8.8
   Secondary DNS: 8.8.4.4

5. Power Connection

Connect the AC power cord to the **AC IN** port on the rear of the player, then plug the other end into a wall outlet.

Operating Instructions

Basic Disc Playback

1. Press the Power button to turn on the player.
2. Press the Open/Close button to open the disc tray.
3. Place a Blu-ray disc or DVD onto the disc tray with the label side facing up.
4. Press the Open/Close button again to close the tray. The player will automatically begin loading the disc.
5. Use the remote control to navigate the disc menu and start playback.

Streaming Services

The BDP-S1100 provides access to over 100 streaming services, including Netflix, YouTube, HuluPlus, Pandora, and Amazon Instant Video. A broadband internet connection of at least 2.5 Mbps (10 Mbps for HD content) is recommended.

1. Ensure the player is connected to your home network.
2. From the player's home menu, navigate to the "Sony Entertainment Network" or "Apps" section.
3. Select your desired streaming application. You may need to log in with your existing account credentials.

USB Media Playback

You can play photos, videos, and music stored on a USB storage device.

1. Insert your USB storage device into the USB port on the front of the player.
2. The player should detect the device and prompt you to select the media type (photos, music, or video).
3. Navigate through your files using the remote control and select the content you wish to play.
4. *Note:* Not all USB devices or file formats are supported. Refer to the full owner's manual for compatibility details.

Gracenote Feature

Gracenote provides detailed information about movies by searching across internet apps and external services. An internet connection is required for this feature.

Social Media Integration

The player allows you to share what you are watching on Facebook and Twitter directly from its user interface. An internet connection and existing social media accounts are required.

Maintenance

Cleaning the Unit

- Wipe the exterior of the player with a soft, dry cloth.
- Do not use abrasive pads, scouring powder, or solvents such as alcohol or benzene.
- The fully-encased optical drive is designed to minimize dust accumulation, reducing the need for internal cleaning.

Firmware Updates

Sony may release firmware updates to improve performance or add new features. Ensure your player is connected to the internet to receive these updates.

1. Navigate to the "Setup" or "System Settings" menu on your player.
2. Select "Software Update" or "Firmware Update".
3. Follow the on-screen instructions to check for and install any available updates. Do not power off the unit during an update.

Troubleshooting

If you encounter issues with your Blu-ray Disc player, refer to the following common problems and solutions:

- **No Power:**
  - Ensure the AC power cord is securely connected to both the player and a working wall outlet.
  - Try plugging another device into the same outlet to confirm it has power.
- **No Picture on TV:**
  - Verify the HDMI cable is securely connected to both the player and the TV.
  - Ensure your TV is set to the correct HDMI input source.
  - Try a different HDMI cable or HDMI port on your TV.
- **No Sound:**
  - Check the audio connections (HDMI or Coaxial) to your TV or audio receiver.
  - Ensure your TV or audio receiver's volume is not muted or set too low.
  - Verify the correct audio input is selected on your audio receiver.

- **Cannot Access Internet/Streaming Services:**
  - Confirm the Ethernet cable is properly connected to the player and your router.
  - Check your router and internet connection for proper operation.
  - In the player's network settings, try manually configuring the DNS servers to **Primary DNS: 8.8.8.8** and **Secondary DNS: 8.8.4.4**.
  - Restart your router, modem, and the Blu-ray player.
- **Disc Playback Errors or Unit Freezes:**
  - Ensure the disc is clean and free of scratches.
  - Try a different disc to determine if the issue is with the player or the disc.
  - If the unit freezes, hold the power button on the device until it turns off, then press it again to restart.
  - Check for and install any available firmware updates.

Specifications

Feature	Detail
Brand	Sony
Model Name	BDP-S1100
Media Type	Blu-Ray Disc, DVD
Resolution	1920x1080 (Full HD 1080p)
Connectivity Technology	HDMI, USB, Ethernet
Connector Type	HDMI
Audio Output Mode	Surround
Supported Audio Formats	Dolby TrueHD, dts-HD
Surround Sound Channel Configuration	7.1
Item Weight	2.4 Pounds
Power Consumption	Energy Star 2.0 rated
UPC	027242858312

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Sony support website. Keep your proof of purchase for warranty claims.
If you require technical assistance or have questions not covered in this manual, please contact Sony Customer Support:

- **Online Support:** Visit sony.com/electronics/support
- **Telephone Support:** Refer to your regional Sony website for local contact numbers.

Official Product Videos

No official product videos from the seller are available for embedding at this time.