Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ONN 4330960893

ONN Universal Remote Instruction Manual

Model: 4330960893

Introduction

This manual provides comprehensive instructions for setting up, operating, and maintaining your ONN Universal Remote. This remote is designed to control up to four different audio/video devices, simplifying your home entertainment experience.

Key Features

- Works with most TVs and home theater components.
- Easy setup with pre-programmed codes.
- Controls up to 4 devices with one remote.
- Retains programmed codes when changing batteries.

Setup

1. Battery Installation

Open the battery compartment on the back of the remote. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment. Close the battery cover securely.

2. Programming Your Devices

The ONN Universal Remote can be programmed using pre-programmed codes or an auto-code search function.
Method A: Direct Code Entry (Recommended)

1. Turn on the device you wish to program (e.g., TV, DVD player).
2. Locate the code list provided with your remote (if available) or search for codes online for your specific device brand.
3. Press and hold the **SETUP** button until the red indicator light on the remote turns on and stays lit.
4. Press and release the device button you want to program (e.g.,**TV**, **DVD**, **CBL**). The indicator light will blink once and then remain lit.
5. Enter the 3-digit code for your device brand using the number buttons. After entering the last digit, the indicator light should turn off.
6. Test the remote by pressing the **POWER** button. If the device turns off, the code is correct. If not, repeat the

process with another code from the list or proceed to Method B.

Method B: Auto Code Search

1. Turn on the device you wish to program.
2. Press and hold the **SETUP** button until the red indicator light turns on and stays lit.
3. Press and release the device button you want to program (e.g.,**TV**, **DVD**). The indicator light will blink once and then remain lit.
4. Point the remote at the device and repeatedly press the**POWER** button (or **PLAY** for DVD/VCR) slowly, allowing time for the device to respond. The remote is sending different codes with each press.
5. Once the device turns off (or begins playing), immediately press the same device button (e.g.,**TV**, **DVD**) to lock in the code. The indicator light will turn off.
6. Test the remote's functions (Volume, Channel, Playback). If some functions do not work, repeat the auto-search process to find a more compatible code.



Image: Front view of the ONN Universal Remote. The remote is black with white and red buttons. Key buttons visible include TV, CBL, SAT, AUX, VCR, DVD, MENU, EXIT, INPUT, SETUP, SHIFT, number pad (0-9), directional pad with OK/MUTE, and media playback controls (REWIND, PLAY, STOP, FF, RECORD, PAUSE).

Operating Your Remote

Once programmed, operating your ONN Universal Remote is straightforward:

- **Device Selection:** Press the desired device button (e.g.,**TV**, **DVD**, **CBL**) to switch control to that device. The indicator light will flash once to confirm.
- **Power:** Press the **POWER** button to turn the selected device on or off.
- **Volume Control:** Use the **VOL+** and **VOL-** buttons to adjust the volume. The **MUTE** button silences the audio.
- **Channel Control:** Use the **CH+** and **CH-** buttons to change channels.
- **Number Pad:** Use the number buttons (0-9) to directly enter channel numbers or other numerical inputs.
- **Input:** Press the **INPUT** button to cycle through video inputs on your TV.
- **Menu/Navigation:** Use the **MENU** button and the directional arrows (Up, Down, Left, Right) with the **OK** button to navigate device menus.
- **Playback Controls:** For DVD/VCR devices, use **PLAY**, **STOP**, **REWIND**, **FAST FORWARD (FF)**, **PAUSE**, and **RECORD** buttons.

Maintenance

Battery Replacement

When the remote's performance degrades or the indicator light does not illuminate, it's time to replace the batteries. As noted in the features, your programmed codes will be retained even after battery removal, thanks to the remote's internal memory.

Cleaning

To clean the remote, wipe it with a soft, slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:** Ensure fresh batteries are installed correctly. Check for any obstructions between the remote and the device's infrared sensor. Make sure you have selected the correct device button (e.g., TV for your television).
- **Device not programming:** Double-check the code you are entering. If using direct code entry, try other codes listed for your brand. If using auto-code search, ensure you are pointing the remote directly at the device and pressing the power button slowly enough for the device to respond.
- **Some functions not working:** Not all functions of your original remote may be supported by the universal remote, especially for older or very specific device models. Try another code for your device, as some codes may offer better functionality than others.
- **Indicator light not turning on:** This usually indicates dead or incorrectly installed batteries. Replace them.

Specifications

Product Dimensions	7.5 x 4 x 2 inches
Item Weight	1.6 ounces
Manufacturer	ONN
Model Number	4330960893

Max Number of Supported Devices	4
Connectivity Technology	Infrared
Compatible Devices	Home Theater Components

Warranty and Support

For warranty information or further technical assistance, please refer to the product packaging or visit the official ONN support website. Keep your purchase receipt as proof of purchase for any warranty claims.
For additional support, you may also find helpful resources and updated code lists on the ONN product support page online.

© 2023 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00AXO37EY

More documents and user manuals: **https://manuals.plus/**