Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi EC220CD

De'Longhi EC220CD 15-Bar Pump Driven Espresso Maker

Model: EC220CD | Brand: De'Longhi

Introduction

The De'Longhi EC220CD 15-Bar Pump Driven Espresso Maker is designed for home use, allowing you to prepare espresso, cappuccinos, and lattes. It features a 15-bar pump system for optimal extraction and a swivel jet frother for milk preparation. Key components include a built-in tamper and removable water tank and drip tray for convenience.



Figure 1: De'Longhi EC220CD 15-Bar Pump Driven Espresso Maker.

Features:

- Stainless steel Boiler with 15 bars of pressure.
- Swivel jet Frother for cappuccinos, lattes, or any other frothy milk beverage with ease.

- 35 ounce removable water tank for easy filling.
- Built-in coffee tamper.
- Self-priming operation requires no start-up preparation.

Setup

Before first use, ensure all packaging materials are removed. Place the espresso maker on a stable, flat surface near a power outlet.

1. Filling the Water Tank:

The water tank is located at the back of the unit. Carefully lift the lid and remove the tank. Fill it with fresh, cold water up to the MAX line. Ensure the tank is fully inserted back into the machine to prevent leaks.


DeLonghi
OK

Figure 2: Removing the removable water tank for filling.

2. Initial Priming:

After filling the water tank and plugging in the machine, turn the control knob to the "ON" position. Wait for the green "OK" light to illuminate, indicating the machine has reached the correct temperature. Then, turn the knob to the coffee brewing position to allow water to flow through the system and prime the pump. This may take approximately 30-40 seconds for the first use.

Operating Instructions

1. Making Espresso:

1. Ensure the machine is primed and the green "OK" light is on.
2. Insert the desired filter into the portafilter. For best results, use espresso grind coffee.
3. Fill the filter with ground coffee. Use the built-in tamper to gently pack the grounds. Avoid over-tamping, as this can restrict water flow.
4. Attach the portafilter to the machine by aligning it and turning it clockwise until it is securely locked.
5. Place your espresso cup(s) on the drip tray beneath the portafilter spouts.
6. Turn the control knob to the coffee brewing position. Espresso will begin to flow into your cup(s).
7. Once the desired amount of espresso is brewed (typically 1-2 ounces per shot), turn the control knob back to the "OFF" position.


DeLonghi
EASY SERVING ESPRESSO
E.S.E.

Figure 3: Espresso being brewed into cups.

2. Frothing Milk (for Cappuccinos/Lattes):

1. Ensure the machine is heated and the green "OK" light is on.
2. Turn the control knob to the steam icon. The red light will illuminate, indicating the machine is heating for steam production.
3. Once the red light turns off and the green "OK" light is steady, the machine is ready for steaming.
4. Submerge the tip of the swivel jet frother into a pitcher of cold milk.
5. Slowly turn the steam knob counter-clockwise to release steam. Move the pitcher up and down to create foam.
6. Once desired foam consistency is achieved, turn the steam knob clockwise to close it, then turn the main control knob back to "OFF".

Maintenance

1. Cleaning the Steam Wand:

Regular cleaning of the steam wand is crucial for optimal performance and hygiene. It is recommended to clean the steam wand every 200 coffees or approximately every 3 months.

Your browser does not support the video tag.

Video 1: Official De'Longhi guide on cleaning the steam wand. This video demonstrates how to remove and clean the nozzle, including using a needle to clear openings, and reattaching it.

1. Remove the nozzle from the steam wand.
2. Clean the nozzle thoroughly with a warm, damp cloth.
3. Rinse the nozzle under warm running water.
4. Use a needle to clear any blockages in the small openings of the nozzle.
5. Dry the nozzle and re-insert it back onto the steam wand.

2. Cleaning the Drip Tray:

The drip tray collects excess water and coffee. It should be emptied and cleaned regularly to prevent overflow and maintain hygiene. The red indicator will pop up when the tray needs to be emptied.

3. Descaling:

Regular descaling is essential to remove mineral buildup and ensure the longevity and performance of your espresso maker. Refer to the full user guide for detailed descaling instructions and recommended descaling solutions.

4. Cleaning the Portafilter and Gasket:

After each use, remove the portafilter and discard the used coffee grounds. Rinse the filter and portafilter under warm water. Periodically, clean the gasket area where the portafilter attaches to prevent coffee grounds from accumulating and affecting the seal.

Troubleshooting (FAQ)

Q: Water does not pump fast enough to make an espresso.
A: The pump is a 15 Bar pressure. Please do not tamp the coffee too hard.

Q: Burns the coffee.
A: Please calibrate the machine before use.

Q: After a couple of cups of coffee the pressure became 0.
A: The pressure has to be built up before each coffee is made to get the right temperature.

Q: I'm not happy with the steam process of this machine. It boils rather than steaming and foaming the milk.
A: Please clean the steam wand, especially the small hole that lets air in and creates the foam.

Q: Water drips from the underside of the tank.
A: The tank must be fully inserted; otherwise, some water can pass through the seal.

Q: Coffee basket sticks and is difficult to turn.
A: When the unit is new, the turning is stronger, but with usage, it gets loosened up.

Specifications

Feature	Detail
Brand	De'Longhi
Model Name	EC220CD
Coffee Maker Type	Espresso Machine
Special Feature	Removable Tank
Filter Type	Reusable
Operation Mode	Fully Automatic
Pressure	15 Bar Pump
Water Tank Capacity	35 ounces
Product Dimensions	13.4 x 11.4 x 15.3 inches
Item Weight	8.8 pounds
Manufacturer	DeLonghi America, Inc.
Date First Available	January 18, 2013

Support & Resources

For comprehensive information, including detailed setup, operation, and maintenance guides, please refer to the official

user manual.

Download Official User Guide (PDF)

Manufacturer: DeLonghi America, Inc.

For additional support, visit the official De'Longhi website or contact their customer service.

Warranty Information

Specific warranty details for the De'Longhi EC220CD Espresso Maker are typically provided with the product packaging or within the official user manual. Please consult these resources or the manufacturer's official website for the most accurate and up-to-date warranty terms and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00B2D25TI

More documents and user manuals: **https://manuals.plus/**