Whirlpool Magicook 20C Knobs

Whirlpool 20 L Convection Microwave Oven Magicook 20C Knobs User Manual

Model: Magicook 20C Knobs

1. Introduction

This user manual provides essential information for the safe and efficient operation of your new Whirlpool 20 L Convection Microwave Oven, model Magicook 20C Knobs. Please read these instructions thoroughly before using the appliance and retain them for future reference.



Figure 1.1: Front view of the Whirlpool Magicook 20C Knobs Convection Microwave Oven. This image displays the appliance's exterior, including the control panel on the right and the door handle.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of burns, electric shock, fire, or injury to persons.

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the door, hinges, or seals.
- Only qualified service personnel should adjust or repair the oven.
- Ensure the appliance is properly grounded.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.

- Do not use corrosive chemicals or vapors in this appliance.
- Always use oven mitts when handling hot items from the oven.

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials from the oven cavity and accessories. Check the oven for any damage, such as dents or a misaligned door. Do not install if the oven is damaged.

3.2 Placement

- Place the oven on a flat, stable surface that can support its weight and the heaviest food item likely to be cooked in the oven.
- Ensure adequate ventilation. Maintain a minimum clearance of 10 cm (4 inches) on the rear, 5 cm (2 inches) on the sides, and 20 cm (8 inches) above the oven.
- Keep the oven away from heat sources and strong magnetic fields.

3.3 Turntable Assembly

The 270 mm turntable is designed to ensure even cooking.

1. Place the roller ring in the center of the oven cavity floor.
2. Place the glass turntable on top of the roller ring, ensuring it sits securely in the center support.



Figure 3.1: Interior view of the microwave oven with the door open, showing the turntable support and the oven cavity.

3.4 Electrical Connection

Plug the oven into a properly installed and grounded wall outlet. Do not use extension cords or adapters.

4. Operating Instructions

Your Whirlpool Magicook 20C Knobs microwave oven features easy-to-use controls for various cooking functions.



Figure 4.1: Detailed view of the control panel, showing the digital display, auto-cook menu options, function buttons (Micro, Combi, Grill, Defrost, Clock), and time/start controls.

4.1 Setting the Clock

To set the clock, press the **CLOCK** button. Use the time adjustment buttons (up/down arrows) to set the current time. Press **CLOCK** again to confirm.

4.2 Microwave Cooking

This function is used for standard microwave heating and cooking.

1. Place food in a microwave-safe container inside the oven.
2. Close the door securely.
3. Press the **MICRO** button.
4. Use the **TIME** adjustment buttons to set the desired cooking time.
5. Press the **START/+30SEC** button to begin cooking.

4.3 Convection Cooking

The convection mode allows you to bake and roast foods like a traditional oven.

1. Place food in an oven-safe container on the metal rack (if provided).
2. Close the door securely.
3. Press the **COMBI** button (or dedicated Convection button if present).
4. Set the desired temperature and cooking time using the control panel buttons.
5. Press the **START/+30SEC** button.

4.4 Grill Function

Use the concealed quartz grill for browning and crisping food.

1. Place food on the grill rack (if provided).
2. Close the door securely.
3. Press the **GRILL** button.
4. Set the desired grilling time.
5. Press the **START/+30SEC** button.

4.5 Defrost Function

The defrost function allows you to thaw frozen food quickly and efficiently.

1. Place frozen food in a microwave-safe container.
2. Close the door securely.
3. Press the **DEFROST** button.
4. Select the defrost setting (e.g., by weight or time) using the control panel buttons.
5. Press the **START/+30SEC** button.

4.6 Keep Warm Function

This feature keeps your cooked food warm at a low temperature without further cooking.

1. After cooking, select the Keep Warm function (refer to specific button or menu option if available).
2. Set the desired duration for keeping warm.
3. Press the **START/+30SEC** button.

4.7 Auto Cook Menu

The oven includes pre-programmed settings for various food items.

- **Categories:** Breakfast, Cakes, Desserts, Snacks, Tikkas, Continental, Curries (Veg), Curries (Non Veg), Sabzi, Beverages & Instants, Breads, Rice.
- **Serves:** Adjust quantity for 2, 3, or 4 servings.

1. Press the desired Auto Cook menu button (e.g., "Breakfast").
2. Select the number of servings if prompted.
3. Press the **START/+30SEC** button.

4.8 Power Levels

The oven offers multiple power levels for precise cooking control:

- 400 Watts
- 550 Watts
- 700 Watts (Maximum)

To adjust power levels, typically you would press the **MICRO** button multiple times or use a dedicated power level button after selecting the microwave function. Refer to the control panel for specific power level selection methods.

4.9 Child Lock

To activate the child lock, press and hold the **PAUSE/STOP** button for approximately 3 seconds until a lock indicator appears on the display. To deactivate, repeat the process.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

5.1 Exterior Cleaning

- Wipe the exterior surface with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- Clean the control panel with a soft, damp cloth. Do not allow water to drip into the ventilation openings.

5.2 Interior Cleaning

- Clean the oven cavity after each use. Wipe with a damp cloth and mild detergent.
- For stubborn food residue, place a bowl of water with lemon slices inside and microwave for 5-10 minutes. The steam will loosen the residue, making it easier to wipe away.
- Clean the turntable and roller ring with warm, soapy water. They are generally dishwasher safe.

5.3 Door and Seal Cleaning

Regularly clean the door, door seals, and adjacent parts with a damp cloth to remove any spills or splatters. This helps maintain the oven's efficiency and safety.



Figure 5.1: The oven cavity with a cooking bowl, illustrating typical usage and areas requiring cleaning. Note the "CAUTION: HOT TEMPERATURE" sticker inside the door frame.

6. Troubleshooting

Before contacting customer service, refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Oven does not start.	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close the door firmly; Check household fuse or reset circuit breaker.
Food not heating.	Cooking time or power level set incorrectly; Door not closed properly.	Adjust cooking time and power level; Ensure door is fully closed.

Problem	Possible Cause	Solution
Light not working.	Bulb is loose or burned out.	Contact qualified service personnel for bulb replacement.
Turntable not rotating.	Turntable or roller ring not positioned correctly; Food too large or heavy.	Reposition turntable and roller ring; Ensure food does not obstruct rotation.

Caution: If the oven displays an error code or unusual behavior persists, discontinue use and contact customer support. Do not attempt to repair the appliance yourself.

7. Specifications

Brand: Whirlpool

Model: Magicook 20C Knobs

Type: Convection Microwave Oven

Capacity: 20 Litres

Wattage: 700 Watts

Oven Cooking Mode: Convection

Installation Type: Countertop

Inner Material: Stainless Steel

Color: White

Special Features: Touch Panel, Defrost System, Concealed Quartz Grill, 270mm Turntable

Item Weight: 15 kg 700 g

Door Orientation: Left

8. Warranty and Support

8.1 Warranty Information

Your Whirlpool Magicook 20C Knobs Convection Microwave Oven comes with a **2-year warranty on the magnetron** from the date of purchase. For detailed terms and conditions, please refer to your purchase documentation or contact Whirlpool customer service.

8.2 Customer Support

For technical assistance, service requests, or inquiries regarding your product, please contact Whirlpool customer support. Refer to the contact information provided in your product packaging or visit the official Whirlpool website for your region.

© 2023 Whirlpool. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question