Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung DV150F

Samsung DV150F Smart WiFi Digital Camera User Manual

Model: DV150F

1. Overview

The Samsung DV150F is a compact digital camera designed for ease of use and versatile photography. It features a 16.2-megapixel CCD sensor, a 5x optical zoom lens, and dual LCD screens (2.7-inch main and 1.48-inch front) for convenient self-portraits and group shots. Integrated Wi-Fi capabilities allow for seamless sharing of photos and videos.



Figure 1: Front view of the Samsung DV150F Smart WiFi Digital Camera.

2. What's in the Box

Verify that all components are present in the packaging:

- Samsung DV150F Digital Camera
- Rechargeable Battery
- Wrist Strap
- Warranty Card
- USB Cable
- AC Adapter

3. Setup

3.1. Installing the Battery

1. Open the battery compartment cover located on the bottom of the camera.
2. Insert the rechargeable battery into the compartment, ensuring the contacts align correctly.
3. Close the battery compartment cover until it clicks securely into place.

Note: Charge the battery fully before first use. Connect the camera to a power source using the provided USB cable and AC adapter.

3.2. Inserting a Memory Card

The DV150F uses microSD, microSDHC, or microSDXC memory cards (up to 64 GB recommended). A memory card is required to save photos and videos.

1. Open the memory card slot cover, usually located near the battery compartment.
2. Insert the microSD card with the metal contacts facing the front of the camera until it clicks into place.
3. Close the memory card slot cover.

Caution: Do not force the memory card. Incorrect insertion can damage the card or camera.

4. Operating the Camera

4.1. Power On/Off

Press the **Power** button located on the top of the camera to turn it on or off. The lens will extend when powered on.

4.2. Taking Photos

1. Turn on the camera.
2. Frame your shot using the main 2.7-inch LCD screen.
3. Press the **Shutter** button halfway down to focus. The focus frame will turn green when focus is achieved.
4. Press the **Shutter** button fully down to capture the image.

4.3. Using the Dual View LCD

The DV150F features a 1.48-inch front LCD screen, ideal for self-portraits or group photos where you want to be in the frame.

1. With the camera powered on, press the **FLCD** button (Front LCD) on the side of the camera.
2. The front LCD will activate, displaying a live preview.
3. Frame your shot using the front LCD and press the **Shutter** button to capture.



Figure 2: The Samsung DV150F's dual view feature allows for easy self-portraits and group shots.



Figure 3: Side view of the Samsung DV150F, highlighting the front LCD and control buttons.

4.4. Recording Videos

The camera supports 720p HD video recording.

1. Switch the camera to video recording mode (refer to your camera's mode dial or menu for this option).
2. Press the **Record** button (often a dedicated button or the Shutter button in video mode) to start recording.
3. Press the **Record** button again to stop recording.

4.5. Smart Wi-Fi Features

The DV150F integrates Wi-Fi for enhanced connectivity and sharing. Access these features via the camera's menu system.

- **Social Media Upload:** Directly upload photos to social networking sites.
- **E-mail:** Send photos via email directly from the camera.
- **Mobile Link:** Connect to a smartphone or tablet to transfer images.
- **PC Auto-backup:** Automatically back up photos to a computer over Wi-Fi.
- **Remote Viewfinder:** Control the camera and view the live image from a smartphone app.
- **Cloud Service:** Upload photos to cloud storage services.

5. Maintenance

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for camera lenses. Avoid touching the lens with fingers.
- **Cleaning the Body:** Wipe the camera body with a soft, dry cloth. Do not use harsh chemicals or solvents.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Remove the battery if storing for extended periods.

- **Battery Care:** Avoid fully discharging the battery frequently. Recharge regularly to maintain battery life.

6. Troubleshooting

Problem	Possible Cause / Solution
Camera does not power on.	Battery is discharged. Charge the battery. Battery is inserted incorrectly. Reinsert the battery with correct orientation.
Cannot take photos.	Memory card is full. Delete unnecessary files or insert a new card. Memory card is not inserted. Insert a memory card. Battery is low. Charge the battery.
Images are blurry.	Camera shake. Hold the camera steady or use a tripod. Subject is too close. Ensure subject is within the camera's focus range. Lens is dirty. Clean the lens.
Wi-Fi connection fails.	Camera is too far from the Wi-Fi access point or mobile device. Move closer. Incorrect Wi-Fi password. Re-enter the correct password. Wi-Fi feature is not enabled on the camera or connected device. Enable it.
Front LCD not working.	Ensure the FLCD button has been pressed. Check camera settings for front LCD activation.

7. Specifications

Feature	Detail
Model Name	Samsung DV150F
Photo Sensor Resolution	16.2 MP
Optical Zoom	5x
Digital Zoom	4x
Main Screen Size	2.7 Inches (LCD)
Front Screen Size	1.48 Inches (LCD)
Video Resolution	HD 720p
Connectivity	Wi-Fi, NFC
Memory Card Type	microSD, microSDHC, microSDXC (up to 64 GB)
Sensor Type	CCD
Minimum Shutter Speed	1 Second
Maximum Shutter Speed	1/2000 Seconds
Item Weight	0.26 Pounds
UPC	887276012537

Feature	Detail
Model Number	EC-DV150FBPWUS

8. Warranty and Support

The Samsung DV150F Digital Camera comes with a **1-year parts & labor warranty** from the date of purchase. For warranty claims, technical assistance, or further support, please contact Samsung customer service or visit the official Samsung support website.
Keep your proof of purchase for warranty validation.

© 2023 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00BBJO4Q0

More documents and user manuals: **https://manuals.plus/**