Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE-0090-05-2

CalExotics Shane's World Hookup Remote Control Vibrating Egg User Manual

Model: SE-0090-05-2

Introduction

Thank you for choosing the CalExotics Shane's World Hookup Remote Control Vibrating Egg. This manual provides detailed instructions for the safe and effective use, maintenance, and troubleshooting of your device. Please read this manual thoroughly before first use and retain it for future reference.

Setup

1. Battery Installation

The CalExotics Shane's World Hookup Remote Control Vibrating Egg requires two (2) N-type 1.5V batteries for the remote control and two (2) N-type 1.5V batteries for the vibrating egg. Batteries are typically included with the product.

1. **For the Remote Control:** Locate the battery compartment on the back of the remote. Use a small screwdriver or coin to open the compartment cover. Insert two N-type batteries, ensuring correct polarity (+/-). Replace the cover securely.
2. **For the Vibrating Egg:** Twist the base of the vibrating egg counter-clockwise to open the battery compartment. Insert two N-type batteries, ensuring correct polarity (+/-). Twist the base clockwise to close and seal the compartment securely.





Figure 1: Battery compartments for the remote control and vibrating egg. Note the battery type (2N 1.5V) and polarity markings.

2. Initial Cleaning

Before first use, clean the vibrating egg thoroughly with warm water and a mild, toy-safe cleanser. Rinse completely and allow to air dry. Do not submerge the remote control in water.

Operating Instructions

The Shane's World Hookup features a remote control for convenient operation of the vibrating egg. The remote has a range of approximately 7 meters (23 feet).



Figure 2: CalExotics Shane's World Hookup Remote Control and Vibrating Egg.

Remote Control Functions:

- **Power Button:** Press and hold the main button on the remote to turn the vibrating egg ON or OFF.
- **Mode Button:** Short press the main button to cycle through various vibration patterns.
- **LED Indicator:** A small LED light on the remote control indicates when the remote is transmitting a signal.



Figure 3: Close-up of the remote control.

Using the Vibrating Egg:

1. Ensure the vibrating egg is clean and dry before use.
2. Apply a generous amount of water-based lubricant to the vibrating egg for comfortable use.
3. Position the vibrating egg as desired.
4. Use the remote control to turn the device on and select your preferred vibration pattern.



Figure 4: Close-up of the vibrating egg.

Maintenance

Cleaning:

- After each use, clean the vibrating egg with warm water and a mild, toy-safe cleanser.

- Rinse thoroughly to remove all soap residue.
- Allow the vibrating egg to air dry completely before storage.
- Do not use cleansers containing alcohol, petroleum, or acetone, as these can damage the material.
- The remote control is not waterproof; clean it with a damp cloth only.

Storage:

Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Remove batteries if the device will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh N-type batteries.
Vibrations are weak or inconsistent.	Low battery power.	Replace batteries in both the remote and the egg.
Remote control not responding.	Out of range, dead remote batteries, or interference.	Move closer to the vibrating egg. Replace remote batteries. Ensure no obstructions.

Specifications

- **Model Name:** CalExotics Shane's World Hookup Remote Control Vibrating Egg
- **Model Number:** SE-0090-05-2
- **Brand:** CalExotics
- **Color:** Pink
- **Material:** ABS Plastic, Polyurethane Coating
- **Product Dimensions:** Approximately 2 x 4.75 x 8.5 inches (packaging dimensions, actual product is smaller)
- **Item Weight:** Approximately 1.76 ounces (product only)
- **Batteries Required:** 2 x N-type 1.5V (for remote), 2 x N-type 1.5V (for egg) - included
- **Remote Range:** Up to 7 meters (23 feet)
- **Waterproof:** Vibrating egg is waterproof; remote control is not.

Warranty and Support

For warranty information or technical support, please contact CalExotics directly. Refer to the product packaging or the official CalExotics website for current contact details. Keep your proof of purchase for warranty claims.
Website: www.calexotics.com

Important Safety Information

This product is intended for adult use only. Must be over 18 to purchase and use.
Consult a healthcare professional before use if you have any medical conditions or concerns. Discontinue use if irritation or discomfort occurs.

© 2023 CalExotics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00BD0WSF6

More documents and user manuals: **https://manuals.plus/**