Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 2000016960

Coleman Self-Inflating Sleeping Pad with Pillow (Model 2000016960) - User Manual

Your guide to comfortable and convenient outdoor sleeping.

Introduction

The Coleman Self-Inflating Sleeping Pad with Pillow is designed to provide compact nighttime comfort and support for your outdoor adventures. Featuring a durable, weather-resistant polyester shell and a tufted design, this pad offers an additional layer of comfort between your sleeping bag and the ground. Its self-inflating mechanism simplifies setup, allowing you to quickly prepare for a restful night.

Product Features

- **No Air Pump Required:** The pad automatically inflates upon opening the valve.
- **Integrated Pillow:** Includes a pillow to keep your head elevated for restful sleep.
- **Quick Deflation:** Features compression straps that assist in forcing air out when packing up.
- **Enhanced Comfort:** Offers extra padding for an additional layer of comfort.
- **Durable Construction:** Made with a durable, weather-resistant polyester shell.

Setup (Inflation)

1. **Unroll the Pad:** Lay the sleeping pad flat on a clean, level surface.
2. **Open the Valve:** Locate the free-flow valve on the pad and open it. The pad will begin to self-inflate as air enters the foam core.

3. **Pillow Inflation:** The integrated pillow requires manual inflation. Locate the separate valve on the pillow and blow air into it until desired firmness is achieved. Close the pillow valve securely.
4. **Adjust Firmness (Optional):** For a firmer sleeping surface, you may manually blow additional air into the main pad's valve before closing it securely.



Image: The Coleman Self-Inflating Sleeping Pad unrolled and beginning to inflate.

Your browser does not support the video tag.

Video: Demonstration of the Coleman Self-Inflating Camping Pad with Pillow setup process.

Your browser does not support the video tag.

Video: Instructions on setting up the sleeping pad.

Operating (Usage)

Once fully inflated and adjusted to your preferred firmness, the sleeping pad is ready for use. Place it inside your tent or on a cot. The tufted design and extra padding provide a comfortable and supportive surface for sleeping, helping to insulate you from the ground.



Image: A person resting comfortably on the inflated sleeping pad inside a tent.



Image: Side view illustrating the thickness and support of the sleeping pad with a person on it.



Image: Close-up of the integrated pillow providing head elevation.

Maintenance

Cleaning

To clean the sleeping pad, simply wipe the surface with a damp cloth and mild soap. Allow it to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.

Storage (Deflation)

1. **Open the Valve:** Open the main free-flow valve on the pad.
2. **Deflate Pillow:** Open the pillow valve to release air.
3. **Roll Up:** Starting from the end opposite the valve, begin to roll the pad tightly. As you roll, apply pressure to force the air out through the open valve.
4. **Use Compression Straps:** Utilize the integrated compression straps to secure the rolled pad and squeeze out any remaining air.
5. **Close Valve:** Once fully rolled and compressed, close the valve securely to prevent air from re-entering.
6. **Store:** Place the rolled pad in its storage bag. Store in a cool, dry place.



Image: The sleeping pad rolled up and secured with its compression straps for compact storage.

Your browser does not support the video tag.

Video: Instructions on how to properly store sleeping mats, including rolling and securing.

Troubleshooting

- **Pad Not Fully Inflating:** Ensure the valve is completely open and allow sufficient time for the foam to expand. For initial use or after long storage, the foam may need more time to regain its full expansion. Manually blowing air into the valve can help achieve desired firmness.
- **Pillow Not Inflating:** Confirm the pillow's separate valve is open and manually blow air into it. Ensure the valve is securely closed after inflation.
- **Difficulty Deflating:** Ensure both the main pad valve and pillow valve are open. Roll the pad tightly from the opposite end of the valve, applying consistent pressure to expel air. The compression straps are designed to assist in this process.
- **Puncture/Leak:** If a small puncture occurs, a repair kit (not included with this specific model but often available separately) can be used. Follow the repair kit instructions carefully.

Specifications

Feature	Detail
Brand	Coleman
Model Name	Self-Inflating Sleeping Pad with Pillow
Item Model Number	2000016960
Product Dimensions	76"L x 25"W x 2.5"Th
Item Weight	7 pounds
Material	Blend (Polyester Shell)
Item Firmness Description	Plush
Special Feature	Inflatable
Included Components	Pillow

Warranty and Support

This Coleman Self-Inflating Sleeping Pad with Pillow comes with a**1-year limited warranty**. For warranty claims, product support, or any questions regarding your sleeping pad, please contact Coleman customer service directly. Refer to the product packaging or Coleman's official website for the most up-to-date contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00BF9IYO4

More documents and user manuals: **https://manuals.plus/**