Morphy Richards AT-201

Morphy Richards AT-201 2-Slice 650-Watt Pop-Up Toaster User Manual

Model: AT-201

Important Safety Instructions

Please read these instructions carefully before using your Morphy Richards AT-201 Pop-Up Toaster. Keep this manual for future reference.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when the toaster is plugged in.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.

Product Overview

The Morphy Richards AT-201 is a 2-slice pop-up toaster designed for efficient toasting. Familiarize yourself with its components:



Image: Front view of the Morphy Richards AT-201 Pop-Up Toaster, showcasing its compact design and two toasting slots.



Image: Diagram highlighting key features: Crumb Tray, Anti-slip Feet, 650W Powerful Motor, Variable Browning Setting, and High-lift Feature.

1. **Toasting Slots:** Two wide slots for various bread types.
2. **Browning Control Dial:** Adjusts toast shade from light to dark (settings 1-7).
3. **Cancel Button:** Stops the toasting cycle at any time.
4. **Toasting Lever:** Lowers bread into the toaster and initiates the toasting cycle.
5. **Crumb Tray:** Removable tray at the bottom for easy cleaning of crumbs.
6. **Hi-Lift Feature:** Allows for easy removal of smaller bread slices.
7. **Anti-slip Feet:** Ensures stability during operation.

Setup

Before first use, ensure the toaster is placed on a stable, heat-resistant surface away from flammable materials.



Image: The Morphy Richards AT-201 Toaster with its power cord, ready for connection to an electrical outlet.

- Unpack the toaster and remove all packaging materials.
- Wipe the exterior with a damp cloth.
- Ensure the crumb tray is correctly inserted.
- Plug the power cord into a standard AC 220-240V, 50Hz electrical outlet.
- For the first use, operate the toaster without bread on the highest setting to burn off any manufacturing residues. A slight odor or smoke is normal during this process. Ensure good ventilation.

Operating Instructions

Follow these steps to toast bread with your appliance:



Image: Two slices of bread inserted into the toasting slots of the Morphy Richards AT-201 Toaster.

1. **Insert Bread:** Place one or two slices of bread into the toasting slots.
2. **Select Browning Level:** Turn the browning control dial to your desired setting (1 for lightest, 7 for darkest). Start with a medium setting (e.g., 3 or 4) and adjust as needed for future use.



Image: Close-up view of the browning control dial with settings 1-7 and the cancel button on the toaster's side panel.

3. **Start Toasting:** Press the toasting lever down until it locks into place. The toasting cycle will begin. The lever will not latch if the toaster is not plugged in.
4. **Cancel Function:** To stop the toasting cycle at any time, press the 'Cancel' button. The bread will pop up.
5. **Remove Toast:** Once the toasting cycle is complete, the toast will automatically pop up. Use the hi-lift feature by pushing the lever further up to safely retrieve smaller items.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.



Image: The Morphy Richards AT-201 Toaster showing the removable crumb tray, essential for cleaning.

- **Always unplug the toaster** and allow it to cool completely before cleaning.
- **Crumb Tray:** Pull out the crumb tray from the bottom of the toaster. Dispose of crumbs and wipe the tray clean with a damp cloth. Dry thoroughly before reinserting.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Interior:** Never insert utensils or fingers into the toasting slots. Do not attempt to clean the interior heating elements.
- **Storage:** When not in use, store the toaster in a clean, dry place. The cord can be wrapped around the base for tidy storage.

Troubleshooting

If you encounter issues with your toaster, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outlet not working; toasting lever not fully depressed.	Ensure the toaster is securely plugged into a working outlet. Press the toasting lever down until it locks.
Bread is not toasting evenly.	Uneven bread thickness; crumb buildup.	Ensure bread slices are of uniform thickness. Clean the crumb tray regularly.
Smoke coming from toaster.	Food lodged in slots; excessive crumbs; first use residue.	Unplug immediately. Allow to cool. Carefully remove any lodged food (do not use metal). Clean crumb tray. (First use smoke is normal, ensure ventilation).
Toast is too light/dark.	Browning control setting incorrect.	Adjust the browning control dial to a higher setting for darker toast or a lower setting for lighter toast.

If the problem persists, contact customer support.

Specifications

Technical details for the Morphy Richards AT-201 Pop-Up Toaster:



Image: The Morphy Richards AT-201 Toaster with approximate dimensions shown.

- **Model:** AT-201
- **Type:** 2-Slice Pop-Up Toaster
- **Power Input:** AC 220 - 240 V, 50 Hz
- **Wattage:** 650 Watts
- **Material:** Plastic
- **Browning Settings:** 7 levels
- **Special Features:** Cancel Function, Variable Browning Control, Hi-lift feature, Crumb Tray, Anti-slip feet.
- **Item Weight:** Approximately 1110 Grams
- **Included Components:** 1 Toaster

Warranty and Support

Your Morphy Richards AT-201 Pop-Up Toaster comes with a manufacturer's warranty.



Image: The Morphy Richards AT-201 Toaster displayed with an overlay indicating a '2-year warranty'.

- **Warranty Period:** 2 years on product.
- For warranty claims or technical support, please refer to the contact information provided with your purchase documentation or visit the official Morphy Richards India website.
- Keep your purchase receipt as proof of purchase for warranty services.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question