Tefal TT7461002

T-fal Avanté Deluxe 4-Slice Toaster User Manual

Model: TT7461002
Brand: Tefal

1. Introduction

Thank you for choosing the T-fal Avanté Deluxe 4-Slice Toaster. This appliance is designed for efficient and convenient toasting of various bread types, including bagels and waffles. Its unique angled design allows for easy viewing and safe removal of toasted items. Please read this manual thoroughly before first use to ensure proper operation and safety.

Key Features:

- Angled design for effortless viewing and safe toast removal.
- High-speed toasting, 40% faster than conventional toasters.
- Bagel toasting technology for perfectly toasted bagels.
- Self-adjusting slots accommodate various bread thicknesses.
- Reheat setting to warm already toasted bread without burning.
- High lift lever for easy removal of small items.
- Safe-to-touch exterior during operation.
- Stop button to cancel toasting at any time.
- Electronic browning control with six settings.
- Anti-jam feature for safety.
- Two removable crumb trays for easy cleaning.
- Convenient cord storage.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. To disconnect, press the STOP button, then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
14. A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
15. Do not attempt to dislodge food when toaster is plugged in.
16. Do not operate unattended.
17. Bread may burn. Therefore, toasters must not be used near or below curtains and other combustible materials. They must be attended when in use.
18. Ensure the toaster is placed on a flat, stable, heat-resistant surface.

3. Product Overview



This image displays the T-fal Avanté Deluxe 4-Slice Toaster. It features a sleek, angled design with a silver-colored top and black sides. There are four wide toasting slots visible at the top. On the front panel, two control levers are present, along with two browning

control dials, and buttons for reheat and bagel functions. The T-fal logo is prominently displayed in the center.

Familiarize yourself with the components of your T-fal Avanté Deluxe Toaster:

- **Toasting Slots:** Four wide slots for various bread types.
- **Control Levers:** Used to lower and raise bread into the toasting slots.
- **Browning Control Dials:** Adjust browning level from 1 (lightest) to 6 (darkest).
- **Reheat Button:** Illuminates when active, warms already toasted bread.
- **Bagel Button:** Illuminates when active, toasts the cut side of bagels.
- **Stop Button:** Immediately cancels the toasting cycle.
- **Crumb Trays:** Two removable trays located at the bottom for easy cleaning.

4. Setup

1. **Unpacking:** Carefully remove the toaster and all packaging materials. Retain packaging for future storage or transport if needed.
2. **Placement:** Place the toaster on a stable, flat, and heat-resistant surface, away from any flammable materials such as curtains or walls. Ensure there is adequate ventilation around the toaster.
3. **First Use:** Before toasting food for the first time, operate the toaster without bread on the highest browning setting (6) for a few minutes. This will burn off any manufacturing residues and eliminate odors. A slight odor or smoke may be present during this initial operation; this is normal and will dissipate.
4. **Cord Management:** Unwind the power cord and plug it into a standard electrical outlet. The toaster features convenient cord storage to keep excess cord neatly tucked away.

5. Operating Instructions

Basic Toasting

1. Plug the toaster into a suitable electrical outlet.
2. Insert up to four slices of bread into the toasting slots. The self-adjusting slots will center the bread for even toasting.
3. Select your desired browning level using the browning control dial. Setting 1 is for light toast, and setting 6 is for dark toast.
4. Press the control lever down until it locks into place. The toasting cycle will begin.
5. Once the toasting cycle is complete, the toast will automatically pop up.

Using the Bagel Function

The bagel function toasts the cut side of the bagel while gently warming the outside.

1. Insert bagel halves into the toasting slots with the cut side facing inwards.
2. Select your desired browning level.
3. Press the 'Bagel' button. The indicator light on the button will illuminate.

4. Press the control lever down until it locks. The toasting cycle will begin.
5. The bagel will automatically pop up when done.

Using the Reheat Function

The reheat function warms already toasted bread without further browning.

1. Insert the already toasted bread into the slots.
2. Press the 'Reheat' button. The indicator light on the button will illuminate.
3. Press the control lever down until it locks. The reheating cycle will begin.
4. The bread will automatically pop up when reheated.

Using the Stop Button

To cancel the toasting cycle at any time, simply press the 'Stop' button. The control lever will immediately pop up, and the toasting will cease.

High Lift Lever

The high lift lever allows you to raise the toasted items higher out of the slots, making it easier and safer to retrieve smaller items like English muffins or waffles without burning your fingers.

Anti-Jam Feature

For your safety, the toaster is equipped with an anti-jam feature. If food becomes jammed in the toasting slots, the toaster will automatically shut off to prevent overheating and potential fire hazards. Unplug the toaster and allow it to cool before carefully removing the jammed food.

6. Maintenance and Cleaning

Regular cleaning of your toaster will ensure its longevity and optimal performance.

1. **Always Unplug:** Before cleaning, always unplug the toaster from the electrical outlet and allow it to cool completely.
2. **Crumb Trays:** The T-fal Avanté Deluxe Toaster has two removable crumb trays located at the bottom. Pull out the trays to remove accumulated crumbs. Discard crumbs and wipe the trays clean with a damp cloth. Dry thoroughly before reinserting them into the toaster. Ensure the trays are fully inserted before operating the toaster.
3. **Exterior Cleaning:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
4. **Never Immerse:** Never immerse the toaster, cord, or plug in water or any other liquid.
5. **Storage:** When not in use, ensure the toaster is clean and dry. You can use the convenient cord storage feature to wrap the power cord neatly. Store the toaster in a dry place.

7. Troubleshooting

If you encounter issues with your toaster, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outlet not working; circuit breaker tripped.	Ensure the toaster is securely plugged into a working outlet. Check your household circuit breaker.
Bread is stuck in the slots.	Food item is too large or has expanded.	Unplug the toaster and allow it to cool. Gently remove the food item using non-metallic tongs. Do not use metal utensils.
Toast is too light or too dark.	Browning setting is incorrect; type of bread.	Adjust the browning control dial to a higher or lower setting. Different types of bread (e.g., fresh vs. frozen) may require different settings.
Smoke coming from toaster.	Crumbs accumulated in the bottom; food stuck and burning.	Immediately press the STOP button and unplug the toaster. Allow to cool. Clean the crumb trays. If food is stuck, carefully remove it.
Lever does not stay down.	Toaster is not plugged in; anti-jam feature activated.	Ensure the toaster is plugged into a live electrical outlet. If food is jammed, unplug and clear the obstruction.

If the problem persists after trying these solutions, please contact Tefal customer support.

8. Specifications

- **Brand:** Tefal
- **Model:** TT7461002
- **Color:** Black
- **Number of Slices:** 4
- **Wattage:** 1500 watts
- **Browning Settings:** 6
- **Specific Uses:** Bagel, Bread, Waffle
- **Special Features:** Angled design, High-speed toasting, Bagel function, Reheat function, High lift lever, Safe-to-touch exterior, Stop button, Anti-jam feature, Removable crumb trays, Cord storage.
- **Manufacturer:** T-fal

9. Warranty and Support

This T-fal product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the duration of the warranty and what it covers.
For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Tefal Customer Support. Contact information can typically be found on the official Tefal website or on the product packaging.

Keep your purchase receipt as proof of purchase for warranty purposes.

© 2025 Tefal. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is the lever not staying down on my T-fal Avanté Deluxe 4-Slice Toaster (Model TT7461002), and where can I find a circuit diagram?

If the control lever on your T-fal Avanté Deluxe 4-Slice Toaster is not staying down, please check the following based on the manufacturer's troubleshooting guide:Power Connection: The lever is held down by an electromagnet....

Read full answer