De'Longhi CTOV2103.BG

De'Longhi Icona Vintage Toaster

Model: CTOV2103.BG

Instruction Manual

Introduction

Thank you for choosing the De'Longhi Icona Vintage Toaster, model CTOV2103.BG. This appliance is designed to provide reliable and efficient toasting for your daily needs. Please read this instruction manual carefully before using the appliance to ensure safe and optimal operation. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.
- Do not operate unattended.
- This appliance is for 220-240 Volts / 50/60 Hz operation only.

Product Overview

Familiarize yourself with the components of your De'Longhi Icona Vintage Toaster.



This image shows the De'Longhi Icona Vintage Toaster CTOV2103BG, featuring its elegant beige finish, chrome accents, and the removable bun warming rack placed on top.



A detailed view of the toaster's control panel, highlighting the toast colour dial, the main lever, and the illuminated buttons for Bagel, Defrost, Reheat, and Cancel functions.

Main Components:

1. **Toasting Slots:** Two slots for bread slices.
2. **Toast Colour Dial:** Adjusts the browning level from light to dark.
3. **Lever:** Lowers bread into the toasting slots and initiates the toasting cycle. Also functions as a high-lift lever.
4. **Bagel Button:** Toasts the cut side of bagels while gently warming the other side.
5. **Defrost Button:** Defrosts and toasts frozen bread.
6. **Reheat Button:** Warms up previously toasted bread without further browning.
7. **Cancel Button:** Stops the toasting cycle at any time.
8. **Removable Crumb Tray:** Collects crumbs for easy cleaning.
9. **Bun Warming Rack:** Accessory for warming buns, croissants, etc.

Setup

- Unpack the toaster and all accessories carefully. Remove any packaging materials, stickers, or protective films.
- Place the toaster on a stable, flat, heat-resistant surface, away from flammable materials such as curtains or walls. Ensure adequate ventilation around the appliance.
- Ensure the crumb tray is correctly inserted into its position at the bottom of the toaster.
- Before first use, operate the toaster without bread for a few cycles at the highest browning setting to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal and will dissipate. Ensure the area is well-ventilated during this process.
- Plug the power cord into a suitable 220-240V / 50/60Hz electrical outlet.

Operating Instructions

Basic Toasting:

1. Insert up to two slices of bread into the toasting slots.
2. Select your desired browning level using the **Toast Colour Dial**. Settings range from 1 (lightest) to 6 (darkest). Start with a medium setting (e.g., 3 or 4) and adjust as needed for future use.
3. Press the **Lever** down until it locks into place. The toasting cycle will begin, and the lever will remain down.
4. When the desired browning is achieved, the toast will automatically pop up, and the lever will release.
5. To stop the toasting cycle at any time, press the **Cancel Button**.



This image demonstrates the operation of the toaster, showing a hand lowering the lever to begin the toasting cycle, with two slices of bread visible in the slots.

Special Functions:

- **Defrost Function:** For frozen bread. Insert frozen bread, select browning level, press the lever down, then press the **Defrost Button**. The indicator light will illuminate. The toaster will automatically adjust the toasting time to defrost and toast the bread.
- **Reheat Function:** To warm up cold toast. Insert previously toasted bread, press the lever down, then press the **Reheat Button**. The indicator light will illuminate. This function warms the bread without further browning.
- **Bagel Function:** For bagels or thick-cut bread. Insert the bagel with the cut side facing inwards. Select browning level, press the lever down, then press the **Bagel Button**. The indicator light will illuminate. This function toasts the cut side and warms the outer side.

Using the Bun Warming Rack:

- Place the bun warming rack securely over the toasting slots.
- Place buns, croissants, or pastries on the rack.
- Set the toast colour dial to a low setting (e.g., 1 or 2).
- Press the lever down. The heating elements will activate to gently warm the items on the rack.
- Monitor the warming process closely to prevent burning. Press the **Cancel Button** when desired warmth is achieved.
- **Note:** Do not place bread directly into the slots when the bun warming rack is in use.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

- **Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.**
- **Crumb Tray:** The removable crumb tray should be emptied regularly to prevent crumb buildup, which can be a fire hazard.



The image displays the toaster's removable crumb tray, partially pulled out from the bottom, illustrating its easy-to-clean design for collecting crumbs.

  - Pull out the crumb tray from the bottom of the toaster.

    - Discard crumbs.
    - Wipe the tray with a damp cloth and dry thoroughly before reinserting. Do not wash the tray in a dishwasher.
- **Exterior:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
- **Interior:** Do not insert any objects into the toasting slots to clean them. If food becomes lodged in the slots, unplug the toaster and carefully turn it upside down to dislodge the food.
- Do not immerse the toaster in water or any other liquid.

Troubleshooting

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; lever not fully depressed.	Ensure the toaster is securely plugged into a working outlet. Check your household circuit breaker. Push the lever down firmly until it locks.
Bread is too dark/light.	Browning level setting is incorrect.	Adjust the Toast Colour Dial to a lower setting for lighter toast or a higher setting for darker toast.
Smoke coming from toaster.	Food lodged in slots; crumb tray full; first use residue.	Immediately press the Cancel button and unplug. Allow to cool. Remove any lodged food. Empty the crumb tray. If it's the first use, ensure good ventilation.
Lever does not stay down.	Toaster is not plugged in; internal mechanism issue.	Ensure the toaster is plugged into a live electrical outlet. If the issue persists, contact customer support.

If you encounter problems not listed here, or if the issue persists, please contact De'Longhi customer support.

Specifications

Feature	Detail
Model Number	CTOV2103.BG
Product Type	Toaster
Color	Beige
Slices / Slots	2
Power Consumption	900 W
Voltage	220 - 240 V / 50/60 Hz

Feature	Detail
Dimensions (W x D x H)	18.5 cm x 32 cm x 20.5 cm (approx. 7.28 x 12.6 x 8.07 inches)
Weight	2 kg (approx. 4.41 pounds)
Control Type	Electronic
Features	Adjustable browning control, removable crumb tray, defrost, warming rack, reheat, anti-skid rubber feet, cancel button, high lift facility, one-side toasting button, safety microswitch.

Warranty and Support

De'Longhi products are manufactured to the highest quality standards. For information regarding warranty coverage, service, or technical support, please refer to the warranty card included with your product or visit the official De'Longhi website.

Official Website: www.delonghi.com

Please have your model number (CTOV2103.BG) and serial number (if applicable) ready when contacting support.

© 2024 De'Longhi. All rights reserved.
This manual is subject to change without notice.