Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RM-Series TOSHIBA DVR17

RM Series Replacement Remote Control User Manual

Model: TOSHIBA DVR17 Replacement

1. Introduction

This manual provides comprehensive instructions for the RM Series Replacement Remote Control, designed to operate all functions of your original TOSHIBA DVR17 remote control. This remote is a dedicated replacement and requires no programming or setup; simply insert batteries, and it is ready for immediate use.

The RM Series remote controls are assembled and tested in the UK, utilizing the latest chip-set technology to ensure precise infra-red code matching with the original device. All buttons are correctly labeled to reflect their exact function, eliminating the need for constant reference to external instructions.

2. Setup

2.1. Battery Installation

The RM Series remote control operates on standard Alkaline batteries. Follow these steps to install or replace batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert the required batteries (typically AAA or AA, refer to the compartment for specific type and polarity) ensuring the positive (+) and negative (-) ends align with the markings inside the compartment.
4. Gently slide the battery compartment cover back into place until it clicks securely.





Figure 2.1: Back view of the remote control with the battery compartment open, illustrating correct battery insertion.

Once batteries are correctly installed, the remote is ready for use. No pairing or programming is required.

3. Operation

The RM Series remote control is designed to replicate the full functionality of your original TOSHIBA DVR17 remote. All buttons are clearly labeled to match their corresponding functions on your device.





Figure 3.1: Front view of the RM Series remote control, displaying the button layout.

3.1. Basic Functions

- **Power Button:** Located at the top left, press to turn your device on or off.
- **Input Select:** Use to cycle through available input sources.
- **Numeric Keypad (0-9):** For direct channel selection or inputting numbers.
- **Volume Up/Down (VOL +/-):** Adjusts the audio volume.
- **Channel Up/Down (P +/-):** Changes the channel.
- **Navigation Buttons (Up, Down, Left, Right, OK/Enter):** Used for menu navigation and selection.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Standard controls for media playback.
- **Menu/Disc/Top Buttons:** Access various menus and disc functions.

3.2. Key Features

- **Full Functionality:** Operates all functions of the original remote control supplied with your TOSHIBA DVR17 device.
- **Dedicated Replacement:** This is not a generic "universal" remote; it is specifically designed for the TOSHIBA DVR17.
- **No Programming Required:** Works immediately out of the box upon battery insertion.
- **LED Indicator:** Features a red LED indicator for signal transmission confirmation.
- **Correctly Labeled Buttons:** All buttons are accurately labeled, matching the original remote's functions.

4. Maintenance

4.1. Cleaning

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaning agents, as these can damage the remote's finish or internal components.

4.2. Battery Replacement

Replace batteries when the remote's performance degrades (e.g., reduced range, inconsistent response) or if the LED indicator does not light up. Always replace all batteries at the same time with new ones of the same type. Refer to Section 2.1 for battery installation instructions.

Remove batteries if the remote will not be used for an extended period to prevent leakage and potential damage.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote does not work or is unresponsive.	• Batteries are dead or inserted incorrectly. • Infrared (IR) sensor on the device is obstructed. • Remote is too far from the device or not aimed correctly.	• Replace batteries, ensuring correct polarity (+/-). • Ensure a clear line of sight between the remote and the device's IR sensor. • Move closer to the device and aim the remote directly at it.
Buttons are sticky or unresponsive.	• Dirt or debris under the buttons.	• Clean the remote's surface and around the buttons as described in Section 4.1.
Remote works intermittently.	• Low battery power. • Interference from other electronic devices or strong light sources.	• Replace batteries. • Ensure no strong light sources (e.g., direct sunlight) are hitting the device's IR sensor.

6. Specifications

Model Number	TOSHIBA DVR17 Replacement
Brand	RM-Series
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Metres
Product Dimensions (L x W x H)	22.71 x 5 x 2.39 cm
Item Weight	86 g
Battery Type	Alkaline (not included)

7. Warranty and Support

RM Series products are manufactured to high standards and undergo vigorous testing to ensure long-term reliability. All RM Series products are CE and ROHS compliant.

For any issues, questions, or support inquiries regarding your RM Series Replacement Remote Control, please contact the retailer or manufacturer directly. Please have your product model number (TOSHIBA DVR17 Replacement) and purchase details ready when contacting support.

© 2023 RM Series. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00BUOVGQM

More documents and user manuals: **https://manuals.plus/**