DEWALT DWE576K-QS

DEWALT DWE576K-QS Circular Saw Instruction Manual

Model: DWE576K-QS

1. Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your DEWALT DWE576K-QS Circular Saw. Please read these instructions thoroughly before using the tool to ensure proper handling and to prevent injury or damage.

2. General Safety Instructions

WARNING: Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

2.1 Work Area Safety

- Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2.2 Electrical Safety

- Power tool plugs must match the outlet. Never modify the plug in any way.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges, and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

2.3 Personal Safety

- Always wear eye protection. Use appropriate personal protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection for appropriate conditions.
- Stay alert, watch what you are doing, and use common sense when operating a power tool.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source, picking up or carrying the tool.

2.4 Circular Saw Specific Safety Warnings

- **DANGER:** Keep hands away from cutting area and the blade. Keep your second hand on the auxiliary handle, or motor housing. If both hands are holding the saw, they cannot be cut by the blade.
- Do not reach underneath the workpiece. The guard cannot protect you from the blade below the workpiece.
- Adjust the cutting depth to the thickness of the workpiece. Less than a full tooth of the blade should be visible below the workpiece.
- Never hold the workpiece in your hands or across your leg while cutting. Secure the workpiece to a stable platform.
- Always use blades of the correct size and shape (diamond as opposed to round) for the saw.
- Never use damaged or incorrect blade washers or bolt.

3. Components and Features

Familiarize yourself with the parts of your DEWALT DWE576K-QS Circular Saw before operation.

- **Main Handle:** For primary grip and control.
- **Auxiliary Handle:** Provides additional stability and control during operation.
- **Blade Guard:** Retracts during cutting to expose the blade, covers it when not in use.
- **Blade Clamp/Arbor Bolt:** Secures the saw blade.
- **Depth Adjustment Lever:** Allows setting the desired cutting depth.
- **Bevel Adjustment Lever:** For setting the cutting angle (0-57 degrees).
- **Base Plate/Shoe:** Supports the saw on the workpiece.
- **Dust Extraction Port:** Connects to a vacuum system for dust collection.
- **Spindle Lock Button:** Engages to hold the spindle for blade changes.
- **Power Cord:** Connects the tool to an AC power source.



Figure 3.1: Overview of the DEWALT DWE576K-QS Circular Saw. This image displays the complete circular saw, highlighting its main components such as the handle, blade guard, and base plate.

4. Setup and Adjustments

4.1 Blade Installation and Removal

1. **Disconnect Power:** Always unplug the saw from the power source before performing any adjustments or maintenance.
2. **Engage Spindle Lock:** Press and hold the spindle lock button to prevent the blade from rotating.
3. **Loosen Arbor Bolt:** Use the provided wrench to loosen and remove the arbor bolt and outer washer.
4. **Retract Lower Guard:** Manually retract the lower blade guard.
5. **Remove/Install Blade:** Carefully remove the old blade. When installing a new blade, ensure the teeth are pointing in the direction of rotation indicated by the arrow on the guard.
6. **Secure Blade:** Place the outer washer and arbor bolt back on, then tighten the arbor bolt firmly while holding the spindle lock.



Figure 4.1: Blade installation process. This image shows a hand securing the blade onto the circular saw, illustrating the ease of disc change.

4.2 Adjusting Cutting Depth

The cutting depth should be set so that the blade extends approximately 3-6 mm (1/8-1/4 inch) below the workpiece. This minimizes kickback and ensures a cleaner cut.

1. Loosen the depth adjustment lever.
2. Raise or lower the saw on its base plate until the desired depth is achieved.
3. Tighten the depth adjustment lever securely.

4.3 Adjusting Bevel Angle

The saw can make bevel cuts up to 57 degrees.

1. Loosen the bevel adjustment lever.
2. Tilt the saw base to the desired angle, using the angle scale as a guide.
3. Tighten the bevel adjustment lever firmly.



Figure 4.2: Bevel angle adjustment. This image illustrates a hand adjusting the bevel angle mechanism on the circular saw's base, showing the angle scale.

5. Operating Instructions

5.1 General Cutting Procedure

1. **Secure Workpiece:** Always clamp the workpiece firmly to a stable surface.
2. **Position Saw:** Place the front of the saw's base plate on the workpiece, ensuring the blade is clear of the material.
3. **Start Saw:** Depress the trigger switch to start the saw. Allow the blade to reach full speed before beginning the cut.
4. **Begin Cut:** Slowly and steadily push the saw forward through the workpiece. Maintain a firm grip with both hands.
5. **Complete Cut:** Continue pushing until the cut is complete. Release the trigger switch and allow the blade to stop completely before lifting the saw from the workpiece.



Figure 5.1: Circular saw in operation with a guide rail. This image shows a user operating the saw on a workpiece, utilizing a guide rail for precise cuts and demonstrating dust extraction.

5.2 Using with Guide Rails

The DEWALT DWE576K-QS is compatible with guide rails for enhanced precision and straight cuts. Ensure the saw's base is properly seated on the guide rail before starting the cut.



Figure 5.2: Circular saw performing a cut on wood. This image shows the saw actively cutting a wooden plank, with a dust extraction hose attached, emphasizing clean and efficient operation.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your circular saw.

- **Cleaning:** Keep the tool clean and free of dust and debris. Use a soft brush or compressed air to clean ventilation openings.
- **Blade Inspection:** Regularly inspect the saw blade for sharpness, cracks, or missing teeth. Replace dull or damaged blades immediately.
- **Cord Inspection:** Check the power cord for damage. Do not use the tool if the cord is frayed or cut.
- **Lubrication:** This tool is factory lubricated and does not require additional lubrication.
- **Storage:** Store the saw in a dry, secure location out of reach of children.

7. Troubleshooting

Problem	Possible Cause	Solution
Saw does not start	No power supply; faulty switch; damaged cord.	Check power connection; inspect cord; contact service center if switch is faulty.
Blade binds or smokes	Dull blade; incorrect blade for material; improper cutting depth; workpiece not secured.	Replace blade; use correct blade; adjust depth; secure workpiece firmly.
Inaccurate cuts	Blade not square to base; loose bevel adjustment; worn blade.	Check and adjust blade squareness; tighten bevel lock; replace blade.

8. Technical Specifications

Feature	Specification
Model	DWE576K-QS
Power Input	1600 W
No-Load Speed	5200 RPM
Blade Diameter	190 mm
Blade Bore	Not specified, typically 30mm for 190mm blades
Max. Cutting Depth (90°)	61 mm
Max. Cutting Depth (45°)	43 mm
Bevel Capacity	57°
Voltage	230 Volts (AC)
Item Weight	1.61 pounds (approx. 730 grams)
Product Dimensions	8.66"L x 5.75"W x 15.75"H
Included Components	Circular Saw, Carrying Case, Parallel Guide

9. Warranty and Support

For warranty information, service, or technical support, please refer to the warranty card included with your product or visit the official DEWALT website. Keep your purchase receipt as proof of purchase for warranty claims.

DEWALT Official Website: www.dewalt.com

© 2025 DEWALT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question