Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia A00011072

Nokia 301 User Manual

Model: A00011072

1. Introduction

Welcome to the user manual for your Nokia 301 mobile phone. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. Please read this manual carefully to ensure optimal performance and longevity of your phone.

2. Setup

2.1. Inserting the SIM Card

1. Turn off the phone and remove the back cover.
2. Locate the SIM card slot.
3. Insert the SIM card with the gold contacts facing down and the cut corner aligned with the slot.
4. Ensure the SIM card is securely in place.

2.2. Inserting the Battery

1. Align the battery contacts with the contacts in the battery compartment.
2. Gently press the battery into place until it clicks.
3. Replace the back cover.

2.3. Charging the Battery

1. Connect the charger to a power outlet.
2. Plug the charger connector into the phone's charging port.
3. The battery indicator on the screen will show the charging status.
4. Once fully charged, disconnect the charger.

2.4. Powering On/Off

- To power on, press and hold the power key until the phone vibrates.
- To power off, press and hold the power key, then select 'Power off' from the options.

3. Operating Your Nokia 301

3.1. Basic Navigation

Use the keypad and the navigation key (center button) to move through menus and select options. The soft keys below the screen perform functions indicated on the display.

3.2. Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the call key (green button).
- **Receiving a Call:** Press the call key when the phone rings.
- **Ending a Call:** Press the end call key (red button).

3.3. Sending and Receiving Messages

- Navigate to the 'Messaging' menu.
- Select 'Create message' or 'New message'.
- Enter your message text.
- Add the recipient's number or select from contacts.
- Select 'Send'.

3.4. Using the Camera

The Nokia 301 features a 3.2 MP camera with smart camera capabilities. To access the camera, navigate to the 'Camera' application from the main menu.



Image: The Nokia 301 phone, showcasing its screen with various camera functions and settings. Options visible include 'My photos' for viewing images, 'Effects' for applying filters, 'Video c.' for video recording, 'White bal.' for white balance adjustment, 'Self-timer' for delayed shots, 'Sequence' for burst mode, 'Self port.' for self-portraits, 'Panorama' for panoramic shots, and 'Grid' for composition guides. The physical keypad is visible below the screen.

- **Taking a Photo:** Frame your shot and press the center navigation key to capture.
- **Video Recording:** Switch to video mode and press the center navigation key to start/stop recording.
- **Camera Features:** Explore options like White Balance, Self-timer, Sequence mode, Self-portrait, Panorama, and Grid for enhanced photography.

3.5. MicroSD Card Usage

The phone supports MicroSD cards for expanded storage. Insert a MicroSD card into the dedicated slot to store more photos, videos, and other files.

4. Maintenance

4.1. Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials.

4.2. Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture or damage the battery.
- For optimal battery life, avoid frequent full discharges.

4.3. Software Updates

Information regarding guaranteed software updates for this model is not available. Please check the Nokia support website for any potential updates.

5. Troubleshooting

5.1. Phone Not Powering On

- Ensure the battery is properly inserted and charged.
- Try connecting the charger to see if the charging indicator appears.

5.2. No Network Signal

- Check that the SIM card is correctly inserted.
- Ensure you are in an area with network coverage.
- Restart the phone.

5.3. Battery Drains Quickly

- Reduce screen brightness.
- Close unused applications.
- Limit background data usage.

5.4. Unable to Send/Receive Messages

- Verify your message center number in settings.
- Check your network signal.
- Ensure you have sufficient credit or plan allowance.

6. Specifications

Feature	Detail
Brand	Nokia
Model Name	Nokia 301

Item Model Number	A00011072
Color	Black
Product Type	Monobloc
Operating System	Asha
Screen Size	2.4 Inches
Screen Resolution	320 x 240
Connectivity	2G, UMTS, 3G Cellular
Cellular Technology	3G, 2G
Camera Resolution	3.2 MP
Internal Memory	20 MB
Special Features	Smart Camera
Battery Composition	Lithium
Battery Type	1 AAA (included)
CPU Speed	1.4 GHz
Wireless Carrier	Unlocked
Manufacturer	Nokia
No Longer Produced by Manufacturer	No

7. Warranty and Support

For information regarding product warranty, please refer to the documentation provided at the time of purchase or visit the official Nokia support website. Standard return policies typically allow for refunds or replacements within 30 days of purchase, subject to seller terms.
For technical support or further assistance, please contact Nokia customer service or visit their official support channels.

© 2024 Nokia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00C9GG7W8

More documents and user manuals: **https://manuals.plus/**