Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Transcend EOS 100D-KSD64GB

Transcend 64GB SDXC Memory Card User Manual

Model: EOS 100D-KSD64GB

For use with Canon EOS 100D Digital Camera and other compatible devices.

1. Introduction

This manual provides essential information for the proper use and care of your Transcend 64GB Secure Digital Class 10 Extreme Capacity (SDXC) Memory Card. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

Product Features:

- 64GB Secure Digital Class 10 Extreme Capacity (SDXC) Memory Card
- Optimized for rapid-fire photo and video capture
- Ideal for high-resolution digital cameras and HD camcorders
- Large storage capacities for HD video recording



Image 1.1: Front view of the Transcend 64GB SDXC Memory Card. The card is blue with a red and white label, displaying "Transcend", "SDXC", "64GB", and the Class 10 speed rating.

2. Setup

2.1 Inserting the Memory Card

1. Locate the memory card slot on your compatible device (e.g., digital camera, camcorder, card reader). Refer to your device's user manual for the exact location.
2. Ensure the memory card is oriented correctly. The gold contacts on the card should align with the contacts in the device's slot.
3. Gently push the memory card into the slot until it clicks into place. Do not force the card, as this may cause damage.

2.2 Initial Formatting (Recommended)

For optimal performance and compatibility, it is highly recommended to format the memory card using the device it will primarily be used with. Formatting erases all data on the card and prepares it for use with your specific device.

1. Insert the memory card into your device.
2. Turn on your device and navigate to the menu settings.
3. Locate the "Format" or "Erase" option for the memory card.

4. Confirm the formatting process. Be aware that all data on the card will be permanently deleted.

Note: If you have important data on the card, back it up before formatting.

3. Operating

3.1 Data Storage

Once formatted, the Transcend SDXC card is ready to store photos, videos, and other digital files from your compatible device. The Class 10 speed rating ensures fast data transfer rates for high-resolution content.

3.2 Data Transfer to Computer

To transfer data from the memory card to your computer:

1. Safely remove the memory card from your device.
2. Insert the memory card into a compatible SD card reader connected to your computer.
3. Your computer should recognize the card as a removable drive.
4. Access the card's contents and copy/move files to your computer's storage.

3.3 Write Protection Switch

The Transcend SDXC card features a small write-protection switch on its left side. Sliding this switch downwards (towards the "LOCK" position) will prevent new data from being written to the card and existing data from being erased or modified. Slide the switch upwards to unlock the card for normal operation.

4. Maintenance

4.1 Handling and Storage

- Avoid touching the gold contacts on the card.
- Store the card in its protective case when not in use to prevent dust, dirt, and static damage.
- Keep the card away from extreme temperatures, direct sunlight, moisture, and strong magnetic fields.
- Do not bend, drop, or apply excessive force to the card.

4.2 Cleaning

If necessary, gently wipe the gold contacts with a clean, dry, lint-free cloth. Do not use liquid cleaners or abrasive materials.

4.3 Data Backup

Regularly back up important data from your memory card to a computer or other storage device to prevent data loss.

5. Troubleshooting

5.1 Card Not Recognized

- Ensure the card is fully inserted into the device or card reader.
- Check the write-protection switch; if it's in the "LOCK" position, the device may not be able to read or write to it.
- Try the card in another compatible device or card reader to rule out a device issue.
- If the card was previously used in another device, try reformatting it (see Section 2.2).

5.2 Data Transfer Errors

- Ensure the card is not write-protected.
- Check if the card has sufficient free space.
- Try using a different USB port or card reader on your computer.
- Ensure your computer's operating system and drivers are up to date.

5.3 Slow Performance

- Ensure your device supports Class 10 or higher speed cards.
- The card may be fragmented; backing up data and reformatting the card can improve performance.

6. Specifications

Feature	Detail
Brand	Transcend
Model Number	EOS 100D-KSD64GB
Flash Memory Type	SDXC
Memory Storage Capacity	64 GB
Secure Digital Association Speed Class	Class 10
Hardware Interface	SDXC, microSDHC
Compatible Devices	Camera
Item Weight	2.4 ounces (0.15 Pounds)
UPC	023005965297
Date First Available	May 3, 2013

7. Warranty and Support

Transcend products are manufactured to the highest standards and undergo rigorous testing. For specific warranty information regarding your Transcend memory card, please refer to the warranty card included with your purchase or visit the official Transcend website.

For technical support, product registration, or frequently asked questions, please visit the Transcend support page:

https://www.transcend-info.com/support

You may also contact Transcend customer service directly through their website for further assistance.

© 2023 Transcend Information, Inc. All rights reserved.
Transcend and SDXC are registered trademarks.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00CMIREJS

More documents and user manuals: **https://manuals.plus/**