Euro-Pro EP133S

Euro-Pro X Big Shark EP133S Turbo Hand Vacuum User Manual

Model: EP133S
Brand: Euro-Pro

1. Introduction

Thank you for choosing the Euro-Pro X Big Shark EP133S Turbo Hand Vacuum. This compact and powerful 800-watt vacuum is designed for quick and efficient dry cleaning tasks around your home or office. Featuring a 17-ounce bagless dust cup, it offers convenient operation and easy maintenance. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance.

2. Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this vacuum cleaner.
- Always unplug the vacuum cleaner from the electrical outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces. This vacuum is designed for dry pick-up only.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to Euro-Pro Operating LLC for examination, repair, or adjustment.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

- Do not pick up hard or sharp objects such as glass, nails, screws, or coins that could damage the vacuum cleaner.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

3. Product Components

Your Euro-Pro X Big Shark EP133S Turbo Hand Vacuum includes the main vacuum unit and a brush attachment. Familiarize yourself with these components before operation.



Image 1: The image displays the packaging of the Euro-Pro X Big Shark EP133S Turbo Hand Vacuum. It highlights the compact design of the vacuum, its 800-watt motor, 17-ounce capacity, and bagless operation. The packaging also illustrates its powerful suction capability, demonstrating its ability to lift heavy objects.

Included Components:

- Main Vacuum Unit (Model EP133S)
- Brush Attachment

4. Setup Guide

Follow these steps to prepare your vacuum for first use:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport if needed.
2. **Inspect:** Check all parts for any signs of damage. Do not use if any part is damaged.
3. **Attach Accessories:** If desired for specific cleaning tasks, attach the included brush accessory to the nozzle of the vacuum. Ensure it clicks securely into place.

4. **Power Connection:** Plug the power cord into a standard electrical outlet. Ensure the outlet provides the correct voltage as specified on the vacuum's rating label.

5. Operating Instructions

The Euro-Pro X Big Shark EP133S is designed for ease of use. Follow these steps for effective cleaning:

1. **Power On:** Ensure the vacuum is plugged into a live electrical outlet. Locate the power button, which is a push-button type, typically found on the handle or main body of the unit. Press the power button to turn the vacuum on.
2. **Cleaning:** Guide the vacuum's nozzle over the area you wish to clean. For optimal performance on upholstery or delicate surfaces, use the brush attachment. The powerful 800-watt motor provides strong suction for various dry debris.
3. **Bagless Operation:** The vacuum features a 17-ounce capacity bagless dust cup. Monitor the dust cup and empty it when it reaches its maximum fill line to maintain suction power.
4. **Power Off:** When you have finished cleaning, press the power button again to turn the vacuum off.
5. **Unplug:** Always unplug the vacuum from the electrical outlet after use and before performing any maintenance or cleaning.

6. Cleaning and Maintenance

Regular maintenance is crucial for the longevity and optimal performance of your vacuum cleaner.

6.1 Emptying the Dust Cup

1. Ensure the vacuum is unplugged from the power outlet.
2. Locate the dust cup release button or latch and detach the dust cup from the main vacuum unit.
3. Hold the dust cup over a trash receptacle and open the bottom flap or lid to empty the collected debris.
4. Close the dust cup securely and reattach it to the vacuum unit, ensuring it locks into place.

6.2 Cleaning Filters

Your Euro-Pro X Big Shark EP133S likely contains washable filters. Refer to the specific instructions on the filter itself or the product packaging for detailed cleaning methods. Generally:

- Remove the filters from the dust cup assembly.
- Tap off loose dirt over a trash can.
- Rinse the filters under cold water until the water runs clear.
- Allow filters to air dry completely for at least 24 hours before reinserting them into the vacuum. Do not use the vacuum with wet filters.

6.3 Cleaning Attachments

- Periodically inspect the brush attachment for tangled hair, lint, or debris.
- Use scissors or your fingers to carefully remove any obstructions.
- Wipe attachments with a damp cloth if necessary and allow them to air dry.

7. Troubleshooting Guide

Before contacting customer support, try these simple troubleshooting steps:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in. No power to outlet.	Ensure power cord is securely plugged into a working electrical outlet. Check circuit breaker or try another outlet.

Problem	Possible Cause	Solution
Low suction.	Dust cup is full. Filters are dirty. Nozzle or hose is blocked.	Empty the dust cup. Clean or replace filters as per maintenance instructions. Check for and remove any obstructions in the nozzle, hose, or attachments.
Unusual noise.	Foreign object lodged in vacuum.	Turn off and unplug the vacuum. Carefully inspect the nozzle, brush, and dust cup area for any lodged objects and remove them.

8. Technical Specifications

Brand: Euro-Pro

Model: EP133S

ASIN: B00CNDAWIM

Power: 800 Watts

Capacity: 17 Ounces (Bagless)

Included Components: Brush

Noise Level: 69 dB

Controller Type: Push Button

UPC: 622356512596

9. Warranty Information

For specific warranty details regarding your Euro-Pro X Big Shark EP133S Turbo Hand Vacuum, please refer to the warranty card included with your product packaging or visit the official Euro-Pro website. It is recommended to retain your purchase receipt as proof of purchase for any warranty claims.

10. Customer Support

If you require further assistance, have questions about your product, or need to order replacement parts, please contact Euro-Pro customer support. Contact information can typically be found on the product packaging, the official Euro-Pro website, or by searching for 'Euro-Pro customer service' online.