KitchenAid KHM926CA

KitchenAid 9-Speed Digital Hand Mixer User Manual

Model: KHM926CA | Brand: KitchenAid

Overview

The KitchenAid 9-Speed Digital Hand Mixer is designed to make your mixing tasks easier and more efficient. With its powerful motor and versatile accessories, you can combine ingredients at various speeds, from gently stirring in chunky ingredients to whipping meringue to stiff peaks. Its compact and lightweight design, along with convenient storage solutions, makes it an essential tool for any kitchen.

Key Features

- **9 Speeds:** Offers precise control for a wide range of recipes, from slow stirring to high-speed whipping.
- **Soft Start Feature:** Gradually brings the beaters up to the selected speed, preventing ingredients from splattering.
- **Locking Swivel Cord:** The round cord can be locked into either the left or right side of the mixer, allowing for flexible approach angles and easy cleaning.
- **Soft Grip Handle:** Provides enhanced comfort during extended mixing sessions.
- **Easy Accessory Ejection:** Quickly remove any accessory with a single-handed press of a button.



Figure 1: KitchenAid 9-Speed Digital Hand Mixer in Candy Apple Red, shown with various accessories including Turbo Beater II, Pro Whisk, and Dough Hooks.

Setup

Unpacking

1. Carefully remove the hand mixer and all accessories from the packaging.
2. Remove any protective film or packing materials.
3. Wash all accessories (beaters, whisk, dough hooks, blending rod) in warm, soapy water or place them in the dishwasher before first use. Rinse thoroughly and dry.

Attaching Beaters

Ensure the hand mixer is unplugged and the speed control is set to '0' (OFF) before attaching or removing accessories.

- Insert the desired beaters or accessories into the openings on the bottom of the mixer. Push firmly until they click into place.
- For beaters, ensure the one with the collar (or larger shaft) is inserted into the larger opening.



Figure 2: Close-up view of the hand mixer with beaters properly inserted into the accessory ports.

Official Product Video: Setup and Features

Video 1: This official KitchenAid product video demonstrates the hand mixer's features, including how to attach and detach accessories, and highlights its ease of use.

Operating Instructions

Power and Speed Control

1. Plug the hand mixer into a standard electrical outlet.
2. Use the digital speed control buttons (up/down arrows) to select your desired speed from 1 to 9. The Soft Start Feature will gradually increase the speed to prevent splattering.
3. To turn off the mixer, slide the speed control switch to the '0' (OFF) position.



Figure 3: Top view of the hand mixer, highlighting the digital speed controls and the speed indicator.

Cord Management

The hand mixer features a unique swivel cord design for convenience.

- The cord can be locked into either the left or right side of the mixer's base. This allows you to position the cord away from your mixing bowl or dominant hand, providing greater flexibility and comfort during use.
- Simply push the cord into the desired slot until it clicks into place.

Mixing Guidelines

Speed Setting	Recommended Use
Speed 1	Slowly stir in chunky ingredients like nuts or chocolate chips.
Speed 2-5	Mix batters, gravies, and sauces. Gradually increase speed for desired consistency.
Speed 6	Mix bread batter, cream butter and sugar.
Speed 7-8	Whip egg whites, heavy cream, or mashed potatoes.
Speed 9	Whip meringue to stiff peaks, knead yeast dough.

Care and Maintenance

Cleaning

- Always unplug the hand mixer before cleaning.
- The mixer body can be wiped clean with a damp cloth. Do not immerse the mixer body in water or other liquids.
- All included accessories (Turbo Beater II, Pro Whisk, Dough Hooks, Blending Rod) are dishwasher safe for easy cleaning.

Storage

The hand mixer comes with a convenient storage bag to keep all your accessories organized.

- After cleaning and drying, place all accessories into the provided storage bag.
- Wrap the power cord neatly using the attached rubber strap for compact storage.
- Store the hand mixer and its accessories in a dry place.



Figure 4: The hand mixer with its power cord neatly wrapped, and accessories stored in the included KitchenAid branded bag.

Troubleshooting

Problem	Possible Cause / Solution
Mixer does not turn on.	Ensure the mixer is properly plugged into a working electrical outlet. Check that the speed control is not set to '0' (OFF).
Beaters are difficult to insert or remove.	Ensure the mixer is unplugged and the speed control is set to '0'. Press the eject button firmly while inserting/removing.
Ingredients splatter during mixing.	Start at a lower speed (Speed 1) and gradually increase. Ensure the bowl is not overfilled. The Soft Start Feature helps minimize splattering.
Mixer seems to struggle with thick mixtures.	Ensure you are using the appropriate speed setting for the mixture. For very thick doughs, consider using the dough hooks and a higher speed. Avoid overloading the mixer.

Product Specifications

Attribute	Detail
Brand	KitchenAid
Model Name	9-Speed Hand Mixer
Model Number	KHM926CA
Color	Candy Apple Red
Product Dimensions	7.5"D x 3.5"W x 6.4"H
Item Weight	2.3 Pounds
Blade Material	Stainless Steel
Controls Type	Push Button
Dishwasher Safe	Yes (Accessories)
Country of Origin	USA

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official KitchenAid website. Keep your purchase receipt for warranty claims.

An official user manual in PDF format is available for download:User Manual (PDF)

For additional support, product registration, or to explore other KitchenAid products, please visit the KitchenAid Store: KitchenAid Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question