Faber CRIS24SS

Faber Cristal Stainless Steel Slide Out Range Hood

Model: CRIS24SS

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Faber Cristal Stainless Steel Slide Out Range Hood. Please read these instructions thoroughly before installation and use, and retain them for future reference.



This image shows the Faber Cristal Stainless Steel Slide Out Range Hood, fully extended and installed beneath a wooden kitchen cabinet. The hood features a sleek stainless steel finish and integrated halogen lights.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the electrical installation complies with all local codes and ordinances.
- Do not operate the hood if the power cord or plug is damaged.
- Disconnect power before servicing or cleaning.
- This appliance is intended for domestic use only.
- Do not flambé under the range hood.
- Clean grease filters regularly to prevent grease accumulation.

Setup and Installation

The Faber Cristal Range Hood is designed for an **Outside Mount** installation. Professional installation is highly recommended to ensure proper function and safety.

Pre-Installation Checklist:

- Verify all components are present and undamaged.
- Ensure adequate clearance above the cooking surface as per local building codes.
- Confirm the electrical supply matches the hood's requirements.

Installation Steps (Summary):

1. Carefully unpack the range hood and inspect for any shipping damage.
2. Mount the hood securely to the cabinet or wall structure, ensuring it is level.
3. Connect the ductwork to the exhaust outlet of the hood and vent to the outside.
4. Connect the electrical wiring according to the wiring diagram provided in the full installation guide (not included in this summary).
5. Install the mesh filters.

For detailed installation instructions, please refer to the comprehensive installation guide provided with your product packaging.

Operating Instructions

Your Faber Cristal Range Hood features intuitive **Push Button** controls for ease of use.

Fan Operation:

- **Power Button:** Press to turn the fan on or off.
- **Speed Buttons:** Select desired fan speed (low, medium, high) to adjust the **300 CFM** extraction power. Higher speeds are recommended for heavy cooking or strong odors.
- The hood operates with a noise level of approximately **60 dB** at maximum speed.

Lighting:

- The hood is equipped with **Halogen** lights.
- **Light Button:** Press to turn the lights on or off, illuminating your cooking surface.

Maintenance

Regular maintenance ensures optimal performance and longevity of your range hood.

Cleaning the Hood Exterior:

- The hood is made of **Stainless Steel** with a **Brushed** finish.
- Clean the exterior surfaces with a soft cloth and a non-abrasive stainless steel cleaner.
- Avoid using abrasive pads or harsh chemicals that can scratch the finish.

Cleaning the Mesh Filters:

- The hood uses **Mesh** filters, which are **Dishwasher safe**.
- Remove the filters by sliding them out of their slots.
- Wash filters in a dishwasher or by hand using hot water and a degreasing detergent.

- Allow filters to dry completely before re-installing.
- Clean filters at least once a month, or more frequently depending on cooking habits.

Replacing Halogen Bulbs:

- Ensure the hood is disconnected from power before attempting to replace bulbs.
- Allow bulbs to cool completely if they have been recently used.
- Refer to your full product manual for specific instructions on accessing and replacing the halogen bulbs.

Troubleshooting

If you encounter issues with your range hood, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Check circuit breaker or fuse. Ensure hood is plugged in.
Lights do not work.	Bulb is burnt out.	Replace halogen bulb.
Poor suction.	Grease filters are clogged.	Clean or replace mesh filters.
Excessive noise.	Loose parts or improper installation.	Check for loose screws or components. Ensure proper ducting.

If the problem persists after attempting these solutions, please contact Faber customer support.

Specifications

Feature	Specification
Brand	Faber
Model	CRIS24SS
ASIN	B00CXNM8TI
Mounting Type	Outside Mount
Controls Type	Push Button
Light Source Type	Halogen
Filter Type	Mesh (Dishwasher Safe)
Airflow (CFM)	300 CFM
Noise Level	60 dB
Material	Stainless Steel
Finish Type	Brushed
Colour	Multicolour

Warranty Information

Faber products are manufactured to high-quality standards and are backed by a manufacturer's warranty. For specific warranty terms and conditions, including duration and coverage, please refer to the warranty card included with your product or visit the official Faber website. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, spare parts, or service inquiries, please contact Faber customer support. Contact details can typically be found on the Faber official website or in the product packaging.
Website: www.faber.com (Please check for your regional website)
Phone: Refer to your regional Faber support contact number.

© 2024 Faber. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question