Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi 9850081500

De'Longhi 9850081500 Washer Instruction Manual

Model: 9850081500

Introduction

This document provides essential instructions for the proper handling, installation, and maintenance of the De'Longhi 9850081500 Washer. This component is an authorized Original Equipment Manufacturer (OEM) replacement part designed for compatibility with various De'Longhi brand models. Please read this manual thoroughly before proceeding with any installation or use.

Product Overview

The De'Longhi 9850081500 Washer is a critical component for ensuring proper sealing and spacing within compatible De'Longhi appliances. It is manufactured to precise specifications to maintain the integrity and performance of your equipment.



Figure 1: De'Longhi 9850081500 Washer. This image displays the De'Longhi 9850081500 Washer, a flat, circular component made of copper-toned metal, designed for sealing or spacing in mechanical assemblies.

Setup and Preparation

1. **Safety First:** Before beginning any work, ensure the appliance is disconnected from its power source to prevent

electrical hazards. Allow any hot components to cool down.

2. **Identify the Location:** Locate the specific area within your De'Longhi appliance where the washer needs to be replaced or installed. Refer to your appliance's primary service manual for detailed diagrams.
3. **Gather Tools:** Prepare any necessary tools, such as wrenches, screwdrivers, or pliers, that may be required for accessing and securing the washer.
4. **Inspect the Area:** Clean the installation area thoroughly, removing any debris, old gasket material, or corrosion that could impede proper seating of the new washer.

Installation Instructions

Follow these steps carefully for the correct installation of the De'Longhi 9850081500 Washer:

1. **Remove Old Component (if applicable):** If replacing an existing washer, carefully remove the old component. Note its orientation and position for correct installation of the new part.
2. **Position the Washer:** Place the De'Longhi 9850081500 Washer into its designated position. Ensure it sits flat and is correctly aligned with the mating surfaces.
3. **Secure Components:** Reassemble any components that secure the washer in place, such as bolts, nuts, or other fasteners.
4. **Tighten Fasteners:** Tighten fasteners according to the torque specifications provided in your appliance's primary service manual. Avoid over-tightening, which can damage the washer or surrounding components, and under-tightening, which can lead to leaks or loose connections.
5. **Verify Installation:** Visually inspect the installed washer to ensure it is properly seated and that all connections are secure.

Note: This washer is a static component and does not require operational instructions beyond proper installation.

Maintenance

The De'Longhi 9850081500 Washer is designed for durability and typically requires minimal maintenance once installed correctly. However, periodic inspection is recommended:

- **Visual Inspection:** During routine appliance maintenance, visually inspect the washer for any signs of wear, deformation, cracking, or corrosion.
- **Leak Checks:** If the washer is part of a fluid or gas system, periodically check for any signs of leakage around the connection point.
- **Replacement:** If any damage or signs of failure are observed, replace the washer immediately with an authorized De'Longhi 9850081500 replacement part to ensure continued appliance performance and safety.

Troubleshooting

As a passive component, the washer itself does not typically "malfunction." Issues related to the washer usually stem from improper installation or material degradation over time. Refer to the following for common issues:

- **Leakage at Connection Point:**
  - **Cause:** Washer not seated correctly, damaged washer, or fasteners not tightened to specification.
  - **Solution:** Disconnect power, disassemble the connection, inspect the washer for damage. Replace if damaged. Reinstall, ensuring proper seating and correct torque on fasteners.
- **Loose Component:**

- **Cause:** Fasteners not tightened sufficiently during installation.
- **Solution:** Disconnect power, tighten fasteners to the recommended torque.

- **Component Deformation:**
  - **Cause:** Over-tightening during installation or prolonged exposure to excessive pressure/temperature.
  - **Solution:** Replace the deformed washer with a new De'Longhi 9850081500 Washer. Ensure correct torque is applied during reinstallation.

If problems persist, consult the service manual for your specific De'Longhi appliance or contact authorized service personnel.

Specifications

Attribute	Detail
Part Number	9850081500
Brand	De'Longhi
Item Model Number	9850081500
Item Weight	0.32 ounces (approx. 0.02 Pounds)
Product Dimensions	1 x 1 x 1 inches (approximate)
Type	Flat Washer
Compatibility	Various De'Longhi brand models
Included Components	Appliance replacement part (single washer)

Warranty and Support

As an OEM replacement part, the De'Longhi 9850081500 Washer is covered by the standard warranty terms applicable to genuine De'Longhi spare parts. For specific warranty details, please refer to the documentation provided with your original De'Longhi appliance or contact De'Longhi customer support directly.
For technical assistance, replacement part inquiries, or warranty claims, please visit the official De'Longhi website or contact their customer service department. Ensure you have your appliance model number and the washer part number (9850081500) ready when seeking support.

- **De'Longhi Official Website:** www.delonghi.com
- **De'Longhi Store on Amazon:** Visit Store

© 2023 De'Longhi. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00CZPNGS6

More documents and user manuals: **https://manuals.plus/**