Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kichler 9708BK

Kichler Mount Vernon 9708BK Outdoor Wall Light Instruction Manual

Model: 9708BK

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler Mount Vernon 9708BK Outdoor Wall Light. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Safety Information

WARNING: Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing. All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
CAUTION: This fixture is designed for outdoor use and is UL Listed for wet conditions, offering full outdoor protection from exposure to sun, rain, water spray, and snow. Ensure all connections are properly sealed to prevent water intrusion.

- Always turn off the power supply before installing, cleaning, or replacing the bulb.
- Consult a qualified electrician if you are unsure about the installation process.
- Wear safety glasses and gloves during installation.
- Do not exceed the maximum wattage specified for the bulb.

Package Contents

Verify that all components are present before beginning installation. If any part is missing or damaged, do not attempt to assemble or install the fixture.

- Mount Vernon Outdoor Wall Light Fixture (Model 9708BK)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

Note: One 150W max candelabra bulb (E26 base) is required but**not included**.

Setup and Installation

Follow these steps to properly install your Kichler Mount Vernon Outdoor Wall Light.

1. **Prepare for Installation:**
   Turn off the electrical power at the main fuse box or circuit breaker. Ensure the power is off before proceeding.
2. **Mounting Plate Installation:**
   Attach the mounting plate to the junction box using the provided screws. Ensure the plate is securely fastened and level.
3. **Electrical Connections:**
   Carefully connect the fixture's wires to the house wiring. Connect the black wire from the fixture to the black (hot) wire from the junction box. Connect the white wire from the fixture to the white (neutral) wire from the junction box. Connect the bare copper or green ground wire from the fixture to the green or bare copper ground wire from the junction box. Secure all connections with wire nuts and wrap with electrical tape for added protection.
4. **Secure the Fixture:**
   Align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the mounting surface and stable.
5. **Install the Bulb:**
   Insert one E26 base incandescent bulb, up to 150 watts maximum, into the socket. Do not overtighten.
6. **Restore Power:**
   Once installation is complete and all connections are secure, restore power at the circuit breaker or fuse box.



Image: Kichler Mount Vernon Outdoor Wall Light with key dimensions of 16.75 inches height and 7.5 inches width.





Image: Front view of the Kichler Mount Vernon Outdoor Wall Light, showcasing its black finish and clear seeded glass.

Operating Instructions

The Kichler Mount Vernon Outdoor Wall Light operates via your home's standard electrical switch. Once installed and power is restored, the light can be turned on and off using the wall switch connected to the fixture.

Bulb Replacement:

1. Turn off power to the fixture at the circuit breaker.
2. Allow the bulb to cool completely before touching.
3. Carefully unscrew the old bulb.
4. Screw in a new E26 base incandescent bulb, not exceeding 150 watts.
5. Restore power at the circuit breaker.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your outdoor wall light.

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Glass Care:** The clear seeded glass can be cleaned with a mild glass cleaner.
- **Inspection:** Periodically inspect the fixture for any signs of wear, loose connections, or damage. Address any issues promptly.

Troubleshooting

If your Kichler Mount Vernon Outdoor Wall Light is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check the circuit breaker or fuse. Ensure the wall switch is in the 'ON' position.
	Loose wire connections.	Turn off power at the breaker. Check all wire connections inside the junction box and fixture.
	Defective bulb.	Replace the bulb with a new one of the correct type and wattage.
Light flickers.	Loose bulb or wiring.	Turn off power. Tighten the bulb. Check wire connections.
	Incorrect bulb type or wattage.	Ensure the bulb meets the specifications (E26 base, max 150W).
Water inside the fixture.	Improper sealing during installation.	Turn off power. Disassemble and re-seal all connections and mounting points with appropriate outdoor sealant.

If you continue to experience issues, contact Kichler customer support or a qualified electrician.

Specifications

Feature	Detail
Model Number	9708BK
Brand	Kichler
Dimensions (Height x Width)	16.75 inches x 7.5 inches
Material	Brass
Finish	Black
Shade Material	Clear Seeded Glass
Light Source Type	Incandescent
Number of Light Sources	1
Bulb Base	E26 (Medium)
Maximum Wattage	150 Watts
Voltage	120 Volts
Indoor/Outdoor Usage	Outdoor
Water Resistance Level	Waterproof
Certification	UL Listed for Wet Conditions
Item Weight	3.5 Pounds
UPC	783927395199

Warranty and Support

This Kichler product comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official Kichler website.
For technical assistance, replacement parts, or further inquiries, please contact Kichler Customer Support:

- **Website:** www.kichler.com
- **Phone:** Refer to the Kichler website for regional contact numbers.

© 2023 Kichler Lighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00D7BU112

More documents and user manuals: **https://manuals.plus/**