GEORGE KOVACS P4338-647

GEORGE KOVACS P4338-647 LED Swing Arm Wall Lamp Instruction Manual

Model: P4338-647

Introduction

Thank you for purchasing the GEORGE KOVACS P4338-647 LED Swing Arm Wall Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image: The GEORGE KOVACS P4338-647 LED Swing Arm Wall Lamp in a bedroom setting, extended over a bedside table.

Safety Information

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Use supply wires rated for at least 90°C (194°F).
- This fixture is ETL certified for **Indoor Locations Only**. Do not install in wet or damp locations.
- Do not attempt to modify the fixture. Any modifications may void the warranty and create a safety hazard.
- Ensure all connections are secure and properly insulated.

Package Contents

Verify that all components are present before beginning installation:

- LED Swing Arm Wall Lamp (P4338-647)
- Integrated LED Module (pre-installed)
- Mounting Hardware (screws, wire nuts, mounting plate)

Setup (Installation)

Tools Required (Not Included): Phillips head screwdriver, wire strippers, electrical tape, safety glasses.



Image: Detail of the lamp's mounting base and swing arm.

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the electrical supply to the installation location. Turn off the power completely.
2. **Prepare Mounting Surface:** This fixture is designed to mount to an existing standard electrical junction box (not included). Ensure the junction box is securely installed and capable of supporting the fixture's weight (approximately 3.17 lbs).
3. **Attach Mounting Plate:** Secure the provided mounting plate to the junction box using the screws supplied with the junction box or the fixture. Ensure the plate is oriented correctly for the fixture.
4. **Make Electrical Connections:** Carefully connect the fixture's wires to the corresponding house wires:
    - Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box.
    - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box.
    - Connect the **green** or **bare copper** ground wire from the fixture to the house ground wire.

    Use the provided wire nuts to secure each connection. Wrap electrical tape around the wire nuts for added security.
5. **Mount Fixture:** Carefully tuck all wires into the junction box. Align the fixture's base with the mounting plate and secure it using the screws provided.
6. **Restore Power:** Once the fixture is securely mounted, restore power at the circuit breaker or fuse box.

Operating Instructions

The P4338-647 LED Swing Arm Wall Lamp features an integrated dimmer switch and an adjustable arm for optimal light positioning.

- **Power On/Off:** Press the button located on the fixture's base to turn the light on or off.
- **Dimming:** While the light is on, press and hold the button to cycle through dimming levels. Release the button when the desired brightness is achieved. The lamp features a memory function that recalls the last dimming setting when turned back on.
- **Adjusting the Arm:** The swing arm allows for flexible positioning of the light. Gently move the arm to direct the light as needed. The

lamp head can also swivel to adjust the light direction.

- **Wall Switch Control:** This fixture is designed with an integrated dimmer switch. If connected to a wall switch, the lamp will power on in the 'off' state after the wall switch is toggled. You will need to press the button on the fixture to turn it on and adjust brightness. Direct control via a wall dimmer switch is not supported for dimming functionality.

Maintenance

To ensure the longevity and appearance of your fixture:

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **LED Module:** The LED module is integrated and not user-replaceable. Do not attempt to remove or replace it.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Fixture switch is off.	Check circuit breaker/fuse. Ensure all wire connections are secure (power off first). Press the button on the fixture to turn it on.
Light flickers or dims unexpectedly.	Loose wire connection. Incompatible wall dimmer (if applicable).	Check all wire connections (power off first). Ensure the fixture is not connected to an external wall dimmer, as it has an integrated dimmer.
Cannot control with wall switch.	Fixture requires manual activation.	The fixture's integrated switch must be used to turn the light on/off and dim, even if the wall switch provides power. The wall switch acts as a master power cut-off.

Specifications

- **Model Number:** P4338-647
- **Dimensions:** 14.75 inches (Width) x 6.25 inches (Height) x 3.5 inches (Depth from wall when folded)
- **Weight:** Approximately 3.17 lbs
- **Light Source:** Integrated LED Module
- **Wattage:** 8 Watts (Total)
- **Lumen Output:** 438.76 Lumens
- **Color Temperature:** 3000K
- **Color Rendering Index (CRI):** 84
- **Voltage:** 120 Volts
- **Dimmable:** Yes, via integrated switch
- **Material:** Steel, Aluminum, Brass
- **Finish:** Copper Bronze Patina
- **Certification:** ETL Listed for Indoor Locations

Warranty and Support

This GEORGE KOVACS P4338-647 LED Swing Arm Wall Lamp is covered by a **One Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical assistance, or replacement parts, please contact the manufacturer or your retailer with your proof of purchase. Do not attempt to repair the fixture yourself, as this may void the warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question