Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer 725.30

Beurer PS160 Digital Bathroom Scale User Manual

Model: PS160 (725.30)

Introduction

Thank you for choosing the Beurer PS160 Digital Bathroom Scale. This manual provides important information regarding the safe and proper use, maintenance, and troubleshooting of your new scale. Please read it thoroughly before first use and keep it for future reference.
The Beurer PS160 is designed for precise and accurate weight measurement in a home environment. Its sleek design, large display, and user-friendly features make it a convenient tool for monitoring your weight.

Safety Information

Please observe the following safety instructions to ensure safe operation and prevent damage to the device or injury:

- Do not step on the scale with wet feet or if the surface is wet, as this may cause slipping.
- Place the scale on a firm, flat surface to ensure accurate measurements. Avoid carpets or uneven flooring.
- The scale is intended for personal use only and not for medical or commercial purposes.
- Keep the scale away from strong electromagnetic fields.
- Do not overload the scale beyond its maximum capacity of 180 kg (396 lb / 28 st).
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of batteries according to local regulations.

Package Contents

Upon unpacking, please check that all components are present and undamaged:

- 1 x Beurer PS160 Digital Bathroom Scale
- 1 x 3V CR2032 Battery (pre-installed or included separately)
- 1 x Instruction Manual (this document)

Product Overview



Figure 1: Top view of the Beurer PS160 Digital Bathroom Scale, showing its pure white acrylic surface and central digital display.



Figure 2: Close-up of the XXL digital display, featuring 47mm digits for easy readability. The display shows "62.4 kg" as an example measurement.



Figure 3: The comfortable acrylic standing platform of the Beurer PS160, designed for user comfort and durability.



Figure 4: The dimensions of the Beurer PS160 scale, measuring approximately 30.5 cm by 30.5 cm, providing a large standing surface.

Setup

1. Battery Installation

The Beurer PS160 scale comes with a 3V CR2032 battery. If the battery is not pre-installed or needs replacement:

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the CR2032 battery with the positive (+) terminal facing upwards.
4. Close the battery compartment cover securely.

2. Initial Placement

For accurate readings, place the scale on a hard, flat, and stable surface. Avoid placing it on carpets, rugs, or uneven flooring, as this can affect accuracy.

Operating Instructions

1. Switching On and Weighing

The Beurer PS160 features quick-start technology:

1. Gently tap the center of the scale with your foot to activate it. The display will show "0.0" or "0.00".

2. Once "0.0" or "0.00" is displayed, step onto the scale with bare feet, standing still and centered.
3. Your weight will be displayed on the XXL LCD screen.
4. The scale will automatically switch off after a few seconds of inactivity to conserve battery life.

2. Changing Weight Units

The scale can display weight in kilograms (kg), pounds (lb), or stones (st). To change the unit:

1. Locate the unit switch button on the underside of the scale, usually near the battery compartment.
2. Press the button to cycle through the available units (kg, lb, st).
3. The selected unit will be indicated on the display.



Figure 5: A user demonstrating the proper way to stand on the Beurer PS160 scale for an accurate weight measurement. The scale supports up to 180 kg.



Figure 6: The Beurer PS160 scale allows users to adjust the displayed weight units between kilograms (kg), pounds (lb), and stones (st).

Maintenance and Care

- Clean the scale surface with a damp cloth and a mild detergent if necessary. Do not use abrasive cleaning agents or immerse the scale in water.
- Do not attempt to disassemble or repair the scale yourself. Refer to qualified service personnel.
- Store the scale in a dry place, away from extreme temperatures and direct sunlight.
- If the scale will not be used for an extended period, remove the battery to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
"Lo" or no display	Low battery.	Replace the CR2032 battery.
"Err" or "O-Ld" on display	Overload. Weight exceeds maximum capacity (180 kg).	Reduce the weight on the scale.
Inaccurate readings	Scale not on a flat, hard surface; scale moved between readings; initial calibration needed.	Ensure scale is on a stable, flat surface. If moved, tap to activate and wait for "0.0" before weighing. Recalibrate by stepping on and off once.
Scale does not turn on	Battery issues; scale not activated correctly.	Check battery installation and charge. Tap the scale firmly to activate.

Specifications

Feature	Detail
Model	PS160 (Item model number: 725.30)
Brand	Beurer
Display Type	XXL LCD with 47mm digits
Weight Capacity	180 kg (396 lb / 28 st)
Graduation	100g
Units	kg / lb / st (selectable)
Standing Surface Area	30.5 x 30.5 cm
Product Dimensions	30.51 x 2.21 x 30.51 cm
Product Weight	Approximately 1.73 kg
Power Source	1 x 3V CR2032 Lithium Metal Battery (included)
Special Features	Quick-start technology, Automatic switch-off, Overload indicator
Colour	Pure white
Country of Origin	China

Warranty and Support

For warranty information and customer support, please refer to the official Beurer website or contact their customer service department. Keep your purchase receipt as proof of purchase.
For further assistance, you may visit the Beurer Store on Amazon.

© 2024 Beurer GmbH. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00DW5C79W

More documents and user manuals: **https://manuals.plus/**