Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi EDG605B

De'Longhi EDG605B Dolce Gusto Circolo Flow Stop Coffee Machine User Manual

Model: EDG605B

1. Introduction

This manual provides comprehensive instructions for the safe and efficient operation of your De'Longhi EDG605B Dolce Gusto Circolo Flow Stop Coffee Machine. This multi-beverage single-serve system is designed to produce a variety of gourmet coffees, lattes, cappuccinos, and iced drinks using a capsule-based system and 15-bar pressure for quality beverages.



Front view of the De'Longhi EDG605B Dolce Gusto Circolo Flow Stop Coffee Machine. The machine features a sleek, circular black design with a central capsule holder and drip tray. The power button is on the left, and beverage volume indicators are at the top.

2. Important Safety Information

Please read all safety instructions carefully before using the appliance. Retain this manual for future reference.

- Ensure the appliance is connected to a power supply that matches the voltage specified on the rating label. The machine operates on 120V.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Do not operate the appliance with a damaged cord or plug. Contact customer support for repairs.
- Always unplug the machine before cleaning and when not in use.

- Avoid contact with hot surfaces.

3. Product Overview and Components

Familiarize yourself with the main components of your coffee machine.

1. **Water Tank:** Located at the back, it holds water for brewing.
2. **Capsule Holder:** Where the coffee capsules are inserted.
3. **Brewing Head:** Pierces the capsule and dispenses the beverage.
4. **Drip Tray:** Collects excess liquid and can be adjusted for different cup sizes.
5. **Control Panel:** Features the power button and LED indicators for beverage volume.
6. **Mechanical Lever:** Used to start and stop the brewing process and select hot or cold water.



Close-up view of the capsule insertion area. A yellow Dolce Gusto capsule is shown being placed into the machine's capsule holder. The LED beverage volume indicators are visible above.

4. Initial Setup and First Use

Before using your coffee machine for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials and place the machine on a stable, flat surface.
2. **Clean Water Tank:** Wash the water tank with warm water and mild detergent, then rinse thoroughly.
3. **Fill Water Tank:** Fill the water tank with fresh, potable water up to the MAX level.

4. **Power On:** Plug the machine into a suitable electrical outlet. Press the power button. The button will flash red while heating, then turn green when ready.
5. **Rinse Cycle:** Perform a rinse cycle without a capsule. Place a cup under the dispenser. Move the mechanical lever to the hot water position (red) and let water flow until the tank is empty. Repeat with cold water (blue). This primes the system and cleans internal components.
6. **Adjust Drip Tray:** Adjust the drip tray height according to your cup size.

5. Operating Instructions

Follow these steps to prepare your desired beverage:

1. **Fill Water Tank:** Ensure the water tank is filled with fresh water.
2. **Power On:** Press the power button. Wait for the light to turn green, indicating the machine is ready.
3. **Insert Capsule:** Open the capsule holder and insert the desired Dolce Gusto capsule. Close the holder securely.
4. **Set Beverage Volume:** Use the LED indicators at the top of the machine to select the recommended water volume for your capsule. The capsule packaging will indicate the appropriate number of bars.
5. **Select Temperature:** Move the mechanical lever to the **red** position for hot beverages or the **blue** position for cold beverages.
6. **Brew:** The machine will automatically stop when the selected volume is dispensed, thanks to the Flow Stop system.
7. **Remove Capsule:** Once brewing is complete, move the lever back to the central position. Open the capsule holder and dispose of the used capsule.



Detailed view of the capsule insertion mechanism and the mechanical lever. The lever is shown in the central position, ready for selection of hot or cold water. The LED volume indicators are clearly visible.

6. Maintenance and Cleaning

Regular cleaning and maintenance ensure optimal performance and longevity of your machine.

6.1 Daily Cleaning

- **Drip Tray:** Empty and clean the drip tray and grid after each use. Wash with warm, soapy water and rinse.
- **Water Tank:** Rinse the water tank daily. Refill with fresh water.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.



Close-up view of the adjustable drip tray and cup rest area. The De'Longhi logo is visible on the removable tray. This component should be regularly cleaned.

6.2 Descaling

Descale your machine every 3-4 months, or more frequently in areas with hard water, to prevent mineral buildup.

1. **Prepare Descaling Solution:** Use a descaling solution specifically designed for coffee machines. Follow the manufacturer's

instructions for mixing with water.

2. **Empty Machine:** Remove any capsule and empty the water tank and drip tray.
3. **Fill Tank:** Pour the descaling solution into the water tank.
4. **Run Cycle:** Place a large container under the dispenser. Run several hot water cycles until the water tank is empty.
5. **Rinse:** Rinse the water tank thoroughly and fill with fresh water. Run several hot water cycles with fresh water to rinse out any remaining descaling solution.

7. Troubleshooting

Refer to this table for common issues and their solutions.

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into the outlet and the machine.
Water is not flowing.	Water tank empty; air in the system; machine needs descaling.	Fill water tank; perform a rinse cycle to prime; descale the machine.
Beverage is cold.	Lever not set to hot (red) position.	Ensure the mechanical lever is moved to the red position for hot beverages.
Machine leaks.	Water tank not properly seated; drip tray full.	Ensure the water tank is correctly positioned; empty the drip tray.

8. Technical Specifications

- **Model:** EDG605B
- **Brand:** De'Longhi
- **Coffee Maker Type:** Espresso Machine (Capsule-based)
- **Pressure:** 15 Bar
- **Special Feature:** Flow Stop System, Thermo block heating system
- **Operation Mode:** Fully Automatic
- **Dimensions:** 12.4 x 7.72 x 7 inches
- **Item Weight:** 8.7 pounds
- **Voltage:** 120V (for US market)
- **Manufacturer:** DeLonghi America, Inc.

9. Warranty and Support

De'Longhi products are manufactured with high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official De'Longhi website. For technical support, spare parts, or service, please contact De'Longhi customer service.
You can find more information and support resources on the De'Longhi Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00DY5WWVS

More documents and user manuals: **https://manuals.plus/**