LiftMaster 893LM

LIFTMASTER Garage Remote 893LM Instruction Manual

Model: 893LM

Product Overview

The LiftMaster 893LM Garage Remote is a three-button remote control transmitter designed for convenient operation of up to three LiftMaster garage door openers, gate operators, or MyQ enabled light devices. It is compatible with Security+2.0 LiftMaster garage door openers and gate operators, as well as Craftsman AssureLink garage door openers by Sears. This remote provides reliable access to your garage or property with its robust design and easy-to-use interface.



Image: The LiftMaster 893LM remote control, featuring three distinct buttons for controlling multiple devices, and a metal visor clip for convenient storage in a vehicle.

Key Features

- Operates up to three LiftMaster garage door openers, gate operators, or MyQ enabled light devices.
- Compatible with Security+2.0 LiftMaster garage door openers or gate operators.
- Compatible with Craftsman AssureLink garage door openers by Sears.
- Designed for garage door openers with a yellow Learn button and two yellow antennas.
- Ergonomic design for comfortable handling.

Package Contents

- One (1) LiftMaster 893LM Garage Remote
- One (1) Visor Clip
- One (1) CR2 Battery (pre-installed or included)
- Instruction Manual (this document)



Image: The LiftMaster 893LM remote control shown alongside its included metal visor clip, ready for attachment.

Setup and Programming

To program your LiftMaster 893LM remote control to your garage door opener, follow these steps. Ensure your garage door opener has a yellow Learn button and two yellow antennas for compatibility.

1. **Locate the Learn Button:** On your garage door opener motor unit, locate the yellow "Learn" button. This button is typically found on the back or side panel of the motor unit.
2. **Press the Learn Button:** Press and immediately release the yellow "Learn" button on the garage door opener. The learn indicator light will glow steadily for 30 seconds.
3. **Activate the Remote:** Within 30 seconds, press and hold the button on your 893LM remote control that you wish to program.
4. **Release the Remote Button:** Release the remote control button when the garage door opener lights flash or two clicks are heard. This indicates that the remote has been successfully programmed.
5. **Test the Remote:** Press the programmed button on your remote control to test its operation. The garage door should activate.
6. **Programming Multiple Buttons:** Repeat steps 1-5 for any additional buttons on your 893LM remote if you wish to control other compatible garage door openers or devices.

For detailed visual instructions, refer to the official LiftMaster support resources or the manual provided with your garage door opener.

Operating Your Remote

Once programmed, operating your LiftMaster 893LM remote is straightforward:

- **Opening/Closing:** Press the programmed button on your remote control to open or close the associated garage door, gate, or activate the MyQ light device.
- **Stopping Operation:** Press the button again while the door is in motion to stop its movement.
- **Multiple Devices:** Use the different programmed buttons to control up to three separate compatible devices.

Maintenance

The LiftMaster 893LM remote control requires minimal maintenance. The primary maintenance task is battery replacement.

Battery Replacement

When the remote's range decreases or the indicator light does not illuminate when a button is pressed, it's time to replace the battery. The remote uses one (1) CR2 battery.

1. **Open the Remote:** Locate the small notch or opening on the side or bottom of the remote. Use a small flathead screwdriver or coin to gently pry open the remote casing.
2. **Remove Old Battery:** Carefully remove the old CR2 battery from its compartment.
3. **Insert New Battery:** Insert a new CR2 battery, ensuring the positive (+) side is facing up, as indicated in the battery compartment.
4. **Close the Remote:** Snap the remote casing back together until it is securely closed.
5. **Test Operation:** Test the remote to ensure it functions correctly with your garage door opener.

Troubleshooting

Problem	Possible Cause	Solution
Remote does not activate opener.	Battery is dead or weak. Remote is out of range. Remote is not programmed. Opener's learn mode has expired.	Replace the CR2 battery. Move closer to the garage door opener. Reprogram the remote following the "Setup and Programming" section. Ensure you press the remote button within 30 seconds of pressing the learn button.
Remote range is poor.	Weak battery. Interference from other devices. Obstructions between remote and opener.	Replace the CR2 battery. Check for sources of interference (e.g., other wireless devices, metal objects). Ensure a clear line of sight to the opener's antenna.
Garage door opens/closes unexpectedly.	Remote button accidentally pressed. Interference.	Ensure remote is stored securely. Check for sources of interference. Consider clearing all remote codes from the opener and reprogramming only your remotes.

Technical Specifications

Model Number: 893LM

Brand: LiftMaster

Product Dimensions: 3 x 1 x 1 inches

Item Weight: 2.11 ounces

Battery Type: 1 CR2 battery required

Color: Black

Max Number of Supported Devices: 3

Compatible Devices: LiftMaster garage door openers with Security+2.0, Craftsman AssureLink garage door openers by Sears, MyQ enabled light devices

Manufacturer: LIFTMASTER

Warranty and Support

For information regarding product warranty, technical support, or to purchase replacement parts, please visit the official LiftMaster website or contact their customer service department. You can also find more information by visiting the LiftMaster Store on Amazon.
Always refer to the latest documentation provided by the manufacturer for the most accurate and up-to-date information.

© 2024 LiftMaster. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question