Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eurotime 53830-05

Eurotime Radio-Controlled Wall Clock User Manual

Model: 53830-05

1. Introduction

Thank you for purchasing the Eurotime Radio-Controlled Wall Clock. This manual provides important information regarding the setup, operation, and maintenance of your new clock. Please read it thoroughly before use and keep it for future reference.

Product Overview

The Eurotime 53830-05 is a modern, radio-controlled wall clock designed for precise timekeeping. Its timeless design with a clear dial and robust plastic casing makes it suitable for various indoor environments such as kitchens, dining rooms, living rooms, or offices.



Figure 1: Front view of the Eurotime Radio-Controlled Wall Clock, showing the black casing, white dial, black hour and minute hands, and a red seconds hand. The text "RADIO CONTROLLED" is visible at the bottom of the dial.

Package Contents

- 1 x Eurotime Radio-Controlled Wall Clock (Model 53830-05)
- 1 x User Manual (this document)

Note: 1 x AA 1.5V battery is required and not included in the package.

2. Safety Information

- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the clock or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the clock yourself. Refer to qualified personnel for service.
- Dispose of used batteries according to local regulations.

- Keep batteries out of reach of children.

3. Setup

Battery Installation

1. Locate the battery compartment on the back of the clock.



Figure 2: Back view of the Eurotime Radio-Controlled Wall Clock, highlighting the central battery compartment and mounting hole.

2. Insert one (1) new 1.5V AA alkaline battery into the compartment, ensuring the correct polarity (+/-) as indicated.
3. Close the battery compartment cover securely.

Initial Synchronization

After inserting the battery, the clock hands will automatically move to the 12 o'clock position. They will remain there until the clock receives the radio signal (DCF signal).

- Place the clock near a window or in an area with minimal electronic interference (e.g., away from TVs, computer

screens, or large metal objects).

- The clock will automatically search for the DCF radio signal and set itself to the correct time. This process can take several minutes.
- If the clock does not set itself within 5 minutes, allow it more time, possibly overnight. The DCF signal is often strongest at night.
- Avoid pressing any buttons on the clock during the synchronization process.

4. Operating the Clock

Automatic Time Setting

The Eurotime Radio-Controlled Wall Clock automatically receives the DCF radio signal to ensure precise timekeeping. This includes automatic adjustment for Daylight Saving Time (summer time) and Standard Time (winter time).

Understanding the Display

- **Hour and Minute Hands:** Black, indicating the current time.
- **Seconds Hand:** Red, providing continuous second-by-second movement.
- **Dial:** Clear, traditional station clock design for excellent readability.

5. Maintenance

Cleaning

To clean the clock, wipe it gently with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the casing or glass.

Battery Replacement

If the seconds hand stops or the clock consistently loses time, it is an indication that the battery needs to be replaced. Follow the battery installation steps in Section 3 to replace the battery with a new 1.5V AA alkaline battery.

6. Troubleshooting

Most malfunctions can be resolved by addressing common issues. Refer to the table below for solutions to frequently encountered problems.

Problem	Possible Cause	Solution
Clock does not set time or stops working.	Weak or incorrect battery type.	Ensure you are using a fresh, full alkaline AA battery. Non-alkaline batteries may not provide sufficient power.
Clock does not synchronize with the radio signal.	Interference or weak signal.	Relocate the clock to a window or an area with less electronic interference (e.g., away from TVs, computers). The DCF signal can be weak in certain regions or locations. Try again, especially overnight when the signal is typically strongest. Ensure no buttons are pressed during the synchronization process.

Problem	Possible Cause	Solution
Seconds hand stops or clock constantly resets.	Battery is low.	Replace the battery with a new 1.5V AA alkaline battery.

If you continue to experience issues, please contact Eurotime customer support for assistance.

7. Specifications

Feature	Detail
Brand	Eurotime
Model Number	53830-05
Type	Radio-Controlled Wall Clock
Color	Black
Material	Plastic casing, Real glass cover
Dimensions	Approximately 30 cm (11.8 inches) diameter, 4 cm (1.6 inches) depth
Weight	501 g (1.1 lbs)
Display Type	Analog
Power Source	1 x 1.5V AA Battery (not included)
Time Synchronization	DCF Radio Signal (Automatic)
Time Adjustment	Automatic Summer/Winter Time Change

8. Warranty and Support

Eurotime products are manufactured with high-quality materials and undergo strict quality control. For information regarding warranty terms and conditions, please refer to the documentation provided at the time of purchase or visit the official Eurotime website.
For technical support or inquiries, please contact Eurotime customer service. Contact details can typically be found on the product packaging or the official brand website.

© 2024 Eurotime. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00E8HX31Y

More documents and user manuals: **https://manuals.plus/**