Beurer MG 300

Beurer MG 300 Shiatsu Massage Seat Cover User Manual

Model: MG 300

1. Important Safety Information

Please read these instructions for use carefully and keep them for later use. Make them accessible to other users and observe the information they contain.

- Always ensure the power cord is kept away from water and out of reach of children.
- Do not operate the massager with wet hands or while sitting on a wet surface.
- Always unplug the massager when not in use and before cleaning.
- Do not use the device if it or its accessories show visible signs of damage.
- This device is not intended for use by persons with reduced physical, sensory or mental capabilities or lack of experience and/or knowledge, unless they are supervised by a person responsible for their safety or have been instructed on how to use the device.

2. Product Overview

The Beurer MG 300 Shiatsu Massage Seat Cover provides a comprehensive massage experience with its advanced features.





Figure 1: Beurer MG 300 Shiatsu Massage Seat Cover. This image shows the full massage seat cover in its upright position, highlighting its ergonomic design and breathable mesh surface.



Figure 2: Remote Control for MG 300. This image displays the wired remote control unit, showing various buttons for massage type selection, intensity adjustment, heat function, and body scanning.



Figure 3: Internal 3D Massage Heads. This image provides a cutaway view of the massage seat cover, illustrating the four 3D massage heads and their track system that moves along the spine.

3. Setup

Follow these steps to set up your Beurer MG 300 Shiatsu Massage Seat Cover:

1. **Unpack:** Carefully remove the device from its packaging. Check for any signs of damage.
2. **Positioning:** Place the massage seat cover on a suitable chair with a backrest. Ensure the chair is stable and can support the weight of the user and the device. The seat cover is designed to fit most chairs with a back area of approximately 89 x 48 cm and a seat area of approximately 40 x 47.5 cm.

3. **Secure:** Use the flexible fastening straps located on the back of the massage seat cover to securely attach it to the chair. This prevents the cover from slipping during use.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet. Ensure the power cord is not kinked or trapped.





Figure 4: Massage Seat Cover Attached to a Chair. This image demonstrates how the Beurer MG 300 can be easily placed and secured onto a standard chair for immediate use.

4. Operating Instructions

The Beurer MG 300 offers various massage functions for a personalized experience.

4.1 Power On/Off

- Press the **Power button** on the remote control to turn the device on. The device will typically begin with an automatic body scan.
- Press the **Power button** again to turn the device off.

4.2 Automatic Body Scanning

Upon activation, the intelligent automatic body scanning function will read your body size and shape, adjusting the massage heads to fit your individual contours for a targeted massage.

4.3 Massage Programs

Select from the following massage types using the remote control:

- **Shiatsu Massage:** A deep, kneading massage that mimics the pressure of human fingers.
- **Swing Massage:** A gentle, rhythmic swinging motion for relaxation.
- **Roll Massage:** A continuous rolling motion along the spine, helping to stretch and relax muscles.

4.4 Massage Areas

You can choose between three individually selectable massage areas:

- **Full Back:** Massages the entire back area.
- **Upper Back:** Focuses on the neck and shoulder region.
- **Lower Back:** Concentrates on the lumbar area.

Use the dedicated buttons on the remote control to select your desired massage area.

4.5 Infrared Light and Heat Function

The optional infrared light and heat function can be activated to intensify your massage and provide soothing warmth. Press the **Heat button** on the remote control to toggle this function on or off.

4.6 Timer Function

The device features a built-in timer. You can set the massage duration to 5, 10, or 15 minutes using the **Timer button** on the remote control. The device will automatically shut off once the selected time has elapsed.

5. Maintenance and Care

Proper maintenance ensures the longevity and hygiene of your massage seat cover.

- **Cleaning:** Always unplug the device before cleaning. Wipe the surface of the massage seat cover with a soft, damp cloth. Do not use abrasive cleaning agents or immerse the device in water.
- **Removable Cover:** The removable cover is machine washable at 40°C. Ensure it is completely dry before reattaching it to the unit.
- **Storage:** When not in use, store the device in a cool, dry place, away from direct sunlight and excessive heat.

6. Troubleshooting

If you encounter issues with your Beurer MG 300, please refer to the following common solutions:

- **Device not turning on:**
  - Check if the power cord is securely plugged into both the device and the electrical outlet.
  - Ensure the power outlet is functional by testing it with another appliance.
- **Massage heads not moving:**
  - Verify that the device is powered on and not in standby mode.
  - The automatic body scanning function might be in progress; wait for it to complete.
  - Ensure no obstructions are preventing the movement of the massage heads.
- **Heat function not working:**
  - Confirm that the heat function is activated via the remote control.
  - Allow a few minutes for the heating elements to warm up.
- **Unusual noises during operation:**
  - Minor operational noises are normal. If the noise is loud or unusual, discontinue use and contact customer support.

If the problem persists after trying these steps, please contact Beurer customer support.

7. Specifications

Feature	Specification
Model Number	640.51 (MG 300)
Product Dimensions	90 x 55 x 21 cm
Item Weight	648 Grams (0.648 kg)
Material	Nylon (Surface made of breathable mesh and neoprene)
Power Source	Power Cord Connector
Massage Types	Shiatsu, Swing, Roll
Massage Heads	4 x 3D Massage Heads
Special Features	Automatic Body Scanning, Infrared Light + Heat Function, Removable Cover
Washable Cover	Machine washable at 40°C

Feature	Specification
Back Surface Dimensions	89 x 48 cm
Seat Surface Dimensions	40 x 47.5 cm
Country of Origin	Germany

8. Warranty and Support

8.1 Warranty Information

Specific warranty details for the Beurer MG 300 Shiatsu Massage Seat Cover are typically provided with the product packaging or on the official Beurer website. Please refer to the warranty card included with your purchase for terms and conditions, including the warranty period and coverage.

8.2 Customer Support

For technical assistance, product inquiries, or warranty claims, please contact Beurer customer service. Contact information can usually be found on the official Beurer website or on the product packaging.
You may also visit the official Beurer website for FAQs and additional support resources:www.beurer.com

© 2023 Beurer GmbH. All rights reserved.