Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AEG EPMX535731

AEG EPMX535731 Built-in Cooker Set with Induction Cooker

User Instruction Manual

Introduction

Thank you for choosing the AEG EPMX535731 Built-in Cooker Set with Induction Cooker. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read it thoroughly before use and keep it for future reference.

Safety Information

Always adhere to the following safety precautions to prevent personal injury or damage to the appliance.

- Ensure the appliance is properly earthed before use.
- Do not store flammable materials in or near the oven.
- Keep children away from the appliance during operation as surfaces can become very hot.
- Always use oven mitts when handling hot dishes or oven racks.
- Do not use abrasive cleaners or sharp metal scrapers to clean the oven door glass.
- Disconnect the appliance from the power supply before any cleaning or maintenance.

Setup and Installation

Professional installation is recommended for this built-in appliance. Ensure all local regulations and standards are met.

Unpacking

Carefully remove all packaging materials. Inspect the appliance for any signs of damage. Report any damage to your retailer immediately.

Electrical Connection

The appliance must be connected to the mains supply by a qualified electrician. Ensure the voltage and frequency ratings on the appliance's rating plate match your household supply.

Mounting the Oven

Slide the oven into the prepared cabinet opening. Secure it using the screws provided, ensuring it is level and stable.



Figure 1: Front view of the AEG EPMX535731 built-in oven. This image shows the control panel at the top, the oven door, and the interior with racks. The fan at the back of the oven cavity is visible.

Operating Instructions

This section details how to use your AEG cooker and induction hob.

Oven Functions

- **Conventional Cooking:** Ideal for baking and roasting on one level.
- **Fan Cooking:** For cooking on multiple levels simultaneously, ensuring even heat distribution.
- **Grill:** For browning and toasting. Use with the oven door slightly ajar.
- **Defrost:** Gentle thawing of frozen foods.

Induction Hob Operation

The induction hob uses electromagnetic fields to heat cookware directly. Only use induction-compatible cookware.

1. Place an induction-compatible pan on the desired cooking zone.
2. Turn the corresponding control knob to activate the zone.
3. Adjust the power level as required.
4. The hob will automatically detect the pan and begin heating.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your appliance.

Oven Cleaning

- Allow the oven to cool completely before cleaning.
- Wipe interior surfaces with a damp cloth and mild detergent. For stubborn stains, use a specialized oven cleaner according to its instructions.
- Remove oven racks and clean them separately in warm soapy water.

Hob Cleaning

- Clean the induction hob surface with a soft cloth and a non-abrasive cleaner specifically designed for ceramic or induction hobs.
- Remove any spills immediately to prevent them from burning onto the surface.

Troubleshooting

Before contacting service, please check the following common issues and solutions.

Problem	Possible Cause	Solution
Oven not heating	No power supply; incorrect settings.	Check circuit breaker; ensure correct function and temperature are selected.
Induction hob not working	Non-compatible cookware; pan not detected.	Use induction-compatible cookware; ensure pan is centered on the zone.
Excessive smoke from oven	Food spills; residual grease.	Clean oven thoroughly; reduce cooking temperature if food is burning.

Specifications

Feature	Detail
Brand	AEG (Manufactured by Electrolux)
Model Number	EPMX535731
Item Model Number	801403598
Type	Built-in Cooker Set with Induction Hob
Language	English
Date First Available	15 March 2022

Warranty and Support

Your AEG EPMX535731 Built-in Cooker Set is covered by a manufacturer's warranty. Please refer to the warranty card included with your appliance for specific terms and conditions.
For technical assistance, spare parts, or to schedule a service appointment, please contact Electrolux customer support. You can find contact details on the Electrolux official website or in the documentation provided with your appliance.
Note: Always provide the model number (EPMX535731) and serial number when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00EIMDL98

More documents and user manuals: **https://manuals.plus/**