Bajaj 2504 ETC

Bajaj 2504 ETC 25 Litres Convection Microwave Oven User Manual

Model: 2504 ETC | Brand: Bajaj

Introduction Safety Instructions Product Features Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Bajaj 2504 ETC 25 Litres Convection Microwave Oven. This appliance is designed to provide versatile cooking options, including microwave, grill, and convection functions, making your cooking experience efficient and convenient. Please read this manual thoroughly before operating the appliance to ensure safe and optimal use. Keep this manual for future reference.



Figure 1: Bajaj 2504 ETC Convection Microwave Oven, front view.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure the appliance is properly grounded.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Only use utensils suitable for microwave ovens.
- Do not use corrosive chemicals or vapors in this appliance.
- Close supervision is necessary when the appliance is used by or near children.

3. Product Features

The Bajaj 2504 ETC Convection Microwave Oven offers a range of features designed for convenience and efficiency:

- **25 Litres Capacity:** Suitable for large families, accommodating various cooking needs.
- **Convection Functionality:** Allows for baking, grilling, reheating, defrosting, and general cooking.
- **Intuitive Controls:** Features tactile buttons for precise temperature and timer settings, along with durable jog dials for ease of use.
- **Child Lock:** An essential safety feature that prevents accidental operation by children.
- **Auto Cook Menus:** Pre-programmed settings for various dishes, simplifying cooking by automatically adjusting time and power levels.
- **Multiple Power Levels:** Offers flexibility to choose different power levels to control cooking intensity as required.



Figure 2: Key features of the Bajaj 2504 ETC Microwave Oven, including electronic controls, convection type, 5 cooking levels, 9 auto cook menus, and 25 litres capacity.

4. Setup and Installation

Proper setup ensures optimal performance and safety of your microwave oven.

1. **Unpacking:** Carefully remove the oven and all materials from the carton. Remove any protective film from the cabinet surface.
2. **Placement:** Place the oven on a flat, stable surface strong enough to hold its weight. Ensure adequate ventilation space: at least 20 cm of space above the oven, 10 cm at the rear, and 5 cm on each side.
3. **Power Connection:** Plug the power cord into a standard, grounded electrical outlet. Ensure the voltage matches the appliance's requirements.
4. **Turntable Assembly:**
    - Place the roller ring in the depression on the oven floor.
    - Place the glass tray on top of the roller ring, ensuring it sits securely.

5. **Initial Cleaning:** Wipe the interior and exterior surfaces with a damp cloth before first use.

5. Operating Instructions

This section details how to use the various functions of your Bajaj 2504 ETC microwave oven.

5.1 Control Panel Overview



Figure 3: Close-up of the control panel, showing the digital display and auto-cook menu buttons.



Figure 4: Close-up of the jog dial for timer/weight/auto menu selection and additional function buttons.

The control panel features a digital display, tactile buttons for specific functions (e.g., Microwave, Grill, Convection, Defrost, Auto Cook), and a central jog dial for adjusting time, weight, or selecting auto menus.

5.2 Microwave Cooking

1. Place food in a microwave-safe container on the glass tray.

2. Close the oven door.
3. Press the "Microwave" button.
4. Rotate the jog dial to set the desired cooking time.
5. Press "Start" to begin cooking.
6. To adjust power levels, press "Power Level" button and then rotate the jog dial to select the desired level (e.g., P100 for full power, P80 for 80% power).

5.3 Convection Cooking

Use the convection function for baking and roasting.

1. Place food on the metal rack (if provided and suitable for convection) or in an oven-safe dish.
2. Press the "Convection" button.
3. Rotate the jog dial to select the desired temperature.
4. Press "Start" to preheat the oven. The oven will beep when preheating is complete.
5. Place the food inside and close the door.
6. Rotate the jog dial to set the cooking time.
7. Press "Start" to begin convection cooking.

5.4 Grill Function

Ideal for grilling and browning food.

1. Place food on the grill rack (if provided) or in a heat-resistant dish.
2. Press the "Grill" button.
3. Rotate the jog dial to set the desired grilling time.
4. Press "Start" to begin grilling.

5.5 Defrosting

The oven offers both time and weight-based defrosting.

- **Defrost by Weight:**
    a. Press the "Defrost" button.
    b. Rotate the jog dial to select the food weight.
    c. Press "Start".
- **Defrost by Time:**
    a. Press the "Defrost" button twice.
    b. Rotate the jog dial to set the defrosting time.
    c. Press "Start".

5.6 Auto Cook Menus

The oven includes several pre-programmed auto cook menus for common dishes.

1. Place the food in the oven.
2. Press the "Auto Menu" button or select directly from the dedicated auto cook buttons (e.g., Pizza, Potato, Meal, Fish, Vegetable, Beverage, Pasta, Popcorn, Cake, Chicken).
3. Rotate the jog dial to select the desired quantity or weight if prompted.
4. Press "Start" to begin cooking.

5.7 Child Lock Function

To prevent unintended operation, especially by children:

- **To Activate:** Press and hold the "Stop/Cancel" button for 3 seconds. A lock indicator will appear on the display.
- **To Deactivate:** Press and hold the "Stop/Cancel" button for 3 seconds again. The lock indicator will disappear.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your appliance and ensure hygienic operation.

- **Interior Cleaning:** After each use, wipe the interior with a damp cloth. For stubborn stains, use a mild detergent. Never use abrasive cleaners or scouring pads.
- **Exterior Cleaning:** Clean the exterior with a soft, damp cloth. Avoid getting water into the ventilation openings.
- **Door and Seals:** Regularly clean the door, door seals, and adjacent parts to remove any spills or splatters.
- **Glass Tray and Roller Ring:** These can be washed in warm soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.
- **Odor Removal:** To remove odors, combine a cup of water with the juice and peel of one lemon in a microwave-safe bowl. Microwave on high for 5 minutes, then let it sit in the oven for another 5 minutes before wiping clean.
- **Power Disconnection:** Always unplug the oven from the power outlet before cleaning.

7. Troubleshooting Guide

If you encounter issues with your oven, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close the door firmly; Check household fuse or reset circuit breaker.
Food not heating	Door not closed properly; Cooking time/power level not set correctly; Food not suitable for microwave.	Close the door firmly; Adjust cooking time and power level; Use microwave-safe dishes.
Sparking inside oven	Metal or foil in the oven; Utensils not microwave-safe; Food splatters.	Remove any metal objects; Use only microwave-safe utensils; Clean oven interior thoroughly.
Uneven cooking	Food not stirred or rotated; Incorrect power level or cooking time.	Stir or rotate food during cooking; Adjust power level and cooking time as needed.
Oven light not working	Bulb burnt out.	Contact qualified service personnel for bulb replacement.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Detailed technical specifications for the Bajaj 2504 ETC Convection Microwave Oven.

Feature	Detail
Brand	Bajaj
Model	2504 ETC

Feature	Detail
Capacity	25 Litres
Oven Cooking Mode	Convection
Wattage	800 Watts
Colour	Silver Grey
Installation Type	Countertop
Special Features	Auto Cook, Child Lock
Defrost System	Defrost
Item Dimensions (LxWxH)	53.2 x 42.1 x 31.3 Centimeters
Item Weight	18 kg 200 g
Date First Available	7 September 2013



Product Name	Length (cm)	Breadth (cm)	Height (cm)
25L Convection Microwave Oven (2504 ETC, Silver Grey)	58	49.5	36.3

Figure 5: Dimensions of the Bajaj 2504 ETC Convection Microwave Oven (Length, Breadth, Height).

9. Warranty and Support

Your Bajaj 2504 ETC Convection Microwave Oven comes with a **1-year warranty on the product** from the date of purchase. For warranty claims, technical support, or service inquiries, please contact Bajaj customer service. Keep your purchase receipt as proof of purchase for warranty validation.

Manufacturer: Bajaj

Importer/Packer: Imported and Marketed by Bajaj Electricals Ltd 45/47, Veer Nariman Road, Mumbai, 400001

Please refer to the warranty card included with your product for complete terms and conditions.

© 2023 Bajaj. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question