Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S7ARFW-343

Skullcandy Air Raid Portable Bluetooth Speaker User Manual

Model: S7ARFW-343 | Brand: Skullcandy

Introduction

The Skullcandy Air Raid is a rugged, water-resistant, and drop-proof portable Bluetooth speaker designed to deliver powerful sound in any environment. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Air Raid speaker.

What's in the Box

- Skullcandy Air Raid Portable Bluetooth Speaker
- Charging Cable (USB)
- Auxiliary Cable (3.5mm)
- User Guide (this manual)



Figure 1: Skullcandy Air Raid speaker and accessories as packaged.

Product Overview

The Skullcandy Air Raid speaker features a robust design with a steel faceplate and a removable rubber boot for enhanced durability. It is equipped with 50mm drivers for 360-degree sound and offers seamless Bluetooth connectivity.



Figure 2: Front view showing speaker grilles and control panel.



Figure 3: Side view with power switch and battery indicator lights.



Figure 4: Top view of the speaker's durable casing.



Figure 5: Side view with integrated carrying handle.

Setup

1. Charging the Speaker

Before first use, fully charge your Skullcandy Air Raid speaker. Connect the provided USB charging cable to the charging port on the side of the speaker and plug the other end into a USB power adapter (not included) or a computer's USB port. The battery indicator lights will show charging status.

- Red lights: Charging
- Green lights: Fully charged

A full charge provides up to 14 hours of music playback.

2. Powering On/Off

Locate the ON/OFF switch on the side of the speaker (refer to Figure 3). Slide the switch to the "ON" position to power on the speaker. Slide it to the "OFF" position to power off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on. The Bluetooth indicator light (usually blue) will blink, indicating it's in pairing mode.
2. On your audio device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.

3. Select "Skullcandy Air Raid" from the list of found devices.
4. Once paired, the Bluetooth indicator light on the speaker will turn solid blue, and you will hear an audible confirmation.

The speaker will automatically attempt to reconnect to the last paired device when powered on.

4. Auxiliary Input

For non-Bluetooth devices, connect the provided 3.5mm auxiliary cable from your audio source to the AUX input port on the speaker. The speaker will automatically switch to AUX mode.

Operating Instructions

Volume Control

Use the large '+' and '-' buttons on the front of the speaker to adjust the volume. Press '+' to increase volume and '-' to decrease volume.



Figure 6: Front panel with volume controls.

Music Playback Control

The central button on the front panel (between the volume controls) can be used for music playback:

- Press once: Play/Pause
- Press twice: Skip to next track
- Press three times: Go to previous track

Call Management

If connected to a smartphone, the speaker can be used for hands-free calls:

- Press once (central button): Answer incoming call / End current call
- Press and hold (central button): Reject incoming call

Features Overview

- **Water-resistant:** Designed to withstand splashes and light rain. Do not submerge the speaker.
- **Drop Proof:** Engineered for durability against accidental drops.
- **Bluetooth Connectivity:** Seamless wireless connection to compatible devices.
- **Portable Design:** Compact and easy to carry for on-the-go use.
- **360° Sound:** Delivers immersive audio from all directions.
- **Long Battery Life:** Up to 14 hours of continuous music playback on a single charge.

Your browser does not support the video tag.

Video 1: Official product video showcasing the Skullcandy Air Raid speaker's features and durability.

Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the exterior of the speaker. Avoid using harsh chemicals or abrasive cleaners.
- **Water Resistance:** Ensure the charging port cover is securely closed to maintain water resistance. Do not expose the speaker to prolonged immersion in water.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Store in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (blinking blue light). Turn off and on Bluetooth on your device. Forget "Skullcandy Air Raid" from your device's Bluetooth settings and try pairing again. Ensure no other devices are currently connected to the speaker.
No sound or low volume.	Increase volume on both the speaker and your connected device. Ensure the speaker is properly paired or the AUX cable is fully inserted. Check if the audio source is playing.
Sound distortion.	Reduce the volume on either the speaker or the connected device. Ensure the speaker is within Bluetooth range.

Specifications

Feature	Detail
Model Name	Air Raid
Item Model Number	S7ARFW-343
Color	Black

Feature	Detail
Product Dimensions	3.3"D x 5.9"W x 8.5"H
Item Weight	1.1 Pounds
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Power Source	Battery Powered
Battery Type	1 Lithium Metal (included)
Speaker Maximum Output Power	5 Watts
Water Resistance Level	Water Resistant
Material	Plastic
Control Method	Touch
Compatible Devices	Laptop, Smartphone, Tablet, Television

Warranty and Support

This product comes with a Limited Warranty. For detailed warranty information, please refer to the official Warranty Document (PDF).
For further assistance or technical support, please visit the Skullcandy official website or contact their customer service.

© 2023 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00FFZD8I6

More documents and user manuals: **https://manuals.plus/**