Mohawk Home M230-0100

Mohawk Fil-Stik M230-0100 Instruction Manual

Model: M230-0100

Product Overview

The Mohawk Fil-Stik M230-0100 is a versatile repair stick designed to eliminate scratches, gouges, and abrasions on various surfaces. It is suitable for furniture, picture frames, leather, and more. This product requires no heat or special tools for application, offering a simple rub-in and wipe-off method. Its colors are fade-resistant and non-bleeding, and surfaces treated with Fil-Stik can be immediately topcoated with compatible finishes.



Image: A single stick of Mohawk Fil-Stik M230-0100 in Natural color. The stick is cylindrical and off-white, with a label wrapped around it. The label features the "MOHAWK" logo in blue and red, and the product name "Fil-Stik" in red. Text on the label indicates its purpose: "Eliminates scratches, gouges & abrasions on furniture, picture frames, leather & more."

Setup and Preparation

1. **Clean the Surface:** Ensure the damaged area is clean, dry, and free of dust, grease, or loose particles. Use a mild cleaner if necessary, and allow the surface to dry completely.
2. **Select the Correct Color:** Choose a Fil-Stik color that closely matches the surface to be repaired. Test on an inconspicuous area if unsure.

Operating Instructions

Follow these steps for effective application of the Mohawk Fil-Stik:

1. **Apply the Fil-Stik:** Firmly rub the Fil-Stik across the scratch, gouge, or abrasion. Apply enough pressure to fill the damaged area completely. For deeper damage, apply multiple layers.
2. **Remove Excess:** Immediately after filling the damage, use a plastic scraper, a credit card edge, or a clean, soft cloth to carefully wipe off any excess Fil-Stik from the surrounding undamaged surface. Wipe in the direction of the grain if applicable.
3. **Buff (Optional):** For a smoother finish, gently buff the repaired area with a clean, lint-free cloth.
4. **Topcoat (Optional):** If desired, the repaired area can be topcoated immediately with compatible finishes such as Tone Finish® aerosols or other clear coatings to provide additional protection and blend the repair.

Note: No heat or special tools are required for application. The Fil-Stik is designed for simple, direct use.

Maintenance and Storage

- **Cleaning:** The Fil-Stik itself does not require cleaning. Keep the tip free of debris for optimal application.
- **Storage:** Store the Fil-Stik in a cool, dry place away from direct sunlight and extreme temperatures. Keep the protective cap on (if applicable) to prevent drying or contamination.

Troubleshooting

Problem	Possible Cause	Solution
Fil-Stik not filling damage properly.	Insufficient pressure; damage too deep; surface not clean.	Apply more pressure; apply multiple layers; ensure surface is clean and dry.
Excess Fil-Stik difficult to remove.	Allowed to dry too long; too much applied.	Wipe off immediately after application; apply in thinner layers.
Color does not match.	Incorrect color selected.	Test on an inconspicuous area first; consider blending with other Fil-Stik colors if experienced.

Specifications

Attribute	Detail
Brand	Mohawk Home
Model Number	M230-0100
Part Number	M230-0100
Item Weight	5 pounds
Product Dimensions	4.15 x 0.5 x 0.5 inches
Usage	Personal use for surface repair
Batteries Included?	No

Attribute	Detail

Warranty and Support

For specific warranty information or technical support regarding your Mohawk Fil-Stik M230-0100, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for any warranty claims.

Manufacturer: Mohawk Finishing Products

Brand Store: Mohawk Finishing Products Store on Amazon

© 2024 Mohawk Home. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question