Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Je Joue E24517

Je Joue Mimi Soft Clitoral Vibrator

Model: E24517 | Brand: Je Joue

1. Introduction

The Je Joue Mimi Soft is a clitoral vibrator designed for powerful yet discreet stimulation. It features a soft, squishy tip and an extra layer of super-soft silicone, allowing for firm pressure without discomfort, ideal for heightened sensitivity. Its ergonomic design fits comfortably in the hand, providing targeted vibrations to pleasure points.

This device utilizes ultra-low frequency vibrations for deeper sensation compared to traditional 'buzzy' toys. It offers 5 speeds and 7 vibration patterns, all powered by a whisper-quiet motor. Constructed from velvety-smooth, medical-grade silicone, the Mimi Soft is 100% body-safe and fully waterproof, making it suitable for use in various environments, including baths and showers.



Image 1.1: The Je Joue Mimi Soft Clitoral Vibrator in its purple color.

2. Safety Information

- **Medical-Grade Silicone:** The device is made from 100% medical-grade silicone. Clean thoroughly before and after each use.
- **Waterproof:** The Mimi Soft is fully waterproof. Ensure the charging port is completely dry before charging.
- **Charging:** Use only the provided USB charging cable. Do not use if the cable or device appears damaged.
- **Storage:** Store in a cool, dry, and dust-free place, away from direct sunlight and extreme temperatures.
- **Discontinue Use:** If you experience any discomfort, irritation, or adverse reactions, discontinue use immediately and consult a healthcare professional.
- **Keep Out of Reach of Children:** This product is intended for adult use only.

3. Package Contents

Verify that all items are present in the package:

- Je Joue Mimi Soft Clitoral Vibrator
- USB Charging Cable
- User Manual (this document)



Image 3.1: The product packaging for the Je Joue Mimi Soft.

4. Setup

4.1 Initial Charging

Before first use, fully charge your Mimi Soft device. The device requires 1 Lithium Ion battery, which is integrated.

1. Locate the charging port on the device. This is typically a small, discreet port on the base or side.
2. Connect the provided USB charging cable to the device's charging port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The indicator light on the device will illuminate or flash to show it is charging. Refer to the device's specific light indicators for charging status.
5. Allow the device to charge completely. A full charge typically takes approximately 2-3 hours. The indicator light will change or turn off when charging is complete.

Important: Ensure the charging cable is securely connected to both the device and the power source for proper charging. The device is waterproof, but the charging port must be dry before connecting the cable.

4.2 Cleaning Before First Use

For hygiene, clean the device thoroughly before its initial use. Refer to the "Maintenance" section for detailed cleaning instructions.

5. Operating Instructions

The Mimi Soft features intuitive controls for easy operation.



Image 5.1: Control buttons for the Mimi Soft.

5.1 Power On/Off

- To turn the device **ON**: Press and hold the power button (usually the central button) for 2-3 seconds until the vibrations begin.
- To turn the device **OFF**: Press and hold the power button for 2-3 seconds until the vibrations stop.

5.2 Adjusting Speeds and Patterns

The Mimi Soft offers 5 speeds and 7 vibration patterns.

- To cycle through **speeds**: While the device is on, short press the '+' or '-' button to increase or decrease the vibration intensity.
- To change **patterns**: While the device is on, short press the pattern button (often indicated by a wave or mode symbol) to switch between the 7 available vibration patterns.

Experiment with different speeds and patterns to find your preferred settings.

Your browser does not support the video tag.

Video 5.2: An official product video demonstrating the features and use of the Je Joue Mimi Soft. This video highlights the device's design, softness, and control options.

6. Maintenance

6.1 Cleaning

Proper cleaning ensures hygiene and prolongs the life of your device.

1. After each use, wash the device with warm water and a mild, toy-safe soap or a specialized toy cleaner.
2. Rinse thoroughly to remove all soap residue.
3. Dry the device completely with a lint-free cloth or allow it to air dry before storing.

4. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone material.

6.2 Storage

Store your Mimi Soft in a clean, dry, and dust-free environment. Keep it away from direct sunlight, extreme temperatures, and other toys made of different materials to prevent potential damage or reactions.

7. Troubleshooting

If you encounter any issues with your Je Joue Mimi Soft, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully (refer to Section 4.1).
Device is not charging.	Loose cable connection; faulty cable or power source.	Ensure the USB cable is firmly connected to both the device and the power source. Try a different USB port or adapter. Ensure the charging port is dry.
Vibrations are weak or inconsistent.	Low battery level.	Recharge the device.
Buttons are unresponsive.	Buttons may be stuck or dirty.	Ensure buttons are clean and free of debris. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact Je Joue customer support for further assistance.

8. Specifications

Brand	Je Joue
Model Number	E24517
Product Dimensions (L x W x H)	5.5 x 1.6 x 6.5 inches
Weight	3.53 ounces
Material	Medical-Grade Silicone
Color	Purple
Power Source	1 Lithium Ion battery (rechargeable via USB)
Features	5 speeds, 7 vibration patterns, Whisper Quiet, Waterproof
Manufacturer	Je Joue
Date First Available	October 10, 2013

9. Warranty and Support

The Je Joue Mimi Soft is covered by a manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty information provided with your purchase or visit the official Je Joue website.

For technical support, product inquiries, or warranty claims, please contact Je Joue customer service through their official website or the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00FTZCK72

More documents and user manuals: **https://manuals.plus/**