McCULLOCH MC1385

McCulloch MC1385 Deluxe Canister Steam Cleaner User Manual

Model: MC1385 | Brand: McCULLOCH

1. Product Overview

The McCulloch MC1385 Deluxe Canister Steam Cleaner is a powerful and versatile cleaning system designed for chemical-free cleaning. It utilizes hot, pressurized steam to effectively remove dirt, grease, grime, and stains from a wide range of surfaces. This system is ideal for various household and automotive cleaning tasks, offering a natural and efficient cleaning solution.



Figure 1.1: The McCulloch MC1385 Deluxe Canister Steam Cleaner and its comprehensive accessory kit.

2. Important Safety Information

WARNING: Read all safety warnings and instructions before operating this appliance. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Always ensure the unit is unplugged from the power outlet before filling, emptying, or performing maintenance.
- Do not leave the appliance unattended when plugged in.
- Do not direct steam at people, animals, or electrical appliances.
- Use only clean water in the tank. Do not add cleaning solutions, perfumes, or other chemicals to the water tank.
- Keep hands and face away from the steam nozzle when operating.
- This product is built to meet U.S. voltage requirements and is warrantied for use only in the U.S.

3. Package Contents

Your McCulloch MC1385 Deluxe Canister Steam Cleaner comes equipped with 23 versatile accessories to handle a variety of cleaning tasks:

- Floor Mop
- Mop Pads (Scrubby & Traditional)
- Nylon Brushes
- Brass Brush
- Angled Nozzle
- Scrub Pad
- Scraper
- Squeegee
- Jet Nozzle
- Large Brush
- Round Scrubby Brushes
- Extension Wands (2)
- Measuring Cup
- Accessory Net
- Swanky Storage Bag



Figure 3.1: Detailed view of the 23-piece professional accessory kit.

4. Setup

1. **Unpack the Unit:** Carefully remove all components from the packaging.
2. **Assemble Handle (if applicable):** Attach the integrated handle to the main unit.
3. **Fill Water Tank:** Unscrew the water tank cap. Using the provided measuring cup, fill the 64-ounce water tank with ordinary tap water. Do not overfill. Securely replace the cap.
4. **Attach Hose and Accessories:** Connect the 7-foot insulated steam hose to the unit. Select the appropriate accessory for your cleaning task and attach it to the end of the hose or extension wand.
5. **Plug In:** Plug the 18-foot power cord into a standard 120V electrical outlet.
6. **Heat Up:** Turn on the power switch. The unit will begin to heat up. The 1500-watt heating element will bring the

water to over 200 degrees Fahrenheit in under 12 minutes. The pressure gauge will indicate when optimal steam pressure is reached (up to 58 PSI).

5. Operating Instructions

Once the unit is heated and ready, you can begin cleaning:

1. **Steam Activation:** Press the steam trigger on the handle to release steam. For continuous steam, engage the optional steam lock.
2. **Variable Steam Control:** Adjust the steam output using the variable steam control dial to suit the surface and cleaning intensity required.
3. **Cleaning Surfaces:** Move the attached accessory slowly over the surface to be cleaned, allowing the steam to penetrate and loosen dirt and grime. For stubborn areas, hold the accessory over the spot for a few seconds.
4. **Wiping:** Immediately wipe the steamed area with a clean cloth to remove loosened dirt and moisture.
5. **Accessory Use:** Utilize specific accessories for different tasks:
    - **Floor Mop:** For large floor areas like tile and laminate.
    - **Brushes (Nylon/Brass):** For scrubbing grout lines, stubborn stains, and hard-to-reach crevices.
    - **Squeegee:** Ideal for windows, mirrors, and other smooth surfaces.
    - **Jet Nozzle:** For concentrated steam on small, tough spots.
6. **Refilling:** If the steam output decreases or stops, the water tank may be low. Turn off and unplug the unit, allow it to cool for a few minutes, and then carefully refill the tank as per the setup instructions.



Figure 5.1: The steam cleaner effectively cleaning a glass surface with the squeegee attachment.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your steam cleaner:

- **Empty Water Tank:** After each use, turn off and unplug the unit. Allow it to cool completely, then carefully empty any remaining water from the tank.
- **Clean Accessories:** Wash accessories with mild soap and water. Mop pads can be machine washed. Ensure all accessories are dry before storing.
- **Decalcification:** Over time, mineral deposits may build up in the water tank. To decalcify, fill the tank with a solution of 50% white vinegar and 50% water. Let it sit for several hours or overnight, then empty and rinse thoroughly. Repeat if necessary.
- **Exterior Cleaning:** Wipe the exterior of the unit with a damp cloth. Do not use abrasive cleaners.

- **Storage:** Store the unit and all accessories in a cool, dry place. The included storage bag is convenient for organizing accessories.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not heated sufficiently; Mineral buildup.	Refill water tank; Allow unit to heat for 12 minutes; Perform decalcification.
Unit not turning on	Not plugged in; Power switch off; Electrical outlet issue.	Ensure unit is securely plugged in; Turn power switch ON; Test outlet with another appliance.
Water leaking from nozzle	Accessory not properly attached; Unit not fully heated.	Ensure accessory is securely attached; Allow unit to reach full operating temperature.

8. Specifications

- **Model:** MC1385
- **Brand:** McCULLOCH
- **Wattage:** 1500 watts
- **Item Weight:** 13 Pounds
- **Tank Volume:** 64 Fluid Ounces
- **Heat Time:** Under 12 minutes
- **Maximum Temperature:** 200 Degrees Fahrenheit
- **Steam Pressure:** Up to 58 PSI (4 bar)
- **Continuous Steam Runtime:** Up to 120 minutes
- **Power Cord Length:** 18 feet
- **Steam Hose Length:** 7 feet

9. Warranty and Support

The McCulloch MC1385 Deluxe Canister Steam Cleaner comes with a**2-year limited warranty**. For warranty claims, technical support, or additional information, please refer to the official McCulloch website or contact their customer service.
An electronic version of this user manual is available for download:User Manual (PDF)

© 2024 McCULLOCH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question