ADESSO IMOUSE_E10

Adesso iMouse E10 User Manual

Vertical Ergonomic Optical 6-Button 2.4 GHz RF Wireless Mouse

Introduction

Welcome to the user manual for your new Adesso iMouse E10. This vertical ergonomic optical mouse is designed to provide a comfortable and efficient computing experience, reducing wrist strain with its unique "handshake" position. Featuring 2.4 GHz RF wireless technology, adjustable DPI settings, and six buttons, the iMouse E10 offers precise control and convenience for various tasks.
Please read this manual thoroughly to ensure proper setup, operation, and maintenance of your device.

What's in the Box

- Adesso iMouse E10 Vertical Ergonomic Optical Mouse
- USB Wireless Receiver
- 2 AAA Batteries



Image: The Adesso iMouse E10 mouse and its USB wireless receiver, shown within its retail packaging.

Product Overview

The Adesso iMouse E10 features a unique vertical design for ergonomic comfort and several functional buttons for enhanced productivity.



Image: A diagram illustrating the button layout of the Adesso iMouse E10, including Left Mouse Click, Scroll Wheel and Middle Button, DPI Switch, Back Button, Forward Button, and Right Mouse Click.

- **Left Mouse Click:** Standard primary click function.
- **Right Mouse Click:** Standard secondary click function.
- **Scroll Wheel and Middle Button:** For scrolling through documents and web pages, and acts as a middle click button.
- **DPI Switch:** Adjusts cursor sensitivity (1000/1500/2000 DPI).
- **Back Button:** Navigates back in web browsers or file explorers.
- **Forward Button:** Navigates forward in web browsers or file explorers.

Setup

1. Installing Batteries

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert the two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.
5. Turn on the mouse using the power switch located on the base of the mouse.

2. Connecting the USB Wireless Receiver

1. Remove the USB wireless receiver from its storage slot on the underside of the mouse.
2. Plug the USB wireless receiver into an available USB port on your computer.
3. Your computer should automatically detect and install the necessary drivers. No additional software installation is required.
4. The mouse is now ready for use.



Image: The Adesso iMouse E10 positioned next to a laptop, illustrating its wireless connectivity up to 30 feet.

Operating Instructions

Ergonomic Design and Grip

The iMouse E10 is designed with a vertical orientation to promote a natural "handshake" position, which helps reduce forearm twisting and wrist strain. Hold the mouse with your hand in this neutral position for optimal comfort.



Image: A hand gripping the Adesso iMouse E10, demonstrating the ergonomic vertical design that supports a natural wrist posture.



Image: An illustration highlighting how the vertical design of the Adesso iMouse E10 helps reduce muscle stress in the wrist and forearm.

Adjusting DPI Sensitivity

The iMouse E10 features a DPI switch button located near the thumb rest. Press this button to cycle through three different DPI (Dots Per Inch) settings: 1000, 1500, and 2000. A higher DPI setting means the cursor moves faster across the screen with less physical mouse movement, which is ideal for large monitors or quick navigation. A lower DPI setting provides more precise control, suitable for detailed work.



Image: A visual representation of the variable DPI switch on the Adesso iMouse E10, showing settings for 800, 1200, and 1600 DPI. Please note that the product specifications state 1000/1500/2000 DPI.

Using Back and Forward Buttons

Two convenient buttons are located on the left side of the mouse, accessible by your thumb. These buttons function as "Back" and "Forward" for quick navigation in web browsers, file explorers, and other applications that support these commands.

Maintenance

Cleaning Your Mouse

To clean your Adesso iMouse E10, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the mouse's finish or internal components. Ensure no liquid enters the mouse.

Battery Replacement

When the mouse's performance degrades or it stops responding, it's likely time to replace the batteries. Follow the "Installing Batteries" steps in the Setup section to replace the two AAA batteries. Always use fresh batteries of the same type.

Battery-Saving Feature

The iMouse E10 includes a battery-saving on/off power switch on its base. To conserve battery life when the mouse is not in use for an extended period, switch it to the "OFF" position.

Troubleshooting

Problem	Solution
Mouse not responding.	Ensure the mouse is turned "ON" using the power switch on its base. Check if the batteries are correctly inserted and have sufficient charge. Replace if necessary. Ensure the USB wireless receiver is securely plugged into a working USB port on your computer. Try a different USB port. Move the mouse closer to the USB receiver to ensure it's within the 30-foot operating range.
Cursor movement is erratic or jumpy.	Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface. The advanced optical sensor works on most glass, wood, marble, and leather surfaces, but highly reflective or uneven surfaces may cause issues. Check battery level and replace if low.
Back/Forward buttons not working.	Ensure the application you are using supports these navigation commands. Restart your computer.

Specifications

Feature	Detail
Model Number	IMOUSE_E10
Connectivity Technology	2.4 GHz RF Wireless
Operating Range	Up to 30 feet (10 meters)
Movement Detection Technology	Optical Sensor
DPI Settings	1000 / 1500 / 2000 DPI (Switchable)
Number of Buttons	6 (Left, Right, Scroll Wheel/Middle, DPI Switch, Back, Forward)
Ergonomics	Vertical, Right Hand Orientation
Power Source	2 x AAA Batteries (Included)
Item Weight	4.8 ounces (approx. 136 grams)
Product Dimensions (LxWxH)	3 x 2.5 x 4.7 inches (approx. 7.6 x 6.35 x 11.9 cm)

Feature	Detail
Color	Black
Hardware Platform	PC; Mac
Operating System Compatibility	Windows® 2000 / XP / Vista / 7 / 8 / 10 or Mac OS X and above

System Requirements

- Available USB Port
- Operating System: Windows® 2000 / XP / Vista / 7 / 8 / 10 or Mac OS X and above

Warranty and Support

For warranty information and technical support, please refer to the official Adesso website or contact Adesso customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.
Manufacturer: Adesso
Brand: ADESSO
Website: www.adesso.com

© 2024 ADESSO. All rights reserved. iMouse E10 User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question