CorningWare Browning Casserole Dish Grill Skillet

CorningWare Amana Radarange Browning Casserole Dish Grill Skillet User Manual

Model: Browning Casserole Dish Grill Skillet

1. Product Overview

The CorningWare Browning Casserole Dish Grill Skillet is specifically designed to facilitate browning of foods within a microwave oven, particularly for models like the Amana Radarange. This unique dish features a special browning element integrated into its base, allowing for a crisp, browned finish typically associated with conventional cooking methods, directly from your microwave.

This product is constructed from durable glass and features a distinctive white finish with a blue house and scene design. It is intended for use in microwave ovens to achieve browning results for various food items.



Image of the CorningWare Browning Casserole Dish, showing its white surface and the distinctive blue house and scene artwork. This dish is designed for microwave browning.

2. Setup

1. **Unpacking:** Carefully remove the browning dish from its packaging. Inspect the dish for any signs of damage. If any damage is observed, do not use the product and contact the retailer.
2. **Initial Cleaning:** Before first use, wash the browning dish thoroughly by hand using warm, soapy water. Rinse completely and dry with a soft cloth. Refer to the "Maintenance and Care" section for detailed cleaning instructions.
3. **Placement:** Ensure your microwave oven's turntable (if applicable) is clean and properly seated. Place the browning dish centrally on the turntable or microwave floor for even heating.

3. Operating Instructions

This browning dish is designed to achieve a browned, seared finish on foods when used in a microwave oven. Follow these steps for optimal results:

1. **Preheating the Dish:** Place the empty browning dish into your microwave oven. Close the microwave door. Set the microwave to its highest power level and heat the empty dish for the recommended time, typically 3 to 5 minutes, or as specified in your recipe. The exact time may vary depending on your microwave's wattage and the desired browning level. The dish's browning element will become very hot during this process.
2. **Adding Food:** Carefully remove the preheated dish from the microwave using oven mitts or heat-resistant gloves. The dish will be extremely hot. Add a small amount of cooking oil (if desired) to the hot surface, then immediately place your food item (e.g., meat, poultry, vegetables) onto the browning surface.

3. **Cooking and Browning:** Return the dish with food to the microwave. If your dish came with a lid, place it on top. Cook according to your recipe's instructions for microwave browning. Cooking times will vary based on the food type, quantity, and desired doneness. Monitor the food closely to prevent overcooking or burning.
4. **Removal:** Once cooking is complete, carefully remove the hot dish from the microwave using oven mitts. Serve food immediately.

Important Safety Note: The browning surface of the dish becomes extremely hot during operation. Always use appropriate heat protection when handling the dish. Avoid direct contact with the hot surface.

4. Maintenance and Care

Proper care will extend the life and performance of your CorningWare Browning Casserole Dish.

- **Hand Wash Only:** This product is not dishwasher safe. Wash by hand using warm, soapy water and a non-abrasive sponge or cloth.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or metal utensils, as these can scratch or damage the browning surface and the dish's finish.
- **Stubborn Food Residue:** For baked-on food, allow the dish to soak in warm, soapy water for a period before gently scrubbing. A plastic scraper may be used for stubborn residue.
- **Drying:** Dry the dish thoroughly after washing to prevent water spots.
- **Storage:** Store the dish in a dry place where it is protected from impacts.

5. Troubleshooting

- **Food Not Browning:**
  - Ensure the dish was preheated for the recommended time. Insufficient preheating will result in poor browning.
  - Verify your microwave is operating at full power.
  - Check that the food item is in direct contact with the browning surface.
- **Food Sticking to Dish:**
  - Ensure a small amount of cooking oil was applied to the hot browning surface before adding food.
  - Avoid using metal utensils which can damage the non-stick properties of the browning surface.
- **Dish Difficult to Clean:**
  - Soak the dish in warm, soapy water immediately after use to loosen food residue.
  - Use a plastic scraper for stubborn, baked-on food.

6. Specifications

Brand	CorningWare
Model	Browning Casserole Dish Grill Skillet
Material	Glass (with integrated browning element)
Color	White with Blue House & Scene
Dimensions (L x W x H)	11.5 x 9.8 x 2.5 inches (approximate)
Item Weight	0.01 Ounces *(Note: This weight seems unusually low and may be a data entry error. Actual weight will be higher.)*

Product Care	Hand Wash Only
Dishwasher Safe	No
Oven Safe	Yes *(for conventional ovens, but primarily designed for microwave browning)*

7. Warranty and Support

Specific warranty information for this CorningWare Browning Casserole Dish is not provided within the product details. For inquiries regarding warranty coverage, product support, or replacement parts, please refer to the original purchase documentation or contact the retailer from whom the product was acquired. You may also visit the official CorningWare website for general product information and customer service contacts.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question