Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ HCDZ-X02517

HCDZ Universal Replacement Remote Control User Manual

Model: HCDZ-X02517

Introduction

Thank you for choosing the HCDZ Universal Replacement Remote Control. This remote is designed to function as a direct replacement for your original remote control for various Samsung 3D Blu-ray DVD Home Theater Systems, including models HT-C5500/XAC, HT-C5530, and HT-C5550. It provides essential control over your home theater system without the need for complex programming.
Key features of this replacement remote include:

- Infrared (IR) replacement remote control.
- No programming required; functions immediately upon battery insertion.
- Easy to use with standard button controls.

Setup

To begin using your HCDZ replacement remote control, follow these simple steps for battery installation:

1. **Locate the Battery Compartment:** Turn the remote control over. The battery compartment is located on the back of the unit.
2. **Open the Battery Cover:** Gently slide the battery compartment cover downwards or in the direction indicated by an arrow (if present) to open it.
3. **Insert Batteries:** Insert two (2) AAA batteries into the compartment. Ensure that the positive (+) and negative (-) terminals of the batteries match the polarity indicators inside the compartment.
4. **Close the Battery Cover:** Slide the battery compartment cover back into place until it clicks securely.

Once batteries are correctly installed, the remote control is ready for immediate use. No additional programming or setup is required.



Image 1: Rear view of the remote control showing the battery compartment cover.



Image 2: Remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

Operating Instructions

This remote control operates using infrared (IR) technology. For optimal performance, ensure a clear line of sight between the remote control and the IR receiver on your Samsung Home Theater System.

- **Point and Press:** Aim the remote control directly at your Samsung Home Theater System.
- **Button Functions:** Each button on the remote corresponds to a specific function on your home theater system. Refer to your original Samsung Home Theater System manual for detailed information on specific button functionalities if needed.
- **Operating Range:** The remote has a maximum operating range of approximately 10 meters (33 feet). Performance may vary depending on environmental factors and battery strength.

Maintenance

Proper care and maintenance will ensure the longevity of your remote control.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Cleaning:** To clean the remote, wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive

materials, as these can damage the remote's surface or internal components.

- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

Troubleshooting

If you encounter issues with your remote control, please refer to the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the home theater system's IR receiver.
  - Ensure you are within the operating range (approximately 10 meters).
- **Specific Functions Not Working:**
  - Verify that the function you are trying to use is supported by your specific Samsung Home Theater System model.
  - Some advanced functions may require the original remote or direct interaction with the device.

If the issue persists after following these steps, please contact the seller for further assistance.

Specifications

Brand	HCDZ
Model Number	HCDZ-X02517
Compatible Devices	Samsung HT-C5500/XAC, HT-C5530, HT-C5550 3D Blu-ray DVD Home Theater Systems
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Meters (approx. 33 feet)
Batteries Required	2 x AAA (not included)
Special Feature	Universal Replacement

Warranty and Support

As a universal replacement remote control, specific warranty details may vary. Please refer to the purchase agreement or contact the seller directly for information regarding warranty coverage and support for this product.
For technical assistance or inquiries, please reach out to the retailer or seller from whom you purchased this HCDZ remote control.

© 2024 HCDZ. All rights reserved. Samsung is a registered trademark of Samsung Electronics Co., Ltd.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00GWF6ZBU

More documents and user manuals: **https://manuals.plus/**