Spinbrush PPAX1228145

Spinbrush Pro Series Daily Clean Powered Toothbrush User Manual

Brand: Spinbrush | **Model:** PPAX1228145

Introduction

Thank you for choosing the Spinbrush Pro Series Daily Clean Powered Toothbrush. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new toothbrush. Please read it thoroughly before first use and keep it for future reference.

Product Overview

The Spinbrush Pro Series Daily Clean Powered Toothbrush is designed to provide a superior cleaning experience compared to manual toothbrushes. Its patented dual-action brush head and advanced features contribute to effective plaque removal and improved oral hygiene.

Key Features:

- **Dual-Action Brush Head:** Features two moving parts for deep cleaning between teeth and along the gum line. This includes an oscillating spinner and a sliding plate (scrubber).
- **Color-Wear Bristles:** Bristles fade over approximately 3 months, indicating when it's time to replace the brush head for optimal cleaning performance.
- **Soft-Switch Power Buttons:** Designed for easy operation (on/off) and to help prevent water from entering the brush handle.
- **Battery Powered:** Operates on 2 AA batteries (included), offering convenience and portability.
- **Brushing Timer:** Assists in ensuring adequate brushing time.



Image: The Spinbrush Pro Series Daily Clean toothbrush is engineered to remove up to 70% more plaque in hard-to-reach areas compared to a manual toothbrush.



Image: The new and improved power switch on the Spinbrush Pro Series Daily Clean helps prevent water from leaking into the brush handle, enhancing durability.

Setup

1. Unboxing and Initial Inspection:

Carefully remove the toothbrush and its components from the packaging. Inspect the toothbrush for any visible damage. Ensure all parts are present.



Image: The Spinbrush Pro Series Daily Clean toothbrush as it appears in its retail packaging.

2. Battery Installation:

1. Twist the bottom cap of the toothbrush handle counter-clockwise to open the battery compartment.
2. Insert two (2) AA Duracell batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Replace the bottom cap and twist clockwise until securely closed.



Image: Packaging detail indicating that batteries are included and replaceable, along with ergonomic design features.

Operating Instructions

1. **Wet the Brush Head:** Before applying toothpaste, wet the bristles of the brush head under running water.
2. **Apply Toothpaste:** Apply a pea-sized amount of your preferred toothpaste to the brush head.
3. **Power On:** Press the top power button (usually marked with a larger circle or 'on' symbol) to turn on the toothbrush.
4. **Brushing Technique:** Guide the brush head slowly from tooth to tooth, allowing the dual-action bristles to clean each surface. Do not scrub aggressively. Brush all surfaces of your teeth (outer, inner, and chewing surfaces) and along the gum line.
5. **Brushing Duration:** Dentists recommend brushing for at least two minutes. The built-in brushing timer can help you track this.
6. **Power Off:** Press the bottom power button (usually marked with a smaller circle or 'off' symbol) to turn off the toothbrush after brushing.

Maintenance

1. Cleaning the Toothbrush:

- After each use, rinse the brush head thoroughly under running water to remove any toothpaste residue and debris.
- Wipe the handle with a damp cloth. Do not submerge the entire handle in water.
- Store the toothbrush upright in a clean, dry place.

2. Brush Head Replacement:

The Spinbrush Pro Series Daily Clean features Color-Wear bristles that fade over time. Replace your brush head when the blue bristles fade to white, or every 3 months, whichever comes first. This ensures optimal cleaning performance and hygiene.

1. To remove the old brush head, firmly pull it straight up from the handle.
2. To attach a new brush head, align it with the shaft and push down firmly until it clicks into place.

3. Battery Replacement:

When the toothbrush performance diminishes, it's time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section. Always use new AA Duracell batteries for best performance.

Troubleshooting

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Dead or incorrectly installed batteries.	Check battery orientation or replace with new AA batteries.
Weak brushing action.	Low battery power.	Replace batteries.
Brush head does not spin effectively.	Old brush head or debris caught in mechanism.	Replace brush head. Clean any visible debris around the brush head base.

Specifications

Feature	Detail
Model Number	PPAX1228145
Power Source	2 AA Batteries (Duracell recommended)
Product Dimensions	9.5 x 2 x 1.13 inches
Item Weight	0.28 Pounds (approx. 4.48 ounces)
Bristle Material	Nylon
Handle Material	Plastic
Operation Mode	Automatic, Spin Motion
Special Features	Brushing Timer, Dual-Action Brush Head, Color-Wear Bristles
Included Components	Battery

Safety Information

- Not intended for children under 3 years of age.
- Consult your dentist or physician before using if you have severe gum problems or have undergone oral surgery.
- Do not immerse the product in water.
- Replace brush head every 3 months or sooner if bristles are splayed or worn.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Warranty and Support

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Arm & Hammer Spinbrush website. The manufacturer is Arm & Hammer.
Manufacturer: Arm & Hammer

© 2024 Spinbrush. All rights reserved.