H.Koenig RP418

H.Koenig RP418 4-in-1 Raclette Grill User Manual

Model: RP418 | Brand: H.Koenig

Introduction

The H.Koenig RP418 is a versatile 4-in-1 raclette grill designed for preparing meals for up to 8 people. This appliance offers multiple cooking options through its interchangeable plates: a natural stone plate for healthy grilling, a traditional grill plate for various foods, and a mini pancake plate for desserts or breakfast items. Its adjustable thermostat ensures precise temperature control for optimal cooking results.

Important Safety Instructions

To ensure safe operation and prevent damage, please read and follow these instructions carefully:

- Always place the appliance on a stable, flat, and heat-resistant surface.
- Do not immerse the appliance base, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Unplug the appliance from the power outlet when not in use, before cleaning, or if a malfunction occurs.
- Do not operate the appliance with a damaged cord or plug, or if it has been dropped or damaged in any way. Contact qualified service personnel for repair.
- Ensure proper ventilation around the appliance during use.
- The cooking plates and raclette pans become very hot during operation. Use oven mitts or appropriate utensils to avoid burns.
- Do not use abrasive cleaning agents or harsh scrubbers on non-stick surfaces.

Package Contents

Verify that all components are present upon unpacking:

- 1 x H.Koenig RP418 Raclette Grill Base
- 1 x Natural Stone Plate
- 1 x Grill Plate (with flat section)
- 1 x Mini Pancake Plate

- 8 x Non-stick Raclette Pans



Image: The H.Koenig RP418 Raclette Grill base shown with its three interchangeable cooking plates: natural stone, grill, and mini pancake plate.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Remove any protective films or stickers.
2. **Clean:** Before first use, wash the cooking plates and raclette pans with warm, soapy water. Rinse thoroughly and dry completely. Wipe the grill base with a damp cloth.
3. **Placement:** Place the grill base on a stable, level, and heat-resistant surface, ensuring adequate space around the appliance for ventilation.

4. **Attach Plate:** Select the desired cooking plate (natural stone, grill, or mini pancake) and place it securely on top of the heating element of the grill base.
5. **Connect Power:** Ensure the temperature control knob is set to 'MIN' before plugging the power cord into a grounded electrical outlet.



Image: The H.Koenig RP418 Raclette Grill with the grill plate in position, ready for use. The raclette pans are visible below the main cooking surface.

Operating Instructions

1. **Preheat:** After setup, turn the temperature control knob from 'MIN' to the desired setting (e.g., 'MAX' for faster preheating). The indicator light will illuminate, signaling that the appliance is heating. Allow 10-15 minutes for the plate to reach optimal cooking temperature.
2. **Using the Grill Plate:** Place food directly onto the grill plate. The ribbed section is ideal for searing meats and vegetables, while the flat section can be used for delicate items.
3. **Using the Natural Stone Plate:** For healthier cooking, place food directly onto the preheated natural stone. This plate

retains heat well and cooks food evenly. Note that the stone may take slightly longer to heat up.

4. **Using the Mini Pancake Plate:** Once heated, pour pancake batter into the circular molds. Cook until golden brown, then flip. This plate can also be used for small omelets or blinis.
5. **Using Raclette Pans:** Place cheese, vegetables, or other ingredients into the individual non-stick raclette pans. Slide the pans under the heating element below the main cooking plate to melt cheese or warm food.
6. **Adjust Temperature:** Use the thermostat knob to adjust the heat as needed during cooking. The indicator light will cycle on and off to maintain the set temperature.
7. **Power Off:** When finished cooking, turn the temperature control knob back to 'MIN' and unplug the appliance from the power outlet. Allow the appliance to cool completely before cleaning or storing.



Image: The H.Koenig RP418 Raclette Grill in operation, demonstrating the grill plate cooking skewers and vegetables, while raclette pans are used underneath.



Image: The H.Koenig RP418 Raclette Grill with the mini pancake plate, featuring six circular molds for preparing small pancakes or similar items.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your raclette grill.

1. **Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Remove Plates and Pans:** Carefully remove the cooking plate and all raclette pans.
3. **Clean Plates and Pans:** Wash the cooking plates and raclette pans with warm, soapy water using a soft sponge. For stubborn food residues, soak them in warm water for a few minutes before cleaning. Rinse thoroughly and dry completely. Do not use abrasive cleaners or metal scouring pads, as these can damage the non-stick coating and natural stone surface.
4. **Clean Base:** Wipe the exterior of the grill base with a damp cloth. Do not use abrasive cleaners. Never immerse the base in water or any other liquid.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance. Store in a cool, dry place.



Image: A detailed view of the grill plate, highlighting its non-stick surface and ribbed sections for grilling.

Troubleshooting

If you encounter issues with your H.Koenig RP418, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not heat up.	Not plugged in; power outlet malfunction; temperature knob set to 'MIN'.	Ensure the appliance is securely plugged into a working outlet. Turn the temperature knob to a higher setting. Check your circuit breaker.
Food cooks unevenly.	Insufficient preheating time; uneven food distribution.	Allow sufficient preheating time (10-15 minutes). Distribute food evenly across the cooking surface.

Problem	Possible Cause	Solution
Smoke or unusual odor during first use.	Residual manufacturing oils burning off.	This is normal for first use. Ensure good ventilation. If smoke persists after initial use, unplug and contact support.

Specifications

Brand: H.Koenig

Model Number: RP418

Power: 1500 Watts

Voltage: 230.0 Volts

Material: Stainless Steel (base), Natural Stone, Non-stick coating

Dimensions (L x W x H): 44.6 x 27.7 x 14 cm

Item Weight: 1.8 Kilograms

Features: Temperature Control, Removable Surface, 8 Non-stick Raclette Pans

Color: Red

Warranty and Support

The H.Koenig RP418 Raclette Grill comes with an extended **2-year warranty**. This warranty covers manufacturing defects under normal use conditions.
For warranty claims, technical assistance, or spare parts, please contact H.Koenig customer support. An authorized after-sales service (SAV) workshop is available in France to provide support and repairs.
Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question