John Deere 3140

John Deere 3140 Tractor Operator's Manual

For Serial Numbers 0-429,999

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of the John Deere 3140 Tractor. It is designed to assist operators in understanding the tractor's features, controls, and recommended procedures to ensure optimal performance and longevity. Please read this manual thoroughly before operating the tractor.




Image Description: The image displays the yellow and black cover of the "John Deere 3040 & 3140 Tractors Operator's

Manual". The title "John Deere" is at the top, followed by "MODEL: 3040 & 3140 Tractors S/N 0-429,999". Below this, in a black band, is "OPERATOR'S MANUAL" with a partial illustration of a hand on a steering wheel. The bottom of the cover includes a disclaimer about the manual being produced by Jensales Inc. without authorization from John Deere, and a product code JD-O-OML34771.

Safety Information

Operating a tractor requires careful attention to safety to prevent injury or damage. Always adhere to the following safety guidelines:

- Read and understand all safety decals on the tractor.
- Wear appropriate personal protective equipment (PPE), including safety glasses, hearing protection, and sturdy footwear.
- Ensure all guards and shields are in place before operation.
- Never allow unauthorized personnel to operate the tractor.
- Be aware of your surroundings and maintain a safe distance from bystanders and obstacles.
- Always engage the parking brake when the tractor is stationary.
- Do not operate the tractor under the influence of alcohol or drugs.

Setup

Before starting the tractor, perform the following checks:

1. **Fluid Levels:** Check engine oil, coolant, hydraulic fluid, and fuel levels. Replenish as necessary.
2. **Tire Pressure:** Verify tire pressures are within recommended specifications.
3. **Battery:** Inspect battery terminals for corrosion and ensure connections are secure.
4. **Lights and Signals:** Confirm all lights, turn signals, and warning lights are functional.
5. **Attachments:** If attaching implements, ensure they are securely connected and PTO shafts are properly guarded.

Operating Instructions

Starting the Engine

1. Ensure the transmission is in neutral and the parking brake is engaged.
2. Turn the ignition key to the "ON" position and wait for indicator lights to cycle.
3. Turn the key to the "START" position. Release the key once the engine starts.
4. Allow the engine to warm up for a few minutes before engaging in heavy work.

Driving the Tractor

- Depress the clutch pedal fully.
- Select the desired gear.
- Gradually release the clutch pedal while simultaneously increasing engine RPM with the throttle.
- Use the brake pedals for slowing or stopping. For emergency stops, depress both brake pedals and the clutch simultaneously.

Maintenance

Regular maintenance is crucial for the longevity and reliable operation of your John Deere 3140 Tractor. Refer to the maintenance schedule for detailed intervals.

Routine Maintenance Schedule (General)

Interval	Task
Daily / Every 10 Hours	Check engine oil, coolant, hydraulic fluid, and tire pressure. Inspect for leaks.
Every 50 Hours	Lubricate grease points. Check battery electrolyte level.
Every 250 Hours	Change engine oil and filter. Inspect air filter.
Every 500 Hours	Replace fuel filter. Check fan belt tension.

Always use genuine John Deere parts and recommended lubricants for optimal performance and to maintain warranty validity.

Troubleshooting

This section addresses common issues you might encounter with your John Deere 3140 Tractor.

- **Engine Fails to Start:**
  - Check fuel level.
  - Ensure battery is charged and connections are clean.
  - Verify transmission is in neutral and parking brake is engaged.
- **Loss of Power:**
  - Inspect fuel filter for clogging.
  - Check air filter for restrictions.
  - Ensure proper fuel quality.
- **Hydraulic System Malfunction:**
  - Check hydraulic fluid level.
  - Inspect for leaks in hydraulic lines.
  - Ensure hydraulic pump is functioning.

For complex issues, consult an authorized John Deere service technician.

Specifications

Key specifications for the John Deere 3140 Tractor (Serial Numbers 0-429,999):

- **ASIN:** B00HQN3JF2
- **Publisher:** Jensales
- **Language:** English
- *Note: Detailed engine, transmission, and dimension specifications are typically found within the full manual.*

Warranty and Support

For specific warranty information regarding your John Deere 3140 Tractor, please refer to the documentation provided at the time of purchase or contact an authorized John Deere dealer. This manual, published by Jensales, is an independent reproduction and does not imply direct endorsement or warranty coverage from John Deere.

For technical support or service, it is recommended to contact an authorized John Deere service center or a qualified tractor mechanic.

Disclaimer: This manual is produced by Jensales Inc. without the authorization of John Deere or its successors. John Deere and its successors are not responsible for the quality or accuracy of this manual. Trademarks and trade names contained and used herein are those of others and are used here in a descriptive sense to refer to the products of others.

© 2023 John Deere 3140 Tractor Operator's Manual (Jensales Edition)