Schick 1558

Schick Hydro 5 Styling Razor & Trimmer User Manual

Model: 1558

1. Introduction

The Schick Hydro 5 Styling Razor & Trimmer is an all-in-one grooming tool designed for shaving, trimming, and edging. This device combines a 5-blade razor with hydrating gel pools and a built-in power trimmer with adjustable comb settings, offering versatility for various grooming needs. This manual provides essential information for the safe and effective use, maintenance, and care of your Schick Hydro 5 Styling Razor & Trimmer.



Image: The Schick Hydro 5 Styling Razor and Trimmer, showcasing its dual functionality.

2. Safety Information

Please read all safety instructions before using this product. Failure to follow these instructions may result in injury or damage to the device.

- **Water Resistance:** The device is designed to be waterproof for use in the shower. However, do not submerge the device in water for extended periods.
- **Battery Safety:** Use only the specified AAA battery. Do not mix old and new batteries, or different types of batteries. Remove batteries if the device will not be used for a long period. Dispose of batteries properly.
- **Blade Handling:** Blades are sharp. Handle razor cartridges with care to avoid cuts. Keep out of reach of children.
- **Damage:** Do not use the device if the razor head or trimmer comb is damaged. Contact customer support for replacement parts.
- **Cleaning:** Always rinse the device under running water. Do not use harsh chemicals or abrasive cleaners.

3. Product Components

The Schick Hydro 5 Styling Razor & Trimmer consists of the following main parts:

- **5-Blade Razor Cartridge:** Features five blades with Skinguards and hydrating gel pools for a close shave.
- **Flip-Back Trimmer:** Located at the top of the razor cartridge for precise edging.
- **Power Trimmer:** Integrated electric trimmer with an adjustable comb for beard and body hair.
- **Power Button:** Activates the electric trimmer.
- **Battery Compartment:** Located at the bottom of the handle, housing one AAA battery.



Image: The Schick Hydro 5 Styling Razor and Trimmer, showing both the razor and trimmer ends.

4. Setup

Before first use, install the battery and ensure the razor cartridge is properly attached.

4.1 Battery Installation

1. Twist the bottom cap of the handle counter-clockwise to open the battery compartment.
2. Insert one (1) AAA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Replace the bottom cap by twisting it clockwise until securely closed.

4.2 Attaching the Razor Cartridge

The razor cartridge comes pre-attached. To replace it, align the new cartridge with the razor handle and push until it clicks into place.

5. Operating Instructions

The Schick Hydro 5 Styling Razor & Trimmer offers three primary functions: shaving, trimming, and edging.

5.1 Shaving

For a close and comfortable shave:

1. Wet your skin and apply shaving gel or foam.
2. Use the 5-blade razor head, gliding it gently over your skin in the direction of hair growth. The hydrating gel pools will activate upon contact with water.
3. Rinse the razor head frequently during shaving to prevent clogging.



Image: A close-up view of the Schick Hydro 5-blade razor head.

5.2 Trimming

To trim beard or body hair to a desired length:

1. Ensure your skin and hair are dry for best trimming results.
2. Press the power button on the handle to activate the trimmer.
3. Adjust the comb to one of the three available length settings by sliding it up or down.
4. Hold the trimmer flat against your skin and move it against the direction of hair growth.



Image: A close-up of the adjustable power trimmer on the Schick Hydro 5.



Image: The trimmer comb showing the three adjustable beard length settings.

5.3 Edging

For precise lines and hard-to-reach areas:

1. Flip back the razor head to expose the precision trimmer blade.
2. Use short, controlled strokes to define edges around your beard, sideburns, or under the nose.
3. Rinse the trimmer after use.

6. Maintenance

Proper maintenance ensures the longevity and performance of your device.

6.1 Cleaning

1. After each use, rinse the razor head and trimmer under running water to remove hair and debris.

2. Shake off excess water and allow the device to air dry.
3. Do not use towels or cloths to dry the blades, as this may damage them.

6.2 Razor Cartridge Replacement

Replace the razor cartridge when the hydrating gel pools are depleted or when you experience discomfort during shaving. To replace:

1. Press the release button on the back of the razor head to detach the used cartridge.
2. Align a new Schick Hydro 5 cartridge with the handle and push until it clicks into place.

6.3 Battery Replacement

Replace the AAA battery when the trimmer's power weakens or stops working. Follow the battery installation steps in Section 4.1.

7. Troubleshooting

If you encounter issues with your device, refer to the following common solutions:

Problem	Possible Cause	Solution
Trimmer not turning on.	Dead or incorrectly installed battery.	Replace the AAA battery or ensure it is installed with correct polarity.
Poor trimming performance.	Trimmer blades are clogged with hair.	Clean the trimmer head thoroughly under running water. Ensure hair is dry before trimming.
Razor pulling or causing irritation.	Dull blades or depleted hydrating gel.	Replace the razor cartridge with a new one. Ensure skin is properly lubricated with shaving gel/foam.

8. Specifications

- **Model Number:** 1558
- **Power Source:** 1 x AAA Battery (included)
- **Number of Blades:** 5
- **Product Dimensions:** 1.3 x 3.54 x 7.03 inches
- **Product Weight:** 3.53 ounces
- **Water Resistance:** Yes (suitable for shower use)
- **Handle Material:** Plastic



Image: Packaging dimensions for the Schick Hydro 5 Styling Razor.

9. Warranty Information

Warranty information for the Schick Hydro 5 Styling Razor & Trimmer is typically provided with the product packaging or can be found on the official Schick website. Please retain your proof of purchase for any warranty claims.

10. Support

For further assistance, product inquiries, or to purchase replacement parts, please visit the official Schick website or contact their customer service department.
Official Website: www.schick.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question