Witonics W-A-5469a-5ea

Witonics T8A 250V Axial Ceramic Slow Blow Fuses Instruction Manual

Model: W-A-5469a-5ea

1. Introduction

This manual provides essential information for the safe and effective use of Witonics T8A 250V Axial Ceramic Slow Blow Fuses. These fuses are designed to protect electrical circuits from overcurrent conditions, preventing damage to sensitive components and ensuring the safety of your equipment. Understanding the characteristics and proper handling of these fuses is crucial for their optimal performance.

2. Safety Information

Always prioritize safety when working with electrical components. Failure to follow these guidelines can result in electric shock, fire, or damage to equipment.

- **Disconnect Power:** Always ensure that the power supply to the circuit is completely disconnected before inspecting, removing, or installing fuses.
- **Verify Ratings:** Use only fuses with the exact specified voltage and amperage ratings as the original or as recommended by the equipment manufacturer. Using an incorrect fuse rating can lead to inadequate protection or premature failure.
- **Handle with Care:** Fuses are delicate. Avoid dropping or bending the leads excessively.
- **Professional Installation:** If you are unsure about any aspect of fuse replacement or circuit repair, consult a qualified electrician or technician.
- **Material Safety:** These fuses contain ceramic material. While generally safe, avoid breaking the fuse body.

3. Product Overview

The Witonics T8A 250V Axial Ceramic Slow Blow Fuse is a time-delay fuse designed for through-hole mounting in various electronic applications. Its ceramic body provides excellent thermal and electrical insulation.



Figure 1: A single Witonics T8A 250V axial ceramic slow blow fuse. It features a white ceramic body with metallic end caps and axial leads extending from both ends for through-hole mounting.

Key Features:

- **Type:** Axial Ceramic Fuse
- **Dimensions:** 5x20mm (approximately 3/16 inch x 3/4 inch)
- **Current Rating:** 8 Amperes (8A)
- **Voltage Rating:** 250 Volts (250V)
- **Characteristic:** Slow Blow (Time Delay)
- **Material:** Ceramic
- **Mounting:** Through-Hole Mount

4. Installation and Setup

Follow these steps for safe and proper installation of the fuse:

1. **Power Disconnection:** Before beginning, ensure the equipment is turned off and completely disconnected from its power source. Verify with a voltage tester if necessary.
2. **Locate Fuse:** Identify the fuse holder or the location of the fuse on the circuit board.
3. **Remove Old Fuse:** Carefully remove the blown or faulty fuse. For through-hole mounted fuses, desoldering may be required.
4. **Inspect Fuse Holder/Area:** Check the fuse holder or circuit board for any signs of damage, corrosion, or debris. Clean if necessary.
5. **Insert New Fuse:** Insert the new Witonics T8A 250V 8A Slow Blow fuse into the designated position. For through-hole mounting, ensure the leads are correctly aligned with the holes and solder them securely if required.
6. **Verify Connection:** Ensure the fuse is seated firmly and makes good electrical contact.
7. **Restore Power:** Once the fuse is securely installed and all connections are verified, reconnect the power

supply and test the equipment.

5. Operating Principles (Slow Blow Fuses)

A slow blow, or time-delay, fuse is designed to withstand temporary current surges that are common in certain electrical equipment, such as motors or power supplies, during startup (inrush current). Unlike fast-acting fuses that blow almost instantly upon exceeding their rated current, slow blow fuses have a built-in delay mechanism. This allows them to tolerate brief overcurrents without opening the circuit, but they will still open and protect the circuit if a sustained overload or short circuit occurs.

This characteristic makes them ideal for applications where momentary current spikes are normal and do not indicate a fault, but continuous overcurrent needs to be interrupted.

6. Maintenance

Fuses are generally maintenance-free components. However, periodic checks can help ensure continued circuit protection:

- **Visual Inspection:** If equipment malfunctions, visually inspect the fuse for signs of a blown element (e.g., darkened glass, broken wire inside). For ceramic fuses, a multimeter is often required to test continuity.
- **Continuity Test:** With power disconnected, use a multimeter to check the continuity of the fuse. A good fuse will show continuity (very low resistance), while a blown fuse will show an open circuit (infinite resistance).
- **Replacement:** Always replace a blown fuse with an identical Witonics T8A 250V 8A Slow Blow fuse to maintain the intended circuit protection.

7. Troubleshooting

If a fuse blows, it indicates an underlying issue in the circuit. Simply replacing the fuse without addressing the root cause may lead to repeated fuse failures.

- **Fuse Blows Immediately After Replacement:** This strongly suggests a direct short circuit in the equipment. Disconnect power immediately and investigate for damaged wires, faulty components, or incorrect wiring.
- **Fuse Blows After Some Operating Time:** This typically indicates a sustained overload condition or an intermittent fault. The equipment might be drawing more current than it should, or a component is failing under load.
- **Equipment Still Not Working After Fuse Replacement:** If the fuse is confirmed to be good but the equipment remains non-functional, the problem lies elsewhere in the circuit, such as a faulty power supply, damaged component, or wiring issue. Further diagnosis by a qualified technician is recommended.

8. Specifications

Specification	Value
Part Number	TTL-A-5469a-5ea
Item Model Number	W-A-5469a-5ea
Material	Ceramic
Voltage Rating	250 Volts
Amperage Capacity	8 Amps

Specification	Value
Item Package Quantity	5
Mounting Type	Through-Hole Mount
Dimensions	5x20mm (3/16 inch x 3/4 inch)
Fuse Type	Slow Blow (Time Delay)

9. Warranty and Support

For specific warranty information regarding your Witonics T8A 250V Axial Ceramic Slow Blow Fuses, please refer to the product packaging or contact the seller directly. Witonics is committed to providing quality products and support.

For further assistance or inquiries, you may visit the official Witonics store or contact their customer service through the platform where the product was purchased.

Witonics Store: https://www.amazon.com/stores/Witonics/page/0D359E50-77BA-4C63-9CCD-9D1EC39512A8

© 2025 Witonics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question