Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Reizen AX-AY-ABHI-61040

Reizen Big LCD Display Talking Alarm Clock User Manual

Model: AX-AY-ABHI-61040

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Reizen Big LCD Display Talking Alarm Clock. Please read this manual thoroughly before using the device to ensure proper function and longevity.
The Reizen Big LCD Display Talking Alarm Clock is designed to provide clear time announcements and an easy-to-read digital display, making it suitable for users who may benefit from audible time information.

Package Contents

- Reizen Big LCD Display Talking Alarm Clock
- User Manual (this document)

Note: Two AA batteries are required for operation and are not included in the package.

Product Overview

Familiarize yourself with the clock's components and controls.



Image 1: Front View of the Alarm Clock. This image shows the front of the Reizen Big LCD Display Talking Alarm Clock. It features a large digital LCD display showing "10:10 PM". Above the display, the brand "REIZEN" is visible. On the top surface, there are three small buttons labeled "HOUR", "MIN", and "TIME", along with a larger central speaker grille and a button labeled "ALARM" on the right side. The overall color is silver/grey.



Image 2: Bottom View of the Alarm Clock. This image displays the underside of the Reizen Big LCD Display Talking Alarm Clock. It shows the battery compartment cover, which requires two "AA" size batteries. Above the battery compartment, there are three slide switches: "VOLUME" (with HI/LOW settings), "LOCK/SET", and "ALARM" (with OFF/ON settings). The model number "LC802T" is printed, along with "BIG LCD DISPLAY TALKING ALARM CLOCK" and "MADE IN CHINA". Two rubber feet are visible at the top.

Controls and Features:

- **Large LCD Display:** Provides clear digital time readout.
- **Talk Button:** Located on the top, activates voice announcement of the current time.
- **HOUR Button:** Used for setting the hour.
- **MIN Button:** Used for setting the minute.
- **TIME Button:** Used to enter time setting mode.
- **ALARM Button:** Used to enter alarm setting mode.
- **Snooze Button:** Activates a 10-minute snooze function when the alarm sounds. (Often the Talk button doubles as snooze)
- **VOLUME Switch (Hi/Lo):** Adjusts the volume of voice announcements and alarms.

- **LOCK/SET Switch:** Prevents accidental changes to time and alarm settings when in "LOCK" position.
- **ALARM ON/OFF Switch:** Toggles the alarm function.
- **Blue Backlight:** Illuminates the display for visibility in low light.
- **Hourly Announcement:** Can be set to announce the time every hour.
- **Alarm Sounds:** Choice of beep, cuckoo, or rooster sounds.

Setup

1. Battery Installation

1. Turn the clock over to access the battery compartment on the bottom.
2. Remove the battery compartment cover.
3. Insert two (2) AA batteries, ensuring correct polarity (+ and -).
4. Replace the battery compartment cover securely.

Important: Use only fresh AA alkaline batteries. Do not mix old and new batteries or different types of batteries.

Operating Instructions

1. Setting the Time

1. Locate the **LOCK/SET** switch on the bottom of the clock. Slide it to the **SET** position.
2. Press the **TIME** button on the top of the clock. The display will flash.
3. Press the **HOUR** button repeatedly to set the correct hour. Pay attention to the AM/PM indicator.
4. Press the **MIN** button repeatedly to set the correct minute.
5. Once the time is set, slide the **LOCK/SET** switch back to the **LOCK** position to prevent accidental changes.

2. Setting the Alarm

1. Ensure the **LOCK/SET** switch is in the **SET** position.
2. Press the **ALARM** button on the top of the clock. The alarm time will flash on the display.
3. Press the **HOUR** button repeatedly to set the desired alarm hour. Observe the AM/PM indicator.
4. Press the **MIN** button repeatedly to set the desired alarm minute.
5. To activate the alarm, slide the **ALARM ON/OFF** switch on the bottom of the clock to the **ON** position.
6. Slide the **LOCK/SET** switch back to the **LOCK** position.

Note: To choose the alarm sound (beep, cuckoo, or rooster), you may need to cycle through the alarm settings by pressing the ALARM button multiple times after setting the time, or there might be a dedicated button/switch not explicitly detailed in the product description. If not, the default alarm sound will be used.

3. Using the Talking Function

To hear the current time announced, simply press the large central **Talk Button** on the top of the clock. The time will be announced in a friendly female voice.

4. Snooze Function

When the alarm sounds, press the large central **Talk Button** (which also functions as the snooze button) to activate the 10-minute snooze. The alarm will sound again after 10 minutes.

5. Adjusting Volume

Locate the **VOLUME** switch on the bottom of the clock. Slide it to either the **HI** (High) or **LO** (Low) position to adjust the volume

of voice announcements and alarms.

6. Hourly Announcement

The clock can be set to announce the time every hour. The method for activating this feature is typically integrated into the time setting or alarm setting sequence. Consult the specific instructions provided with your physical product if this option is not immediately apparent through the HOUR/MIN/TIME/ALARM buttons.

Maintenance

Cleaning

- Wipe the clock with a soft, dry cloth.
- Do not use abrasive cleaners or solvents, as these can damage the finish and electronic components.
- Avoid exposing the clock to excessive moisture.

Battery Replacement

When the display dims or the voice announcements become unclear, it is time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

Troubleshooting

Problem	Possible Cause	Solution
Clock does not turn on or display is dim.	Dead or incorrectly installed batteries.	Replace batteries with two fresh AA batteries, ensuring correct polarity.
Voice announcement is unclear or too quiet.	Low batteries or volume set to "LO".	Replace batteries. Check the VOLUME switch on the bottom and set it to "HI".
Alarm does not sound.	Alarm is not set, or ALARM ON/OFF switch is in "OFF" position.	Ensure the alarm time is set correctly. Slide the ALARM ON/OFF switch to "ON".
Time or alarm settings change accidentally.	LOCK/SET switch is in "SET" position.	After setting, always slide the LOCK/SET switch to the "LOCK" position.

Specifications

- **Brand:** Reizen
- **Model:** AX-AY-ABHI-61040
- **Display Type:** Digital LCD
- **Power Source:** 2 x AA Batteries (not included)
- **Material:** Plastic
- **Dimensions:** Approximately 11.68 cm (4.6 inches) diameter x 5.84 cm (2.3 inches) high
- **Weight:** Approximately 181.44 g (6.4 oz)
- **Special Features:** Talking function, 10-minute snooze, Hi/Lo volume, Lock/Set function, Hourly announcement, Blue backlight.

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact

your retailer. Specific warranty terms may vary by region and retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00I5PPSNG

More documents and user manuals: **https://manuals.plus/**