T'nB TCUN06

T'nB TCUN06 Universal 6-in-1 Remote Control User Manual

Model: TCUN06

1. Introduction

The T'nB TCUN06 Universal Remote Control is designed to simplify your home entertainment experience by consolidating up to six of your original remote controls into one device. This remote is compatible with various audio-visual equipment, including TVs, Satellite receivers, DVD players, VCRs, TNT (Digital Terrestrial Television) decoders, and auxiliary devices. It allows for both automatic and manual code searching to ensure compatibility with a wide range of brands and models.
This manual provides detailed instructions for setting up, operating, and maintaining your T'nB TCUN06 remote control. Please read it carefully before use.

2. Package Contents

- 1 x T'nB TCUN06 Universal 6-in-1 Remote Control
- 1 x User Manual (this document)

Note: 2 x AAA batteries are required and not included in the package.

3. Remote Control Overview

Familiarize yourself with the buttons and layout of your T'nB TCUN06 Universal Remote Control.



Image 1: Front view of the T'nB TCUN06 Universal Remote Control, showing all buttons including power, number pad, volume, channel, navigation, and device selection buttons (TV, SAT, DVD, VCR, TNT, AUX).



Image 2: Side view of the T'nB TCUN06 Universal Remote Control, illustrating its ergonomic design and slim profile.

4. Setup

4.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: If the battery cover feels loose, a small piece of adhesive tape can be used to secure it, ensuring proper contact and preventing accidental opening.

4.2. Programming the Remote Control

The T'nB TCUN06 remote control can be programmed using either an automatic code search or a manual code entry method. It is recommended to try the automatic search first.

4.2.1. Automatic Code Search

This method scans for compatible codes for your device.

1. Turn on the device you wish to control (e.g., TV, DVD player) manually.
2. Press and hold the desired device button on the remote (e.g.,**TV**, **DVD**) for approximately 5 seconds until the indicator light on the remote illuminates and stays on.
3. While the indicator light is on, press the**POWER** button once. The indicator light will start flashing, indicating that the remote is searching for a code.
4. Point the remote control at your device. The remote will send power-off signals every few seconds.
5. As soon as your device turns off, immediately press any device button (e.g.,**TV**, **SAT**) to save the code. The indicator light will turn off.
6. Test the remote's functions (e.g., volume, channel, power) with your device. If all functions work correctly, the programming is complete. If not, repeat the process from step 2.

Tip: If the remote cycles past the correct code, you may need to restart the automatic search or try the manual code entry method.

4.2.2. Manual Code Entry

This method requires you to enter a specific code for your device's brand. A list of codes is typically provided in a separate code booklet or can be found on the manufacturer's website (www.t-nb.com).

1. Turn on the device you wish to control.
2. Locate the 3 or 4-digit code for your device's brand in the code list.
3. Press and hold the desired device button (e.g.,**TV**, **DVD**) for approximately 5 seconds until the indicator light illuminates and stays on.
4. Enter the code using the number buttons on the remote control. After each digit, the indicator light may flash.
5. Once all digits are entered, the indicator light will turn off if the code is valid. If the light flashes rapidly and stays on, the code is invalid; try another code for your brand.
6. Test the remote's functions with your device. If all functions work, programming is complete. If not, try another code from the list for your brand.



Image 3: Back of the T'nB TCUN06 packaging, illustrating "Easy programming" and "Universal" features, including compatibility with over 900 brands like LG, Samsung, Philips, Grundig, JVC, and Panasonic.

5. Operating the Remote Control

Once programmed, your T'nB TCUN06 remote control functions similarly to your original remotes.

1. **Device Selection:** Press the corresponding device button (**TV**, **SAT**, **DVD**, **VCR**, **TNT**, **AUX**) to select the device you wish to control. The indicator light will briefly illuminate to confirm selection.
2. **Power On/Off:** Press the **POWER** button to turn the selected device on or off.
3. **Volume Control:** Use the **VOL+** and **VOL-** buttons to adjust the volume.
4. **Channel Change:** Use the **CH+** and **CH-** buttons to change channels.
5. **Number Pad:** Use the number buttons (**0-9**) to directly enter channel numbers or other numerical inputs.
6. **Navigation and OK:** Use the arrow buttons (**UP**, **DOWN**, **LEFT**, **RIGHT**) and the **OK** button for menu

navigation and selection.

7. **Menu and Exit:** Use the **MENU** button to access device menus and **EXIT** to leave them.
8. **Playback Controls:** For DVD/VCR devices, use the playback buttons (e.g., **PLAY**, **PAUSE**, **STOP**, **REWIND**, **FAST FORWARD**).
9. **Advanced Functions:** The remote supports various advanced functions depending on the programmed device. Refer to your device's original manual for specific functions.

Note: Not all buttons may be functional for every device, as compatibility depends on the original remote's features and the programmed code.

6. Maintenance

To ensure the longevity and optimal performance of your T'nB TCUN06 Universal Remote Control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's indicator light becomes dim or unresponsive. Always replace both AAA batteries at the same time. Do not mix old and new batteries or different types of batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the remote or exposing it to excessive moisture.

7. Troubleshooting

If you encounter issues with your T'nB TCUN06 Universal Remote Control, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Remote does not control device.	Incorrect code programmed or no code programmed.	Ensure the correct device button (TV, SAT, etc.) is selected. Repeat the programming steps (automatic or manual code search). Try different codes for your device's brand from the code list.
Some functions do not work.	The programmed code may not fully support all functions of your specific device model.	Try another code for your device's brand. Some advanced functions may not be universally compatible.
Indicator light does not illuminate or is dim.	Batteries are low or incorrectly inserted.	Replace both AAA batteries with new ones. Check battery polarity (+/-).
Remote range is poor.	Low batteries or obstruction.	Replace batteries. Ensure a clear line of sight between the remote and the device's infrared sensor. Ensure you are within the maximum operating range (up to 10 meters).

8. Specifications

Feature	Detail
Brand	T'nB
Model Number	TCUN06
Color	Black
Connectivity Technology	Infrared
Special Feature	Universal
Compatible Devices	TV, SAT, DVD, VCR, TNT, AUX
Maximum Supported Devices	6
Number of Buttons	6 (device selection buttons)
Controller Type	Remote Control
Maximum Range	10 Meters
Batteries Required	2 x AAA (not included)
Rechargeable Battery	No

9. Warranty and Support

The T'nB TCUN06 Universal Remote Control comes with a**1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
For technical support, warranty claims, or to find the latest code lists for your devices, please visit the official T'nB website:

www.t-nb.com

Please retain your proof of purchase for warranty purposes.

© 2023 T'nB. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question